

COMP 136



OPERATING, MAINTENANCE & PARTS MANUAL

SERIAL NO. 164058-1087971

CAT 750-S-CAT 7103 11-21 ACQUA LUNG 7Z 8625
REFERENCE SEE LITERATURE DIVISION OF V-14.

MODEL

XHP-750-S-CAT

PART NO. 35366004

JULY, 1985

COMPRESSOR SERIAL NUMBER RANGE

163058-164067

XHP 750-S-CAT

HR2-750-300

0418 928 826

IAN HEWITT

750-



STATEMENT CONCERNING THE USE OF THIS EQUIPMENT FOR BREATHING AIR AND/OR AQUA LUNG SERVICE

If the model number on this air compressor contains the letters "BAP", the compressor is suitable for use in breathing air services. In the absence of such a designation, the compressor is not considered as capable of producing air of breathing quality. For a compressor to be capable of use in breathing air services, it must be fitted with additional specialized equipment to properly filter and/or purify the air to meet all applicable federal, state and local laws, rules, regulations and codes, such as, but not limited to, OSHA 29 CFR 1910.134, Compressed Gas Association Commodity Specification G-7.1-1966, Grade D Breathing Air, and/or Canadian Standards Association. Should the Purchaser and/or User fail to add such specialized equipment and proceeds to use the compressor for breathing air service, the Purchaser/User assumes all liability resulting therefrom without any responsibility or liability being assumed by Ingersoll-Rand Company.

The Purchaser is urged to include the above provision in any agreement for any resale of this compressor.



A BATTERY CONTAINS SULFURIC ACID AND CAN GIVE OFF GASES WHICH ARE CORROSIVE AND POTENTIALLY EXPLOSIVE. AVOID CONTACT WITH SKIN, EYES AND CLOTHING. IN CASE OF CONTACT, FLUSH AREA IMMEDIATELY WITH WATER.

EXERCISE EXTREME CAUTION WHEN USING BOOSTER BATTERY. TO JUMP BATTERY, CONNECT ENDS OF ONE BOOSTER CABLE TO THE POSITIVE (+) TERMINAL OF EACH BATTERY. CONNECT ONE END OF OTHER CABLE TO THE NEGATIVE (-) TERMINAL OF THE BOOSTER BATTERY AND OTHER END TO A GROUND CONNECTION AWAY FROM DEAD BATTERY (TO AVOID A SPARK OCCURRING NEAR ANY EXPLOSIVE GASES THAT MAY BE PRESENT). AFTER STARTING UNIT,

ALWAYS DISCONNECT CABLES IN REVERSE ORDER.

NEVER INSPECT OR SERVICE UNIT WITHOUT FIRST DISCONNECTING BATTERY CABLE(S) TO PREVENT ACCIDENTAL STARTING.

USE EXTREME CARE TO AVOID CONTACTING HOT SURFACES (ENGINE EXHAUST MANIFOLD AND PIPING, AIR RECEIVER AND AIR DISCHARGE PIPING, ETC.).

DO NOT LOOSEN OR REMOVE OIL FILLER PLUG OR PERFORM ANY MAINTENANCE FUNCTIONS WITHOUT FIRST MAKING SURE ALL AIR PRESSURE HAS BEEN RELIEVED FROM UNIT.

NEVER OPERATE THIS MACHINE WITH ANY GUARDS REMOVED.

THE HIGH AIR PRESSURE DEVELOPED BY THIS MACHINE CAN BE HAZARDOUS.

THE AIR DISCHARGED FROM THIS UNIT IS NOT SUITABLE FOR HUMAN CONSUMPTION.

NEVER OPERATE UNIT WITHOUT FIRST OBSERVING ALL CAUTION AND WARNING DECALS AND CAREFULLY READING THE OPERATOR'S AND MAINTENANCE MANUAL FURNISHED WITH THIS MACHINE. ADDITIONAL COPIES OF THE MANUAL CAN BE OBTAINED FROM INGERSOLL-RAND COMPANY, MOCKSVILLE, NC 27028 USA.



®

OPERATING, MAINTENANCE & PARTS MANUAL

COMPRESSOR NOISE EMISSION CONTROL INFORMATION

THIS COMPRESSOR CONFORMS TO U.S. E.P.A. REGULATIONS FOR NOISE EMISSIONS APPLICABLE TO PORTABLE AIR COMPRESSORS. THE FOLLOWING ACTS OR THE CAUSING THEREOF BY ANY PERSON ARE PROHIBITED BY THE NOISE CONTROL ACT OF 1972:

(A) THE REMOVAL OR RENDERING INOPERATIVE, OTHER THAN FOR THE PURPOSE OF MAINTENANCE, REPAIR, OR REPLACEMENT, OF ANY NOISE CONTROL DEVICE OR ELEMENT OF DESIGN INCORPORATED INTO THIS COMPRESSOR IN COMPLIANCE WITH THE NOISE CONTROL ACT;

(B) THE USE OF THIS COMPRESSOR AFTER SUCH DEVICE OR ELEMENT OF DESIGN HAS BEEN REMOVED OR RENDERED INOPERATIVE.

NOTE: The above information applies only to units that are built in compliance with the U.S. Environmental Protection Agency.

IMPORTANT SAFETY INSTRUCTIONS

This manual provides important information to familiarize you with safe operating and maintenance procedures for your Ingersoll-Rand Compressor. Even though you may be familiar with similar equipment you **MUST** read and understand this manual before operating this unit.

LOOK FOR THESE SYMBOLS WHICH POINT OUT ITEMS OF EXTREME IMPORTANCE TO YOU AND YOUR CO-WORKERS' SAFETY. READ AND UNDERSTAND THOROUGHLY. HEED THE WARNING AND FOLLOW THE INSTRUCTIONS.

DANGER

You **MUST** follow all **DANGER** safety notes. If you do not follow the instructions, your mistake might likely result in **VERY SERIOUS INJURY** or **DEATH**.

WARNING

WARNING safety notes must **ALSO** be followed. Your mistake might result in **SERIOUS INJURY** to yourself or others.

CAUTION

CAUTION safety notes are **ALSO** very important. They point out to you where your mistakes could cause **PHYSICAL HARM** to you or others, or damage to the machine.

TABLE OF CONTENTS

SECTION

SAFETY WARNINGS

0

FOREWORD

1

GENERAL DATA

2

OPERATING INSTRUCTIONS

3

MAINTENANCE

4

LUBRICATION

5

SPEED AND PRESSURE REGULATION ADJUSTMENTS

6

TROUBLE SHOOTING

7

PARTS ORDERING INFORMATION

8


PARTS LIST

9

COMMON FASTENERS

10

FOREWORD



During the preparation of this manual every effort was made to ensure the adequacy and accuracy of the contents. Only in this manner can the owner be provided with a tool that will aid him in obtaining maximum performance and trouble-free service from the compressor. Since all classes of equipment require a certain amount of attention, the purpose of this manual is to acquaint an operator with the functions, operation and lubrication of the compressor. This manual also provides the owner with the maintenance requirements applicable to the various components designed or selected for incorporation into this unit. Special attention has been given in an effort to make sure that only components built with the very best materials and the finest workmanship have been used, thus reducing the maintenance requirement to a bare minimum.

Before starting the compressor, the instructions should be carefully read to obtain a thorough knowledge of the duties to be performed. Take pride in the compressor, keep it clean, and in good mechanical condition.

For complete protection and minimum down-time to facilitate the maintenance effort that is required, it is suggested that a complete set of recommended spares be kept on hand during and after the first few months of operation. For recommended spares, replacement parts or information regarding the condition or operation of your unit or for major servicing not covered in this manual, consult your nearest sales office, autonomous company or au-

thorized distributor. Be sure to specify the model and serial number of the compressor during any correspondence with a company representative. **THIS IS IMPORTANT.** The serial number of the unit will be found stamped on a plate attached to the unit. (The serial number of the unit is also permanently stamped in the metal of the frame side rail.)

In addition to preventive maintenance, the compressor aircend may require overhauling to maintain maximum output and performance of the unit. Your Ingersoll-Rand Company Construction Equipment Group Sales Offices and authorized distributors as well as Ingersoll-Rand International autonomous companies and authorized distributors now have a compressor aircend exchange program, therefore we do not recommend overhaul of the aircend by the customer. However, we do recognize the fact that circumstances may warrant field overhaul of the aircend. Prior to any disassembly or reassembly of the aircend we strongly suggest the owner contact the Customer Service Department, Ingersoll-Rand Company, Mocksville, North Carolina, 27028 for their advice and suggestions.

SECTION 2 — GENERAL DATA

Contents	Page	Contents	Page
Specifications	1		
Operating Controls & Instruments	2		

SPECIFICATIONS

COMPRESSOR

Aerial Delivery	770 cfm (334 litres per sec)
Rated Operating Pressure	400 psi (27.1 kgf per cm ²) (2070 kPa)
Safety Valve Setting	400 psi (27.1 kgf per cm ²) (2760 kPa)

ENGINE (DIESEL)

Manufacturer	Caterpillar Tractor Co.
Model	3306 TA
Speed, Full	1100 RPM
Speed, Idle	1200 RPM
Electrical System	24 Volt

FLUID CAPACITIES

Compressor Lubrication	42 U.S. gals. (159 litres)
Engine Crankcase (including filter)	23 quarts (22 litres)
Engine Coolant Capacity	55 quarts (52 litres)
Fuel Tank (Diesel)	144 U.S. gals. (540 litres)

UNIT MEASUREMENTS/WEIGHTS

Overall Length	12.54 feet (3.82 meters)
Overall Height	7.09 feet (2.16 meters)
Overall Width	6.69 feet (2.04 meters)
Net Weight (including lube oil)	10,600 lbs. (4800 kg)
Gross Weight (including fuel and coolant)	12,100 lbs. (5500 kg)


RUNNING GEAR

Tire Size/Load Range	8.00 x 10.5/E
Inflation Pressure (Cold)	75 psi (5.25 kgf per cm ²) (520 kPa)
Towing Speed (Maximum)	20 mph (32 km/hr)

CAUTION: ANY DEPARTURE FROM THE SPECIFICATIONS MAY MAKE THIS EQUIPMENT UNSAFE.

EXPENDABLE SERVICE PARTS

Compressor Oil Filter Element Kit	Part No. 35367879
Compressor Oil Separator Element	Part No. 35820893
Air Filter Element (Primary)	Part No. 35109263
Air Filter Element (Safety)	Part No. 35109271



3586-1479

OPERATING CONTROLS AND INSTRUMENTS

1. **Engine Oil Pressure Gauge** — Indicates lubricating oil pressure in the engine. See engine manual for normal range.
2. **Compressor Discharge Pressure Gauge** — Indicates pressure in receiver tank, normally from 0 psi/kPa to the rated pressure of the machine.
3. **Engine Coolant Temperature Gauge** — Indicates coolant temperature in the engine, with normal maximum from 180°F (82°C) to 200°F (93°C). The red band indicates an overheating condition.
4. **Engine Fuel Pressure** — Can be used to determine when filters are clogged by comparing with pressure when clean.
5. **Discharge Air Temperature Gauge** — Indicates air temperature in °F and °C.

Normal range is 190°F (88°C) to 230°F (110°C).

6. **Voltmeter** — Indicates voltage of the electrical system, normally approximately 28 volts.
7. **Fuel Level** — Indicates level in tanks, from empty to full.
8. **Engine Tachometer/Hourmeter** — Indicates engine speed, from 0 rpm at stop to 1800 rpm at full load. Records running time in hours for maintenance purposes.
9. **Ammeter** — Indicates charging rate of alternator, normally slightly positive.
10. **Start Button** — Switch that activates the engine starter.
11. **"Service Air" Button** — A 2-way valve that should be tripped (pushed) after engine is warmed up to obtain full air pressure at the service outlet.
12. **Stop Handle** — Is connected by cable to lever on the engine governor.
13. **"Safety Circuit Bypass" Button** — Switch that bypasses the engine low oil pressure sensor in the safety shutdown system during start-up.
- 14-16. **Air Filter Service Indicators** — Indicate acceptable (green flag) or excessive (red flag) restriction within engine or compressor air filter.
15. **Pressure Regulator Knob** — Valve that can be adjusted to automatically limit the operating pressure from 150 psi (10.5 kgf per cm²) to 300 psi (21.1 kgf per cm²).
- **Cold Starting Aid (Beside Control Panel)** — A valve for injecting a measured shot of ether from a pressurized can.
- **Fuel Primer Pump (On side of engine)** — Manually operated to prime fuel system.

SECTION 3 — OPERATING INSTRUCTIONS

Contents	Page	Contents	Page
Moving/Setting Up	1	Stopping	3
Before Starting	1	Safety Shutdown	4
Starting	2		

DANGER

Failure to follow these instructions could result in very serious personal injury or death.

- Do not store or transport material or equipment in or on compressor.
- Do not transport personnel in or on compressor.
- Do not climb on top of machine.

MOVING THE UNIT

DANGER

Failure to follow these instructions could result in very serious personal injury, death or property damage.

- Insure that the tires, wheels and running gear are in good condition and secure.
- Insure that the tires are inflated to 75 psi (5.25 kgf per cm²) (520 kPa).
- Do not tow this unit in excess of 20 mph (32 km/hr).
- Use a vehicle whose towing capacity is greater than the gross weight of this unit.

SETTING UP

- All fluid levels (engine oil, compressor oil and radiator coolant) should be checked and topped off while the unit is level and maintained at this level. Do not overfill either the engine crankcase or the compressor oil reservoir.
- Place the unit in a position as level as possible. The design of these units permits a 15-

degree lengthwise and a 15-degree side-wise limit on out-of-level operation.

- Check the wheels of the compressor unit.

CAUTION

Do not connect the air discharge on this unit into a common header with any other unit of any description, or any other source of compressed air, without first making sure a check-valve is used between the header and the unit. If this unit is connected in parallel with another unit of higher discharge pressure and capacity, a safety hazard could occur in a back-flow condition.

BEFORE STARTING

- Open manual blowdown valve on the receiver-separator tank to insure pressure is relieved in the system. Close this valve and all service valves.
- Check battery for proper connections and conditions.

WARNING

Exercise extreme caution when using a booster battery to start, as a spark in the presence of battery gases could cause an explosion and result in serious personal injury. To jumpstart, connect the ends of one booster cable to the positive (+) terminals of each battery (booster and weak). Then connect one end of the other cable to the negative (-) terminal of the booster

battery and the other end to the engine block (NOT TO THE NEGATIVE (-) TERMINAL OF THE WEAK BATTERY).

After starting:

- a. Reduce engine speed to idle.
 - b. Disconnect negative (-) cable from engine block; then from booster battery.
 - c. Disconnect positive (+) cable from both batteries (booster and weak).
- Check the compressor lubricating oil level. The proper oil level is mid-way on the sight window. Add oil if the level falls to the bottom of the sight window when the unit is not running. DO NOT OVERFILL. If necessary, refer to Section 5 — Lubrication, for recommended lubricant.
 - Check the engine lubricating oil level. Refer to the engine Operator's Manual for recommended lubricant.

⚠ DANGER

No smoking, sparks, or open flame near fuel.

- Check the fuel level. Use only clean diesel fuel. Refer to engine Operator's Manual for specifications.

NOTE

To minimize condensation (water) in the fuel tank, it is recommended to fill the tank at the end of each day.

- Check the service indicators on both air cleaners. If the flag in either shows red, refer to Section 4 — Preventive Maintenance, for service instructions.

⚠ WARNING

Use extreme care when removing a radiator pressure cap from the engine radiator. The sudden release of pressure from a heated cooling system can

result in a loss of coolant and possible personal injury by scalding.

- Check the coolant level in the radiator. The coolant must cover the tubes in the top tank (approximately 1 inch high on a clean measuring rod stuck down filler neck).

⚠ WARNING

Insure that all guards (fan, etc.) are in place and that all high pressure air and oil lines are safely connected.

NOTE

When operating in ambient temperatures above 90°F (32°C) and high humidity, drain any condensate from the receiver tank daily. Also inspect compressor oil for milky appearance. If found, refer to Section 5 — Lubrication.

STARTING THE UNIT

- Make sure the manual stop handle is pushed in all the way.
- Manually operate the hand-primer pump on side of engine to insure fuel pressure.

NOTE — COLD WEATHER

If the temperature is below 60°F (16°C), it may be necessary to use the cold starting aid (ether bottle and valve located adjacent to instrument panel). If so, operate the valve handle once prior to and sparingly during cranking. Engine damage can result from excessive use.

⚠ WARNING

Ether is an extremely flammable and toxic gas. It can be harmful or fatal if swallowed. Avoid contact with skin or eyes, or breathing the fumes. If swal-

lowed do not induce vomiting. Call a physician immediately.

If fluid enters the eyes, or fumes irritate the eyes, they should be flushed with large quantities of clean water for 15 minutes. A physician should be consulted.

Contents of the cylinder are under pressure. Store in a cool dry place. Do not incinerate or puncture.

STARTING BELOW 32°F/0°C

If the temperature is below 32°F/0°C it is essential to close the compressor air inlet valve prior to cranking.

1. Pull and lock the handle on the left side of the control panel.
2. As soon as the engine speed reaches 1200 rpm, immediately unlock and GRADUALLY push in on the handle. The air inlet valve must be opened as quickly as possible to prevent oil pump cavitation and loss of air end lubrication.

- Press the start button and the safety bypass button at the same time.

NOTE

If the engine fails to start within 20 seconds, release the starting switch and allow the starting motor to cool 1 to 2 minutes before engaging the starter again.

If the engine does not start after 2 or 3 attempts, refer to Section 7 of this manual.

- Release the start button when the engine speed increases.

NOTE

If the engine oil pressure does not rise within 5 seconds, stop the engine and

trouble shoot. Refer to Section 7 — Trouble Shooting, of this manual.

- Release the bypass button when the air discharge pressure reaches approximately 40 psi (2.81 kgf per cm²).
- Allow the engine to warm-up for 5 to 10 minutes, depending upon the ambient temperature, or until the coolant temperature reaches 140°F (60°C).
- Push the "service air" button (2-way valve). The engine should go to full speed and the discharge pressure rise to approximately 325 psi (2200 kPa). If there is no air being consumed the compressor will unload (intake will be throttled) and the engine speed drop to an idle.
- Compressor is now ready to furnish air when the service valve is opened.

NOTE

If the engine stops unexpectedly, refer to Section 7 — Trouble Shooting, for assistance.

STOPPING

- Close all service valves.
- Allow unit to run at idle for 3 to 5 minutes. This will allow engine components to cool gradually and thus promote longer engine life.
- Pull the stop handle and hold it out until the engine comes to a complete stop.

NOTE

Once the engine stops the automatic blowdown valve will begin to relieve all pressure from the receiver-separator system.

CAUTION

Never allow the unit to sit stopped with pressure in the receiver-separator

system. If necessary, open the manual blowdown valve.

! DANGER

Even after pressure is relieved from the receiver-separator system, any air supply line from the compressor to a tool or machine could remain under pressure and cause very serious personal injury or death. After the compressor stops, carefully open a valve at any tool or machine to exhaust the

pressure in any line prior to removal or servicing.

SAFETY SHUTDOWN

Should any of three shutdown failures occur (engine overheat, low engine oil pressure, excessive discharge air temperature), the unit will shut down. This occurs when the shutdown cylinder actuates the engine fuel rack thereby shutting off the fuel supply to the engine.

SECTION 4 — MAINTENANCE

Contents	Page	Contents	Page
General	1	Safety Shutdown System	5
Scheduled Maintenance	1	Compressor Oil Cooler	6
Compressor Oil Level	1	Hoses	6
Air Cleaner	1	Compressor Oil Filter	7
Required Maintenance Schedule	2	Fasteners	8
Engine Radiator	4	Coolant (Antifreeze)	8
Gauges	4	Compressor Oil	8
Fuel Tank	5	Running Gear	8
Belts (Fan/Alternator)	5	Receiver-Separator System	9
Battery	5	Scavenger Line	9
Tires	5		

GENERAL

In addition to periodic inspections, many of the components in these units require periodic servicing to provide maximum output and performance. Servicing may consist of pre-operation and post-operation procedures to be performed by the operating or maintenance personnel. The primary function of preventive maintenance is to prevent failure, and consequently, the need for repair. Preventive maintenance is the easiest and the least expensive type of maintenance. Maintaining your unit and keeping it clean at all times will facilitate servicing.

Refer to the engine Operator's Manual furnished with the unit for the specific requirements on preventive maintenance for the diesel engine.

SCHEDULED MAINTENANCE

The schedule on the following page is based on normal operation of the unit. This page can be reproduced and used as a checklist by the service personnel. In the event unusual environmental operating conditions (very humid, very dusty, etc.) exist, the schedule should be adjusted accordingly.

COMPRESSOR OIL LEVEL

The optimum operating level is midway of the sight window on the side of the receiver tank. **DO NOT OVERFILL.** A totally filled sight window in which the level is not visible indicates an over-full condition and requires that oil be drained. Add oil only when the level is near the bottom. Then add enough oil to bring the level midway of the sight window.

AIR CLEANER

Inspect daily the air cleaner service indicator. Never guess about restriction in the air cleaner, always know what condition your air cleaner is in with the assistance of the service indicator. If it is not working properly, or is missing, replace it. Maximum compressor and engine protection against the ravages of dust is possible only if the air cleaner is serviced at regular intervals or whenever the service indicator shows red. Visually inspect the position of the flag in the air cleaner restriction indicator. Normally, the flag in a service indicator shows green indicating that the filter element is still serviceable. If the flag shows red when the unit is operating at full speed or stopped, it is an indication that proper servicing of the filter element is necessary. Also squeeze the precleaner dumps (rubber valve) to insure that they are not clogged.



- ANY UNAUTHORIZED MODIFICATION OR FAILURE TO MAINTAIN THIS EQUIPMENT MAY MAKE IT UNSAFE AND OUT OF FACTORY WARRANTY.
- IF PERFORMING MORE THAN VISUAL INSPECTIONS: (1) DISCONNECT BATTERY CABLES, (2) OPEN MANUAL BLOW-DOWN VALVE, AND (3) INSURE DISCHARGE AIR PRESSURE GAUGE READS ZERO (0).
- USE EXTREME CARE TO AVOID CONTACTING HOT SURFACES (ENGINE EXHAUST MANIFOLD AND PIPING, AIR RECEIVER AND AIR DISCHARGE PIPING, ETC.).
- NEVER OPERATE THIS MACHINE WITH ANY GUARDS REMOVED.
- INCH AND METRIC HARDWARE WAS USED IN THE DESIGN AND ASSEMBLY OF THIS UNIT. CONSULT THE PARTS LISTING FOR CLARIFICATION OF USAGE.

REQUIRED MAINTENANCE SCHEDULE

UNIT _____

DATE _____

HOURS _____

SERVICEMAN _____

	DAILY	WKLY	MO.	3 MO. 500 HRS	6 MO. 1000 HRS	12 MO. 2000 HRS
COMPRESSOR OIL LEVEL/DRAIN CONDENSATE ..	C					
ENGINE OIL LEVEL	C					
AIR FILTER RESTRICTION INDICATORS	C					
AIR FILTER PRECLEANER DUMPS	C					
RADIATOR COOLANT LEVEL	C					
GAUGES	C					
FUEL TANK (FILL AT END OF DAY)	C					
FAN BELTS		C				
BATTERY ELECTROLYTE LEVEL		C				
TIRE PRESSURE AND SURFACES		C				
SAFETY SHUTDOWN SYSTEM			C			
EXTERNAL COOLER SURFACES (CLEAN)			C			
HOSES (OIL, AIR, HYDRAULIC, INTAKE, ETC.)			C			
COMPRESSOR OIL FILTERS				R		
FASTENERS (TIGHTEN)				C		
ANTIFREEZE (50% SOLUTION)				C		
COMPRESSOR OIL					R	
CHASSIS LUBE POINTS					C	
WHEEL BEARINGS						C
SEPARATOR ELEMENT						R
SAFETY SWITCH SETTING						C
SCAVENGE LINE						C
ENGINE	REFER TO ENGINE OPERATOR'S MANUAL OR DEALER					

C = CHECK (AND ADJUST OR REPLACE IF NECESSARY) R = REPLACE

In addition, the air cleaner assembly should be inspected every three (3) months or 500 hours to maintain maximum protection to the compressor and engine and to obtain maximum service life. Make sure that the inlet is free from obstructions. Make sure the air cleaner mounting bolts and clamps are tight and that the air cleaner is mounted securely. Check the air cleaner housing for dents or damage to the cleaner which could mean a leak. Inspect the air transfer ducting to the air cleaner and from the air cleaner to the compressor and the engine. Make sure that all clamps and flange joints are tight and that there are no leaks in the ducting.

To service an air cleaner, first remove and empty the dust cup. Dirt should not be allowed to build up closer than one inch (25.4 mm) from the baffle. If the restriction indicates that element servicing is required, loosen the wing nut and remove the primary element. After the primary and the safety elements have been removed, wipe the inside of the air cleaner housing with a clean, damp cloth. If this surface is not cleaned, the gasket on the new elements may sit on top of some of this dirt and create potential leaks. If dirt on the inside of the air cleaner is left on the clean side of the element gasket, it could find its way into the compressor or the engine.

In the event that the filter element must be re-used immediately, maintenance of the element should be performed as follows: Direct compressed air through the element in the direction opposite to the normal air flow through the element. Move the nozzle up and down while rotating the element. Be sure to keep the nozzle at least one inch (25.4 mm) from the pleated paper.

CAUTION

To prevent damage to the element, never exceed a maximum air pressure of 100 psi (7.03 kgf per cm²) (700 kPa).

Compressed air cleaning is recommended whenever the element must be reused immediately. A washed element must be thoroughly dried before re-using.

In the event the element is contaminated with dry dirt, oil or greasy dirt deposits, maintenance of the element should be performed as follows:

1. If only a mild cleaning is required, mix a sufficient amount of warm water and household detergent to allow the element to be fully submerged. Place the element in the cleaning solution and allow it to soak for five minutes. Agitate the element thoroughly in the cleaning solution after the soaking period. Remove the element from the cleaning solution, drain, then flush using a gentle stream of clean water.
2. If stronger cleaning is required, wash the element in a thoroughly mixed cleaning solution consisting of four tablespoons of household detergent and one-half teaspoon of trisodium phosphate to each gallon of lukewarm water. After soaking the element in the cleaning solution for not less than five minutes, agitate the element in the solution to make sure it is thoroughly cleaned.
3. Discard the dirty solution and rewash the element in a newly mixed bath of cleaning solution. After the element has been thoroughly cleaned, flush the element with clear water, using a gentle stream, being careful not to point the stream directly at the element.
4. Inspect the washed element for any damage by placing a bright light inside the element and rotating the element slowly. Keep in mind that the slightest rupture requires replacement of the element.
5. Allow the element to air-dry or use a stream of warm flowing air not exceeding a maximum temperature of 160°F (71°C).

Do not use compressed air or the heat of a light bulb to dry the element.

NOTE

It is highly recommended that new replacement elements be installed in the unit immediately in order that the unit be returned to service in the shortest possible time. In this manner the primary elements just removed for cleaning can be washed and stored as future replacement elements.

CAUTION

The safety element is not intended to be cleaned. For maximum protection and air cleaner service life, replace the safety cleaner with a new safety element every third primary element change.

Before installing new elements, always inspect the elements and their gaskets for shipping or storage damage. Carefully install the elements and their attaching wing nut. Reinstall the dust cap, making sure it seals 360 degrees around the air cleaner body.

Reset the restriction indicator to green. This may be done by pressing down on the indicator's flexible top.

ENGINE RADIATOR

The diesel engine cooling system functions not only to prevent the high combustion chamber temperatures from damaging the engine but, at the same time, must maintain the operating temperatures within safe limits. It is extremely important to maintain efficiency in the engine cooling system as the engine temperatures must be brought up to and maintained within a satisfactory range for efficient operation, but must also be kept from overheating in order to prevent damage to the engine moving parts.

To control the engine operating temperature range, the cooling system is designed so that the coolant is allowed to circulate only within the engine itself until normal operating temperatures are reached. At this point bypass-type thermostats open to allow all of the coolant to circulate through the radiator as well as the engine. The radiator, which consists of a core section through which the coolant is circulated, is designed to provide an extended surface through which the heat of the coolant can be dissipated. It is, therefore, extremely important that this core section be kept clean on the inside and free from dirt on the outside so that maximum heat transfer can take place.

Blowing compressed air, which contains a non-flammable safety solvent, between the cooling fins of the radiator in a direction opposite to that of the fan-circulated air should serve to keep the exterior cooling surfaces of the radiator section free of dirt and other foreign particles. This cleaning operation should be performed each month.

Sludge and rust in the cooling system can prevent normal heat transfer and in time can render the cooling system ineffective to properly maintain normal operating temperatures. The appearance of rust in a coolant system is a warning that the corrosion inhibitor has lost its effectiveness and that the system requires cleaning and flushing. Refer to the engine Operator's Manual for specific instructions on cleaning the cooling system.

Before placing the unit back into service, make sure that all hose connections are tight and that all radiator draining points are tight, including all of the engine drain cocks. Refill the radiator with coolant as recommended in the engine Operator's Manual. Never use plain water.

GAUGES

The instruments or gauges are essential for

safety, maximum productivity and long service life of the machine. Inspect the gauges prior to start-up and during operation to insure proper functioning. Refer to Section 3 — Operating Controls, for the normal readings.

FUEL TANK

The fuel tank on this unit should be filled daily or every eight hours if necessary. However, in order to prevent condensation from forming in the fuel tank, it should be filled immediately after the unit has been operated, for example, at the end of each working day. Using clean fuel in the fuel tank is vitally important and every precaution should be taken to insure that only clean fuel is either poured or pumped into the tank.

When filling the fuel tank on this unit, by methods other than a pump and hose, use a nonmetallic funnel which is kept for this purpose only. Make sure the funnel is wiped clean before using.

Every six months the drain plugs should be removed from the fuel tanks so that any sediment or accumulated condensate may be drained. When replacing the drain plugs, make sure they are tightened securely.

BELTS (FAN/ALTERNATOR)

The fan belts should be neither too tight nor too loose. A belt that is too tight imposes an undue load on the fan bearings and shortens the life of the belt. One that is too loose allows slippage and lowers the fan speed, causes excessive belt wear and leads to overheating of the cooling system.

Replace all belts in a set when one is worn, single belts of similar size should not be used as substitute for a matched belt set; premature belt wear can result because of the belt length variation. All belts in a matched belt set are within .032 inch (.79 mm) of their specified center distances.

NOTE

To prevent premature fan or crankshaft bearing failure and/or belt failure, it is very important to refer to belt adjustment instructions outlined in the Engine Operator's Manual.

BATTERY

The electrolyte level in each cell should cover the top of the plates. If necessary, top-up with clean distilled water.

NOTE

If the ambient temperature is below 32°F (0°C) any addition of water to the batteries must be done after the engine has been started to prevent the batteries from freezing.

TIRES

The proper inflation pressure for the tires is listed in Section 2 — General Data. Tires that have cuts or cracks or little tread should be repaired or replaced.

SAFETY SHUTDOWN SYSTEM

The operation of the safety shutdown system should be checked every month, or whenever it appears not to be operating properly. The three switches involved in this protective shutdown system are the discharge air temperature switch, the engine coolant high temperature switch and the engine oil pressure switch. The operation of these switches is extremely important in order to protect the engine and the compressor aircend from overheating. The engine oil pressure switch prevents the engine from being damaged due to oil starvation. Once a month remove a wire from the engine oil pressure switch to check the shutdown system for proper operation.

Once a year, the two temperature actuated switches should be tested by removing them

from the unit and placing them in a bath of heated oil. The engine coolant high temperature switch will require a temperature of approximately 210°F (99°C), while the discharge air high temperature switch will require approximately 248°F (120°C) to actuate. Test the switch's operation by connecting an ohmmeter between the two wire terminals. The ohmmeter should show zero ohms. When the switch is placed in the heated oil bath and its contacts open, the ohmmeter should indicate infinite ohms. Tap the switch lightly during the checking operation. Replace any defective switch before continuing to operate the unit. Test the engine oil pressure switch by removing it and connecting it to a source of controlled pressure while monitoring an ohmmeter connected to the switch terminals. As pressure is applied slowly from the controlled source, the switch should close at 12 psi (84 kPa) and show continuity through the contacts. As the pressure is slowly decreased to 10 psi (70 kPa) the contacts should open and the ohmmeter should show lack of continuity through the contacts. Replace a defective switch before continuing to operate the unit.

CAUTION

Never operate the unit with a defective safety shutdown switch or by shorting over a switch.

COMPRESSOR OIL COOLER

The compressor lubricating and cooling oil is cooled by means of the fin and tube-type oil cooler, located beside the engine radiator. The oil cooler is so arranged that the lubricating and cooling oil, flowing internally through the core section, is cooled by the air stream from the cooling fan flowing past the core section. When grease, oil and dirt accumulate on the exterior surfaces of the oil cooler, its efficiency is impaired. Each month it is recommended that the oil cooler be cleaned by directing compressed air which contains a non-

flammable safety solvent through the core of the oil cooler. This should remove the accumulation of grease, oil and dirt from the exterior surfaces of the oil cooler core so that the entire cooling area can transmit the heat of the lubricating and cooling oil to the air stream.

In the event foreign deposits, such as sludge and lacquer, accumulate in the oil cooler to the extent that its cooling efficiency is impaired, a resulting high discharge air temperature is likely to occur, causing shutdown of the unit. To correct this situation it will be necessary to clean it using a cleaning compound in accordance with the manufacturer's recommendations. Use only a dependable cleaning compound. This is of prime importance because different cleaners vary in concentration and chemical composition. After completing the cleaning procedure, the oil cooler must be flushed before returning to service.

HOSES

Each month it is recommended that all of the intake lines to and from the air cleaners, the engine cooling system hoses and all of the flexible hoses used for air, oil, brake and fuel be inspected.

To insure freedom from air leaks all rubber hose joints and the screw-type hose clamps must be absolutely tight. Regular inspection of these connections for wear or deterioration is a definite "must" if regular servicing of the air cleaners is not to prove futile. Premature wear of both the engine and compressor is assured whenever dust-laden air is permitted to enter the engine's combustion chamber or the compressor intake practically unfiltered.

All components of the engine cooling system, in addition to radiator maintenance, should be checked periodically to keep the engine operating at peak efficiency. The cooling system hoses should be checked for wear or deterioration and replaced if necessary. At

the same time the thermostats as well as the radiator pressure cap should be checked and replaced if necessary. Whenever new hoses are installed, be sure the connecting parts are properly aligned and that the hose is in its proper position before tightening the clamps. All external leaks should be corrected as soon as they are detected.

The flexible hoses used in the fuel, oil and air lines on these units are primarily used for their ability to accommodate relative movement between components. Secondly, they reduce vibration problems found with fixed piping and they permit much more flexibility in routing. Because these hose lines are flexible it is extremely important they be periodically inspected for wear and deterioration. Clamps are used to prevent hose cover abrasion through vibration. This abrasion may occur when two hose lines cross, or when a hose line rubs against a fixed point; therefore, it is necessary that all clamps be replaced if missing or that new clamps be added if required to prevent further wear. It is also important the operator does not use the hoses as convenient hand holds or steps. Such use can cause early cover wear and hose failure.

COMPRESSOR OIL FILTER

The compressor lubrication and cooling system is equipped with an in-line, canister-type filter with an integral bypass valve. This canister is mounted to the rear of the aircend. With a clean element installed all of the oil flows through the full element area, from the outside to inside. As the element becomes contaminated with dirt, the pressure drop across the element increases and the bypass valve cracks open, thus providing proportional filtration. As the element traps additional contaminants the pressure drop increases until the bypass valve fully opens. At this time little filtration is taking place but the oil is allowed to continue flowing through the system thus preventing any damage from loss of oil.

NOTE

The oil filter element must be replaced every 500 hours of operation. On new or overhauled units replace the filter element after the first 50 and 150 hours of operation; thereafter, replace the filter element every 500 hours of operation or three months, whichever comes first.

To service the oil filter it will first be necessary to shut the unit down, open the manual blowdown valve (on end of separator tank) and wipe off any dirt and oil from the exterior of the filter. This will assure that the system is relieved of all pressure and will prevent any contaminants from entering the system. Next, loosen the center bolt at the bottom of the filter canister; then remove the canister and element as a complete assembly. Remove the element from the canister and then clean the canister thoroughly.

CAUTION

If there is any indication of formation of varnishes, shellacs or lacquers on the oil filter element or in the canister, it is a warning that the compressor lubricating and cooling oil has improper characteristics and should be immediately changed. Refer to Section 5 — Lubrication.

Push the center bolt back through the canister far enough to inspect the gasket washer for any nicks or deterioration. Replace if necessary, then place the element assembly into the canister and bolt assembly. Using a new housing O-ring, install the canister/element assembly back into the filter head. Tighten the center bolt snug to tight. Start the unit and check the filter for any leaks. If leakage occurs, excess tightening of the center bolt will not correct the situation. Either the gasket washer on the center bolt or the housing O-ring has been damaged and must be replaced.

FASTENERS

Visually check entire unit in regard to bolts, nuts and screws being properly secured. Spot check several capscrews and nuts for proper torque. If any are found loose a more thorough inspection must be made.

COOLANT (ANTIFREEZE)

The engine cooling system was filled at the factory with a fifty per cent (50%) solution of water and permanent-type antifreeze for protection to some thirty degrees below zero ($-30^{\circ}\text{F}/-34^{\circ}\text{C}$). Every three months or 500 hours the protection level should be checked and adjusted if necessary. Refer to the engine Operator's Manual for recommendations and specifications on coolants and additives.

NOTE

If antifreeze is not used as the coolant, failure to drain the engine may cause serious damage during freezing weather.

COMPRESSOR OIL

The lubricating and cooling oil must be replaced every 1000 hours of operation or six months, whichever comes first. Refer to Section 5 — Lubrication, for detailed instructions and specifications.

RUNNING GEAR

The tie rod ends and steering knuckles are equipped with grease fittings and should be lubricated every six months.

Every six months the wheel bearings, grease seals and axle spindles should be inspected for damage and wear (i.e., from corrosion, scratches, metal particles, etc.). Replace any damaged or worn parts. Repack wheel bearings using a wheel bearing grease conforming to specification MIL-C-10924 and suitable for all ambient temperatures.

Grease can be replaced in a wheel bearing using a special fixture or by hand as follows. Place a spoonful of grease in the palm of one hand and take the bearing in the other hand. Push a segment of the wider end of the bearing down into the outer edge of the grease pile closest to the thumb. Keep lifting and pushing the bearing down into the edge of the grease pile until grease oozes out both from the top and from between the rollers. Then rotate the bearing to repeat this operation on the next segment. Keep doing this until you have the entire bearing completely filled with grease. Before installing bearing, place a light coat of grease on the bearing cups which are pressed in the hub.

NOTE

Excessive grease in the hub or grease cap serves no purpose due to the fact that there is no way to force the grease into the bearing. The manufacturer's standard procedure is to thoroughly pack the inner and outer bearing with grease and then to apply only a very small amount of grease into the grease cap.

If bearing adjustment is required or the hub has been removed for any reason, the following procedure must be followed to insure a correct bearing adjustment of .001 to .012 end play.

- (1) While rotating hub slowly to seat the bearings, tighten spindle nut to approximately 50 ft. lbs.
- (2) Loosen nut slightly to remove preload torque. Do not rotate hub.
- (3) Finger tighten nut until just snug and place cotter pin in the first nut castellation which lines up with cotter pin hole in spindle.
- (4) Bend over cotter pin legs to secure nut and clear grease or oil cap.

- (5) Nut should be free to move with only restraint being the cotter pin.

RECEIVER-SEPARATOR SYSTEM

WARNING **HOT PRESSURIZED FLUID**

Before performing any service on the compressor lubricating system:

- Open manual blowdown valve on separator tank cover.
- Insure pressure is relieved, with BOTH:
 - Discharge air pressure gauge reads zero (0).
 - No air discharging from manual blowdown valve.
- When draining oil, remove and replace (make tight) plug at bottom of separator tank.
- When adding oil, remove and replace (make tight) plug on side of separator tank.

In the compressor lubricating and cooling system, separation of the oil from the compressed air takes place in the receiver-separator tank. As the compressed air enters the tank, the change in velocity and direction drop out most of the oil from the air. Additional separation takes place in the oil separator element which is located in the top of the tank. Any oil accumulation in this separator element is continuously drained off by means of a scavenger line which returns the accumulated oil to the compressor.

The life of the oil separator element is dependent upon the operating environment (soot, dust, etc.) and should be replaced every twelve months or 2000 hours. To replace the element proceed as follows:

- Insure manual blowdown valve is open.

- Disconnect large hose from fitting in service valve.
- Remove (12) cover mounting screws.
- Remove cover and remove element.
- Remove any gasket material left on cover or tank.
- Install new element with drain hole at the bottom, as marked on element.
- Re-position cover.
- Replace (12) mounting screws; tighten in a cross-cross pattern to 600 ft. lbs. (800 Nm).
- Reconnect large hose.
- Replace scavenger line.

When replacing the element, the scavenger line should be thoroughly cleaned and the oil changed.

SCAVENGER LINE

The scavenger line originates at the receiver-separator tank cover and terminates at the compressor. Once a year or every 2000 hours of operation, whichever comes first, remove this line, thoroughly clean, then re-assemble.

NOTE

Excessive oil carry-over may be caused by an oil-logged separator element. Do not replace element without first performing the following maintenance procedure:

1. Check oil level. Maintain as indicated earlier in this section.
2. Thoroughly clean scavenger line.
3. Assure minimum pressure valve has proper setting.
4. Run unit at rated operating pressure for 30 to 40 minutes to permit element to clear itself.

SECTION 5 — LUBRICATION

Contents	Page
General Information.....	1
Compressor Oil Change.....	1

Contents	Page
Fluids & Lubricants Table.....	2

GENERAL INFORMATION

Lubrication is an essential part of preventive maintenance, affecting to a great extent the useful life of the unit. Different lubricants are needed and some components in the unit require more frequent lubrication than others. Therefore, it is important that the instructions regarding types of lubricants and the frequency of their application be explicitly followed. Periodic lubrication of the moving parts reduces to a minimum the possibility of mechanical failures.

The lubrication chart on page 5-2 shows those items requiring regular service and the interval in which they should be performed. A regular service program should be developed to include all items and fluids. These intervals are based on average operating conditions. In the event of extremely severe (hot, cold, dusty or wet) operating conditions, more frequent lubrication than specified may be necessary. Details concerning lubrication of the running gear are in Section 4 — Maintenance.

All filters and filter elements for air and compressor lubricant must be obtained through Ingersoll-Rand to assure the proper size and filtration for the compressor.

COMPRESSOR OIL CHANGE

These units are normally furnished with an initial supply of oil sufficient to allow operation of the unit for approximately 1000 hours; however, if a unit has been completely drained of all oil, it must be refilled with new oil before it is placed in operation. Refer to specifications in table on page 5-2.

NOTE

Some oil types are incompatible when mixed and result in the formation of varnishes, shellacs, or lacquers which may be insoluble. Such deposits can cause serious troubles including clogging of the filters. Where possible, do not mix oils of different types and avoid mixing different brands. A type or brand change is best made at the time of a complete oil drain and refill.

If the unit has been operated for 1000 hours, it should be completely drained of oil. If the unit has been operated under adverse conditions (high temperature/high humidity) or under long shutdown periods, an earlier change period may be necessary as oil deteriorates with time as well as by operating conditions. Complete replacement of the old oil with clean new oil every 1000 operating hours (or every six months, whichever comes first), depending upon operating conditions, is not only desirable; but is good insurance against the accumulation of dirt, sludge, or oxidized oil products.



Do not, under any circumstances, remove any drain plugs, or the oil filler plug from the compressor lubricating and cooling oil system without first making sure the air receiver system has been completely relieved of all air pressure.

Insure the following conditions are met:

- Discharge air pressure gauge reads zero (0).
- No air discharging from manual blowdown valve.

Completely drain the receiver-separator, piping, and oil cooler. If the oil is drained immediately after the unit has been run for some time, most of the sediment will be in suspension and, therefore, will drain more readily. However, the fluid will be hot and care must be taken to avoid contact with the skin or eyes.

After the unit has been completely drained

of all old oil, close the drain valve (under the receiver tank). Add oil in the specified quantity at the filler plug. Tighten the filler plug and run the machine to circulate the oil. Shut the machine down and after some 5 minutes check the oil level. Top-up as required to put the level in the middle of the sight window. DO NOT OVERFILL.

CAUTION

When using a synthetic lubricant, insure that all downstream components (hoses, valves, etc.) will be compatible.

FLUIDS AND LUBRICANTS TABLE


ITEM	FLUID	AMBIENT TEMP.	SPECIFICATION	INTERVAL	QUANTITY
Compressor	Lubricant	125°F to -10°F (52°C to -23°C) 125°F to 0°F (52°C to -18°C)	<ul style="list-style-type: none"> • DEXRON[®] or DEXRON[®] II ATF • I-R XHP 505 Synthetic 	1000 hours* 1000 hours*	42 U.S. gals. (159 litres)
Engine	<ul style="list-style-type: none"> • Oil • Coolant • Fuel 	Refer to Engine Operator's Manual or Manufacturer's Representative			55 quarts (52 litres) 144 U.S. gals. (540 litres)
Running Gear	Grease	All	MIL-G-10924	6 months	As Required
<ul style="list-style-type: none"> • Wheel Bearings • Other 	Grease	All	Multi-Purpose	6 months	As Required

DEXRON[®] — Reg. T.M. of General Motors Corp.

*Or every 6 months, whichever comes first.

SECTION 6 — SPEED AND PRESSURE REGULATION ADJUSTMENTS

Contents	Page
Before Starting Unit.....	1
After Starting Unit.....	2



35829340

The operating pressure of this unit was set at the factory to the maximum rating (at full speed). However, this pressure may be reset down to 150 psi (10.5 kgf per cm²).

Normally, regulation requires no adjusting, but if proper adjustment is lost, proceed as follows:

BEFORE STARTING UNIT:

1. With unit stopped, assure pneumatic actuating cylinder rod (A) is fully extended by adjusting engine throttle cable

(B). NOTE: Engine governor must be at full speed position.

2. Disconnect ballast spring (C) from butterfly valve pivot lever (D).
3. Adjust rod end bearing (E) until butterfly valve pivot lever (D) moves approximately 30° past vertical toward engine side of butterfly valve shaft (F). Tighten locknuts (G) to protect adjustment.
4. Loosen screw (H) on butterfly valve pivot lever (D) and turn shaft (F) until scribed

end of shaft is approximately 70° above the horizontal.

5. Tighten screw (H). Rotate butterfly valve open and closed several times to assure that linkages are not binding.

AFTER STARTING UNIT:

6. Allow engine to warm up. Push "service air" button (2-way valve) on control panel.
7. Adjust service valve to obtain 300 psi (21.1 kgf per cm²) on the discharge pressure gauge. NOTE: Pneumatic cylinder must be fully extended and discharge pressure at 300 psi (21.1 kgf per cm²) during steps 8 and 9. If this pressure cannot be obtained without pneumatic cylinder beginning to retract, loosen pressure regulator locknut (J) and adjust adjusting screw (K) "in" until 300 psi (21.1 kgf per cm²) can be maintained with pneumatic cylinder rod fully extended.
8. Adjust regulator adjusting screw (K) "in" an additional revolution. Adjust engine throttle cable (B) to obtain full load engine speed at 300 psi (21.1 kgf per cm²). Throttle cable adjustment can be made by screwing rod end bearing (L) "in" for increased speed and "out" for lower speed. Screw locknut (M) against rod end to protect adjustment.
9. When full load engine speed is attained, readjust pressure adjusting screw (K) "out" until pneumatic cylinder just begins to retract while still maintaining 300 psi (21.1 kgf per cm²). This adjustment is

important to limit regulation range. Tighten locknut (J) to protect adjustment.

10. Close service valve. Engine will slow to idle speed and butterfly valve will close. Observe idle speed, then shut unit down.
11. Adjust butterfly valve opening to change idle speed by first loosening screw (H) and then adjusting butterfly valve shaft (F). Open butterfly valve to reduce idle speed and close it to increase idle speed. Retighten screw (H). Restart unit and, after warm-up, push "service air" button. Recheck idle speed and repeat step, if necessary. NOTE: Idle speed should not be adjusted unless unit is fully warmed up.



WARNING
Do not attempt to adjust idle speed while engine is running, as personal injury may result.

12. Connect ballast spring (C) to butterfly valve pivot lever (D). Adjust spring using nut (N) on threaded rod (P) to assure there is no tension on spring when unit is operating at full load condition.
13. Slowly open service valve. If engine speed does not stabilize, increase tension on ballast spring (C). After speed stabilizes, lock adjustment with locknut (Q).
14. To select any pressure range between 150 and 300 psi (10.5 and 21.1 kgf per cm²), change adjustment of screw (K) to obtain desired discharge pressure at full load engine speed. Always lock and protect pressure setting of adjustment screw (K).

SECTION 7 — TROUBLE SHOOTING

Contents	Page
Introduction	1
Action Plan	1
Chart	2

INTRODUCTION

Trouble shooting for a portable air compressor is an organized study of a particular problem or series of problems and a planned method of procedure for investigation and correction. The trouble shooting chart that follows includes some of the problems that an operator may encounter during the operation of a portable compressor.

The chart does not attempt to list all of the troubles that may occur, nor does it attempt to give all of the answers for correction of the problems. The chart does give those problems that are most apt to occur. To use the trouble shooting chart:

- A. Find the "complaint" in the top horizontal line.
- B. Follow down that column to find the potential cause or causes. The numbers (1, 2, 3, etc.) suggest an order to follow in trouble shooting.
- C. A reference for most causes is indicated in the extreme right column and the footnotes. For example, "M" stands for Maintenance — Section 4 in this manual.

For trouble shooting electrical problems refer to the Wiring Diagram Schematic found in the Parts List section of this manual.

ACTION PLAN

A. THINK BEFORE ACTING

Study the problem thoroughly and ask yourself these questions:

- (1) What were the warning signals that preceded the trouble?

- (2) Has a similar trouble occurred before?
- (3) What previous maintenance work has been done?
- (4) If the compressor will still operate, is it safe to continue operating it to make further checks?

B. DO THE SIMPLEST THINGS FIRST

Most troubles are simple and easily corrected. For example, most complaints are "low capacity" which may be caused by too low an engine speed or "compressor overheats" which may be caused by low oil level.

Always check the easiest and most obvious things first; following this simple rule will save time and trouble.

C. DOUBLE CHECK BEFORE DISASSEMBLY

The source of most compressor troubles can be traced not to one component alone, but to the relationship of one component with another. Too often, a compressor can be partially disassembled in search of the cause of a certain trouble and all evidence is destroyed during disassembly. Check again to be sure an easy solution to the problem has not been overlooked.

D. FIND AND CORRECT BASIC CAUSE

After a mechanical failure has been corrected, be sure to locate and correct the cause of the trouble so the same failure will not be repeated. A complaint of "premature breakdown" may be corrected by repairing any improper wiring connections, but something caused the defective wiring. The cause may be excessive vibration.



TROUBLE SHOOTING I-R PORTABLE COMPRESSOR	CAUSE	COMPLAINT																		
		Short Air Cleaner Life	Excessive Oil In Air	Oil Seal Leak	Oil In Air Cleaner	Excessive Comp. Oil Temperature	Engine RPM Down	Will Not Unload	Safety Valve Relieves	Low CFM	Unit Shutdown	Unit Fails To Shutdown	Excessive Vibration	Won't Start Run	Alternator Lamp Stays On	Alternator Lamp Stays Off	Low Water Lamp Stays On	Low Water Lamp Stays Off	Engine Water Temp. Too High	Engine Oil Pressure Too Low
Dirty Operating Conditions		1		1		7				4									4	M
Wrong Air Filter Element		6					8			13										P
Defective Service Indicator		3																		P
Inadequate Element Cleaning		2								4										M
High Oil Level			1																	M
Out Of Level > 15°			2			3												6	3	O
Clogged Scavenge Orifice			3																	M
Defective Separator Element			8				9		7	12										P
Scavenge Tube Blocked			4																	M
Defective Scavenge Check Valve			5																	M
Defective Minimum Pressure Valve			7			15				11										P
Contaminated Lube Oil				2																M
Malfunctioning Seal				6																P
Scored Shaft				7																P
Malfunctioning Inlet Unloader		5			3			5	6	9										P
Incorrect Stopping Procedure		4			1															O
Dirty Cooler					6													5		M
Low Oil Level					4														2	M
Clogged Oil Filter Elements					8														5	M
Wrong Lube Oil				3	5														4	L
Malfunctioning Thermostat					13													11		P
Defective Oil Cooler Relief Valve					14															P
Recirculation Of Cooling Air					11													10		RA
Operating Pressure Too High			5		10	2		1	6									8		O A
Loose Or Broken Belts					9								1		1			7		M P
Blocked Or Restricted Oil Lines				4	16														6	—
Incorrect Linkage Adjustment						5				5										A
Clogged Fuel Filters						1							5							EM
Incorrect Pressure Regulator Adjustment						3	3	3	6											A
Ruptured Inlet Unloader Diaphragm				2		2		5												P
Defective Discharge Air Temp. Switch										7	1		11							P M
Defective Engine Water Temp. Switch										8	2		12							P M
Defective Engine Oil Pressure Switch										9	3		13							P M
Defective Shutdown Solenoid										10	4		14							P M
Malfunctioning Relay										11	5		15							P M
Loose Wire Connection										6			10	2	2		3			W P
Defective Master Off-On Switch										12	6		16		3		2			P
Blown Fuse										1			3							P
Low Battery Voltage													2	3						—
Malfunctioning Start Switch													4							P
Defective Safety Bypass Switch											7		17							P
<16 Volts At Shutdown Solenoid										13			1							—
Malfunctioning Alternator														4						P
Bulb Burnt Out															1		1			P
Low Water Level																1		3		M
Malfunctioning Probe																3	5			P
Malfunctioning Circuit Module																2	4			P
Ambient Temp. >125°F (52°C)					2													2		RA
Ice In Regulation Lines/Orifice						10	6	8	14											RA
Sep. Tank Blown Down Too Quickly			6																1	O
Malfunctioning Gauge					1														1	P
Dirty Air Filter						6				1										M
Malfunctioning Pressure Regulator						4	4	4	7											P
Malfunctioning Air Cylinder						7				10										P
Leaks In Regulator Piping							1	2	2											—
Compressor Oil Temp. Too High										3			7							TC
Engine Water Temp. Too High										4			8							TC
Engine Oil Pressure Too Low										5			9							TC
Out Of Fuel										2			6							—
Malfunctioning Fan					12							3						9		P
Rubber Mounts Damaged												2								P
Engine Malfunctioning						11				14		5	18					12	7	EM
Drive Coupling Defective												4								P
Airend Malfunctioning						17	12					6	19							P
Defective Safety Valve								9												P

Numbers (1, 2, 3, Etc.) Suggest
Order To Follow In
Trouble Shooting

SECTION 8 — PARTS ORDERING INFORMATION

Contents	Page	Contents	Page
General	1	How To Use Parts List	2
Description	1	How To Order	2
Fasteners	1	Terms And Conditions	2
Markings And Decals	2	Airend Exchange Program	3

GENERAL

This publication, which contains an illustrated parts breakdown, has been prepared as an aid in locating those parts which may be required in the maintenance of the unit. All of the compressor parts, listed in the parts breakdown, are manufactured with the same precision as the original equipment. For the greatest protection always insist on genuine Ingersoll-Rand Company parts for your compressor.

Ingersoll-Rand Company service facilities and parts are available worldwide. There are Ingersoll-Rand Company Construction Equipment Group Sales Offices and authorized distributors located in the principal cities of the United States. In Canada our customers are serviced by the Canadian Ingersoll-Rand Company, Limited. There are also Ingersoll-Rand International autonomous companies and authorized distributors located in the principal cities throughout the free world.

All parts orders pertaining to your engine should be referred to your particular engine manufacturer's authorized distributor or dealer.

DESCRIPTION

The illustrated parts breakdown illustrates and lists the various assemblies, subassemblies and detailed parts which make up this particular air compressor. This includes the standard unit along with some of the options that are available. A series of illustrations show each part clearly and in its correct location relative to the other parts in the illustration. The part number, the description of the part,

the quantity of parts required, and the part number of the next higher assembly in which a particular part is used are shown on each illustration. The quantities specified are the number of parts used per one assembly and are not necessarily the total number of parts used in the overall unit. Where no quantity is specified the quantity is assumed to be one.

Each description of a part is based upon the "noun first" method, i.e., the identifying noun or item name is always the first part of the description. In the event the item is an assembly or subassembly, the abbreviation "assy" or "subassy" follows the noun name. If the previous conditions do not exist, the noun name is followed by a single descriptive modifier. The descriptive modifier may be followed by words or abbreviations such as upper, lower, inner, outer, front, rear, RH, LH, etc. when they are required to modify the part noun.

In referring to the rear, the front or to either side of the unit, always consider the flywheel end of the engine as the rear of the unit. Standing at the rear of the unit facing the flywheel end of the engine, will determine the right and left sides.

FASTENERS

Both SAE/inch and ISO/metric hardware have been used in the design and assembly of these units. In the disassembly and reassembly of parts, extreme care must be taken to avoid damaging threads by the use of wrong fasteners. In order to clarify the proper usage and for exact replacement parts, all fasteners have been identified by part number, size and de-



scription. This will enable a customer to order fasteners that may be available locally rather than factory replacement parts. These parts are identified in tables that will be found at the rear of the parts illustrations. Any fastener that has not been identified by both part number and size is a specially engineered part that must be ordered by part number to obtain the exact replacement part. Refer to Section 10 — Common Fasteners.

MARKINGS AND DECALS

Exterior marking and decal (instructions and safety warnings) sets are listed with the enclosure in Section 9 — Parts List. The complete set of original equipment decals are available only as long as a particular model is in production. Afterwards, service decal sets (corporate signatures, safety warnings, etc.) are available. Contact the product support group at Mocksville for your particular needs and availability.

HOW TO USE PARTS LIST

- Turn to Section 9 — Parts List.
- Locate the area or system of the compressor in which the desired part is used and find illustration page number.
- Locate the desired part on the illustration by visual identification and make note of part number and description.

HOW TO ORDER

The satisfactory ordering of parts by a purchaser is greatly dependent upon the proper use of all available information. By supplying your nearest sales office, autonomous company or authorized distributor, with complete information, you will enable them to fill your order correctly and to avoid any unnecessary delays. In order that all avoidable errors may be eliminated, the following instructions are offered as a guide to the purchaser when ordering replacement parts:

- Always specify the model number of the unit as shown on the general data decal attached to the unit.
- Always specify the serial number of the unit. **THIS IS IMPORTANT.** The serial number of the unit will be found stamped on a plate attached to the unit. (The serial number of the unit is also permanently stamped in the metal of the frame side rail.)
- Always specify the number of the parts list publication.
- Always specify the quantity of parts required.
- Always specify the part number, as well as the description of the part, or parts, exactly as it is given on the parts list illustration.

In the event parts are being returned to your nearest sales office, autonomous company or authorized distributor, for inspection or repair, it is important to include the serial number of the unit from which the parts were removed.

TERMS AND CONDITIONS ON PARTS ORDERS

Acceptance: Acceptance of this offer is expressly limited to the exact terms contained herein. If purchaser's order form is used for acceptance of this offer, it is expressly understood and agreed that the terms and conditions of such order form shall not apply unless expressly agreed to by Ingersoll-Rand Company ("Company") in writing. No additional or contrary terms will be binding upon the Company unless expressly agreed to in writing.

Taxes: Any tax or other governmental charge now or hereafter levied upon the production, sale, use or shipment of material and equipment ordered or sold is not included in the Company's price and will be charged to and paid for by the Purchaser.

Delivery: Shipping dates are approximate. The Company will use best efforts to ship by the dates specified; however, the Company shall not be liable for any delay or failure in the estimated delivery or shipment of material and equipment or for any damages suffered by

reason thereof. Shipping dates shall be extended for delays due to acts of God, acts of Purchaser, acts of Government, fires, floods, strikes, riot, war, embargo, transportation shortages, delay or default on the part of the Company's vendors, or any other cause beyond the Company's reasonable control. Should Purchaser request special shipping instruction, such as exclusive use of shipping facilities, including air freight when common carrier has been quoted and before change order to purchase order can be received by the Company, the additional charges will be honored by Purchaser.

Warranty: The Company warrants that parts manufactured by it will be as specified and will be free from defects in materials and workmanship. The Company's liability under this warranty shall be limited to the repair or replacement of any part which was defective at the time of shipment provided Purchaser notifies the Company of any such defect promptly upon discovery, but in no event later than three (3) months from the date of shipment of such part by the Company.

Repairs and replacements shall be made by the Company F.O.B. point of shipment. The Company shall not be responsible for costs of transportation, removal or installation.

Warranties applicable to material and equipment supplied by the Company but wholly manufactured by others shall be limited to the warranties extended to the Company by the manufacturer which are able to be conveyed to the Purchaser.

THE COMPANY MAKES NO OTHER WARRANTY OR REPRESENTATION OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES, INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED. THE ONLY EXCEPTION TO THE PREVIOUS STATEMENT IS THE EXTENDED WARRANTY AS IT APPLIES TO THE SPECIAL AIREND EXCHANGE PROGRAM.

Limitation of Liability: The remedies of the Purchaser set forth herein are exclusive, and the total liability of the Company with respect to this order whether based on contract, warranty, negligence, indemnity, strict liability or otherwise, shall not exceed the purchase price of the part upon which such liability is based.

The Company shall in no event be liable to the Purchaser, any successors in interest or any beneficiary of this order for any consequential, incidental, indirect, special or punitive damages arising out of this order or any breach thereof, or any defect in, or failure of, or malfunction of the parts hereunder, whether based upon loss of use, lost profits or revenue, interest, lost

goodwill, work stoppage, impairment of other goods, loss by reason of shutdown or non-operation, increased expenses of operation or claims of customers of Purchaser for service interruption whether or not such loss or damage is based on contract, warranty, negligence, indemnity, strict liability or otherwise.

AIREND EXCHANGE PROGRAM

Your Ingersoll-Rand Company Construction Equipment Group Sales Offices and authorized distributors as well as Ingersoll-Rand International autonomous companies and authorized distributors now have an airend exchange program to benefit portable compressor users.

On the airend exchange program the exchange price is determined by the age and condition of the airend and may be classified by one of the following categories.

Category "A"

The airend must not be over two years old and must have reusable motor housing(s) and rotor(s).

Category "B"

The airend must be between two and five years old and returned with two or more reusable major castings.

Category "C"

The airend must be over five years old.

Your nearest sales office, autonomous company or authorized distributor must first contact the Parts Service Department at the factory at which your portable air compressor was manufactured for an airend exchange number. The airend must be tagged with this pre-assigned number and returned to the factory prepaid. The airend must be intact, with no excluded parts, otherwise the exchange agreement may be cancelled. The warranty on an exchange or factory rebuilt airend is 365 days.

NOTE

Airends being returned to the factory in connection with a warranty claim




must be processed through the Customer Service Department. **If returned as an exchange airtend, no warranty claim will be considered.**

SECTION 9 — PARTS LIST

Contents	Drawing No.	Page	Contents	Drawing No.	Page
Frame and Running Gear	35864495	9-2	Air Piping,		
Front and Rear Axle,			(Sheet 1)	35864560	9-18
(Sheet 1)	35864503	9-3	(Sheet 2)	35864560	9-19
(Sheet 2)	35864503	9-4	(Sheet 3)	35864560	9-20
Engine Assembly	35864511	9-5	Airend Piping,		
Airend Complete	35864529	9-6	(Sheet 3)	36735967	9-21
Airend Assembly,			(Sheet 4)	36735967	9-22
(Sheet 1)	36505865	9-7	Oil Temperature Bypass		
(Sheet 2)	36505865	9-8	Valve Piping	35864578	9-23
(Sheet 3)	36505865	9-9	Engine Piping	35864586	9-24
Blank Page		9-10	Oil Filter Complete	35864818	9-25
Radiator and Oil Cooler,			Battery and Mounting	35864594	9-26
(Sheet 1)	35864537	9-11	Instrument Panel Assembly	35864602	9-27
(Sheet 2)	35864537	9-12	Control Panel Assembly	35864610	9-28
Separator Tank Assembly	35864545	9-13	Wiring Diagram	36502201	9-29
Minimum Pressure and			Enclosure Complete,		
Service Valve Assembly	35830926	9-14	(Sheet 1)	35864636	9-30
Fuel Tank Complete	35832955	9-15	(Sheet 2)	35864636	9-31
Air Filter Assembly	35827484	9-16	(Sheet 3)	35864636	9-32
Air Intake Complete	35864552	9-17	(Sheet 4)	35864636	9-33





35A2D327
SCREW (8 REQD)
14A5C120
WASHER (8 REQD)
16A4C7
NUT (8 REQD)

35704782
BAIL - LIFTING

W86676
RIVET (4 REQD)
X1222T11
CUSHION (4 REQD)

36747038
FRAME

35A2D327
SCREW (16 REQD)
35321504
NUT (16 REQD)

35272350
TIRE
35148204
STEM
35145234
WHEEL

35272368
TIRE & WHEEL ASSY.

INGERSOLL-RAND COMPANY				FRAME AND RUNNING GEAR			
PORTABLE COMPRESSOR DIVISION				SHEET NO. 1 OF 1			
CHARGE NOS.				ILLUSTRATION NO. XHP-750-S-CAT			
DESCRIPTION				35864495			
REVISIONS	DATE	E/C NO.	CHARGE NO.	DATE	E/C NO.	CHARGE NO.	DESCRIPTION
A	6-18-85						
B							
C							
D							


FRONT AXLE ASSEMBLY PART NO. 35335439

INGERSOLL-RAND COMPANY
 NORTH CAROLINA DIVISION

FRONT & REAR AXLE

REVISION TO PARTS LIST NO.

DATE	ILLUSTRATION NO.	SHEET NO.	E/C
6-28-85	35864503	1 of 2	21973



36719631 R.H.
36719649 L.H.
KNUCKLE ASSY

35324789
GUIDING ARM ASSY.

35588953 R.H.
ROD END,
(2 RECD)

35324466
DRAW BAR ASSY

35324474
PIN

25A13C332
SPRING, PIN

36719219
LATCH, DRAWBAR

35141167
SPRING LATCH

25A13C332
SPRING, PIN

23A13C258
PIN,

36720662
WELDMENT, DRAWBAR

25A13C298
PIN, SPRING

35324326
PIN, GUIDING ARM

35319003
BUSHING, BRONZE (2 RECD)

W86707
FITTING, GREASE



35588961 L.H.
ROD END
(2 RECD)

35335488
AXLE WELDMENT, FRONT

35324805
ROD, TIE (2 RECD)

35140722 R.H.
35140730 L.H.
NUT, JAM (2 EA. RECD)

W86707
FITTING, GREASE
(4 RECD)




INGERSOLL-RAND COMPANY
PORTLAND COMPRESSOR DIVISION

DESCRIPTION
FRONT & REAR AXLE


REF TO PARTS LIST NO

DATE	ILLUSTRATION NO	SHEET NO	E/C
6-28-85	35864503	2 OF 2	2/1993



ENGINE FUEL FILTER	35310549
ENGINE OIL FILTER	35310556
ENGINE WATER SEPARATOR FILTER	35607605

REVISIONS		DATE	CHANGE NOS.	NAME OF PART
A	ORIGINAL RELEASE PER E/C 31993	6-28-85	5-30-85	ENGINE ASSEMBLY
B			NAME W. POOLE	INGERSOLL-RAND COMPANY <small>MOOREVILLE PLANT</small>
C			E/C NO.	MODEL NO. XHP-750-S-CAT
D				DRAWING NO. 35864511




	DATE	NAME	INGERSOLL-RAND CONTRACTOR EQUIPMENT
A	ORIGINAL RELEASE PER E/C 21993	G. GIVENS	
B	CHG. PER PAUL BEAVER'S REQUEST 7-2-85	DATE	PORTABLE OPERATIONS WHEELSILENCE 2008
C	CHG. PER E/C 22546 WEP	TITLE	
D			
E			

AIR END COMPLETE

MODEL	34" HET 40	DRAWING NO	I.C.
XHP-750-S-C	1	35864529	21993

- A 92304435 BOLT
 B 35856467 COVER, OIL SEAL
 C 95022372 O-RING
 D 35361286 BOLT
 E 36738573 CASE, GEAR
 F 35318146 BOLT
 G 35593516 SEAL, OIL
 H 35104082 NUT, LOCK
 J 35610195 BEARING, TAPER ROLLER
 K 35372002 SPACER
 L SEE GEAR SET CHART
 M 36504116 SHAFT, DRIVE
 N 35355809 KEY
 P 35610203 BEARING ROLLER
 Q 35300193 CLAMP PLATE
 R 35311463 BOLT
 S 35372010 SPACER
 T 35372028 SHIM SET
 U 39424916 RETAINER, BEARING
 V 35287648 BOLT
 W 35355806 SPACER
 X 35273408 BOLT
 Y 35364975 KEY
 Z 35361286 SCREW
 A1 35610153 PLATE, RETAINING
 A2 35371996 SPACER
 A3 35337580 SPACER
 A4 35306122 DOWEL
 A5 35272541 BOLT
 A6 36737161 HOUSING, MAIN
 A7 35355775 O-RING
 A8 35271139 BOLT
 A9 35272533 BOLT

CFM	INPUT SPEED	GEAR SET PART NO.	A/E ASSY. NO.
600	2100	36746436	35086339
750	2100	36746410	35086347
900	2100	36746428	35086354




SHEET 1 OF 3

REVISIONS	DATE	CHARGE NOS	NAME OF PART
A ORIGINAL RELEASE	6-16-87	6-16-87	AIR END ASSEMBLY
B		NAME	INGERSOLL-RAND COMPANY
C		W. POOLE	WORKING PART
D		E/C NO	MODEL NO
			HR-2
			DRAWING NO
			36505865

IN PUT SHAFT 003 ~~TH~~ END FLOOR MIN
 005 MAX


H1 DISCHARGE SIDE HOUSING END FLOAT .001 - .002
H1 STAGE ROTOR & HOUSING .005
LO STAGE .005 to .007 E .002 1 PART
H1 AMBIENT
SCREWS W/OUT
TOUCH



SHEET 2 OF 3

REVISIONS	DATE	CHANGE NOS	NAME OF PART
A	6-14-87	6-18-87	AIR END ASSEMBLY
B			INGERSOLL-RAND COMPANY
C			MOOREVILLE PLANT
D			DRAWING NO
E			36505861





- | | |
|----------------------------------|--------------------------------------|
| (A) 35355767 SHIM SET | (J) 35329149 BOLT |
| (B) 36504013 PLATE RETAINER | (K) 35300151 CLAMP PLATE |
| (C) 35271154 BOLT | (L) 35400022 BEARING ROLLER |
| (D) 35606203 BEARING TAPERED | (M) 35355803 SHIM SET |
| (E) SEE GEAR SET CHART | (N) 35400100 BEARING TAPERED |
| (F) 35355811 SPACER | (O) 35355812 SHIM SET |
| (G) 35355821 SHIM SET | (P) 35355813 PLATE RETAINER |
| (H) 35355814 CLAMP PLATE | (Q) 35355815 BOLT |
| (I) 35355821 BOLT | (R) 35355816 PISTON THRUST |
| (J) 35355817 DOWEL | (S) 35355817 O-RING |
| (K) 35355817 DOWEL | (T) 35355817 HOUSING 1st STAGE ROTOR |
| (L) 35355817 KEY | (U) 35355817 BOLT |
| (M) 35355817 ROTOR SET 1st STAGE | (V) 35355817 BOLT |
| (N) 35355817 RING SNAP | (W) 35355817 BOLT |
| (O) 35355817 BEARING ROLLER | (X) 35355817 O-RING |
| (P) 35355817 CLAMP PLATE | (Y) 35355817 PLATE COVER |
| (Q) 35355817 BOLT | |



SHEET 3 OF 3

REVISIONS	DATE	CHANGE NOS
1 ORIGINAL RELEASE	6-16-87	
2		
3		
4		
5		
6		
7		
8		
9		
10		

DATE	6-16-87	NAME OF PART	AIR END ASSEMBLY
DESIGNER	W. POOLE	COMPANY	INGERSOLL-RAND COMPANY
DRAWING NO.	HR-2	MODEL NO.	36505865




- (E7) 35355701 O-RING
- (E8) 36738128 HOUSING, REAR BEARING
- (E9) 35355874 SHIM SET
- (F1) 35600113 BEARING, TAPERED
- (F2) 35355957 CLAMP, PLATE
- (F3) 35311461 BOLT
- (F4) 35355999 SHIM SET
- (F5) 35355957 CLAMP, PLATE
- (F6) 35355957 CLAMP, PLATE
- (F7) 35271168 BOLT
- (F8) 35355957 CLAMP, PLATE
- (F9) 35355957 CLAMP, PLATE
- (G1) 35355957 CLAMP, PLATE
- (G2) 35355957 CLAMP, PLATE
- (G3) 35355957 CLAMP, PLATE
- (G4) 35355957 CLAMP, PLATE
- (G5) 35355957 CLAMP, PLATE
- (G6) 35355957 CLAMP, PLATE
- (G7) 35355957 CLAMP, PLATE
- (G8) 35355957 CLAMP, PLATE
- (G9) 35355957 CLAMP, PLATE
- (H1) 35355957 CLAMP, PLATE
- (H2) 35355957 CLAMP, PLATE
- (H3) 35355957 CLAMP, PLATE
- (H4) 35355957 CLAMP, PLATE
- (H5) 35355957 CLAMP, PLATE
- (H6) 35355957 CLAMP, PLATE
- (H7) 35355957 CLAMP, PLATE
- (H8) 35355957 CLAMP, PLATE
- (H9) 35355957 CLAMP, PLATE
- (J1) 35355957 CLAMP, PLATE
- (J2) 35355957 CLAMP, PLATE
- (J3) 35355957 CLAMP, PLATE
- (J4) 35355957 CLAMP, PLATE
- (J5) 35355957 CLAMP, PLATE
- (J6) 35355957 CLAMP, PLATE
- (J7) 35355957 CLAMP, PLATE

- (H6) 35600014 BEARING, ROLLER
- (H7) 35300201 CLAMP, PLATE
- (J1) 35311461 BOLT
- (J2) 35355999 SHIM SET
- (J3) 35271168 BOLT
- (J4) 35355973 SPACER, BEARING
- (J5) 35355866 SPACER
- (J6) 35600022 BEARING, ROLLER
- (J7) 35355965 PLATE, RETAINING


SHEET 3 OF 3

REVISIONS		DATE	CHARGE NOS	NAME OF PART	
A	ORIGINAL RELEASE	6-16-87		AIR END ASSEMBLY	
B				INGERSOLL-RAND COMPANY	
C				MODEL NO	
D				DRAWING NO	
				HR-2	36505865




SHT 1 OF 2

REVISIONS	DATE	CHARGE NOS	NAME OF PART
A ORIGINAL RELEASE	DATE	DATE	RADIATOR & OIL COOLER COMP
WAF PER E/C 21993	6-28-85	6-28-85	INGERSOLL-RAND COMPANY
H CAG PER PAUL	6/22/80	NAME	
WAF BEAUCH'S REQUEST	6-25-80	W. POOLE	
C		E/C NO.	MODEL NO.
D			XHP-750-S-CAT
			DRAWING NO.
			35864537




SHT 2 OF 2

REVISIONS	DATE	CHANGE NOS	NAME OF PART
A. ORIGINAL RELEASE	DATE	6-28-85	RADIATOR & OIL COOLER COMP.
YES PER SIC 21993	6-28-85		INGERSOLL-RAND COMPANY
B.		NAME	
		W POOLE	
C.		DATE	
D.		MODEL NO	
		FILED-7:0-5-CLT	35864537



REVISIONS		DATE	U/C NO	INGERSOLL-RAND COMPANY PORTLAND COMPRESSOR DIVISION		
1	ORIGINAL DESIGN	6-15-85		CHARGE NOS.		
2	PER PRC 71993			DESCRIPTION		
3	ERRON CORRECTION	11-5-86		SEPARATOR TANK ASSEMBLY		
4	PER PAUL BAZEL			JACOBEL NO	ILLUSTRATION NO	SHEET NO
				XHP-750-	35864545	1 of 1
				S-CAT		

MINIMUM PRESSURE VALVE COMPLETE
PART NO. 35820901



INGERSOLL-RAND COMPANY
PORTABLE COMPRESSOR DIVISION


DESCRIPTION

MINIMUM PRESSURE VALVE ASSEMBLY

REFER TO PARTS LIST NO. 35057579

DATE 3 6 52 ILLUSTRATION NO. 35830926 SHEET NO. 1 of 1

INGERSOLL-RAND COMPANY PORTABLE COMPRESSOR DIVISION		11	22305
DESCRIPTION	FUEL TANK COMPLETE	SHEET NO	1 OF 1
REFER TO PARTS LIST NO	35057587	ILLUSTRATION NO	35832955
DATE	4-25-66		



AIR FILTER COMPLETE
PART NO. 35902451
(2 REQD)

INGERSOLL-RAND COMPANY
PORTABLE COMPRESSOR DIVISION

DESCRIPTION AIR FILTER

REFER TO PARTS LIST NO.


DATE 17 2 80


ILLUSTRATION NO.

35827484



SHEET NO.

1 OF 1





REVISIONS		DATE	CHARGE NOS	NAME OF PART
A	ORIGINAL RELEASE			AIR INTAKE COMPLETE
WZ	PER EIC 21443	6-28-85	5-30-85	
B	CHG PCE			NAME
W	EIC 12887	4-16-87		G. GIVENS
C			EIC NO.	MODEL NO.
D				DATE
				XHP-750-S-CAT
				35864552




SHEET 1 OF 3

REVISIONS	DATE	CHARGE NOS	NAME OF PART
A. ORIGINAL RELEASE	6-28-85	G-11-B5	AIR PIPING
B. WIP FOR E/C 21993			
C. NAME			
D. W. POOLE			
E. F/C NO			
F. MODEL NO			
G. DRAWING NO.			

INGERSOLL-RAND COMPANY
RHP-750-S-CAT 35864560

SHEET 2 OF 3




REVISION	DATE	CHARGE NOS	NAME OF PART	AIR PIPING
A. ORIGINAL REQD	6-28-85	6-11-85		
WATER E/C 21915				
B. ENG DEL 412319	1-2-86		NAME	INGERSOLL-RAND COMPANY
WATER			W. POOLE	
C. ENG DEL 412319	3-21-86		MODEL NO	XHP-750-S-CAT
WATER			DRAWING NO	35864560

(B4)	16A4C7	NUT
(B5)	35132299	MUFFLER
(B6)	14A5C120	WASHER
(B7)	35A2D331	SCREW
(B8)	35824630	PIPE, SERVICE
(B9)	23A7S2	BUSHING
(C1)	35283464	ELBOW, 90°
(C2)	35310226	HOSE
(C3)	35287903	CONNECTOR
(C4)	108A23S12D	ADAPTER
(C5)	35287739	TEE
(C6)	35294693	HOSE
(C7)	35294735	ELBOW, 90°
(C8)	35295880	CONNECTOR
(C9)	35321165	REDUCER
(D1)	35283068	ELBOW, 90°
(D2)	35289578	HOSE
(D3)	35279116	ADAPTER
(D4)	19A7S5	NIPPLE
(D5)	35576115	VALVE, BALL
(D6)	23A7S2	BUSHING
(D7)	35283464	ELBOW, 90°
(D8)	35291269	HOSE
(D9)	35283076	CONNECTOR
(E1)	35287903	CONNECTOR
(E2)	35315431	HOSE
(E3)	104A23S1	ELBOW, 45°
(E4)	11A7S1	COUPLING
(E5)	35586304	GASKET
(E6)	35A2D327	SCREW
(E7)	35306091	REDUCER
(E8)	35306109	NUT
(E9)	35324987	NUT

[illegible]

QTY IN STOCK			
ITEM	QTY	DATE	BY
1	1	11/15/77	W. J. K.
2	1	11/15/77	W. J. K.
3	1	11/15/77	W. J. K.
4	1	11/15/77	W. J. K.
5	1	11/15/77	W. J. K.
6	1	11/15/77	W. J. K.
7	1	11/15/77	W. J. K.
8	1	11/15/77	W. J. K.
9	1	11/15/77	W. J. K.
10	1	11/15/77	W. J. K.




UNLESS OTHERWISE SPECIFIED:		TOLERANCE ON DRAWING	
A. DIMENSIONS		UNIT	
B. FINISH		PRIME PAINT PER I. R. SPEC.	
C. MATERIAL		MATERIAL	
D. WEIGHT		WEIGHT	
E. SURFACE		SURFACE	
F. FINISH		FINISH	
G. FINISH		FINISH	
H. FINISH		FINISH	
I. FINISH		FINISH	
J. FINISH		FINISH	
K. FINISH		FINISH	
L. FINISH		FINISH	
M. FINISH		FINISH	
N. FINISH		FINISH	
O. FINISH		FINISH	
P. FINISH		FINISH	
Q. FINISH		FINISH	
R. FINISH		FINISH	
S. FINISH		FINISH	
T. FINISH		FINISH	
U. FINISH		FINISH	
V. FINISH		FINISH	
W. FINISH		FINISH	
X. FINISH		FINISH	
Y. FINISH		FINISH	
Z. FINISH		FINISH	

INDEPENDENT BRAND
PORTLAND CEMENT
226/127.5-2 STAGE O/U
PIPING DRAWING
35279827





- (A) 95746434 BASKET
- (B) 35863620 VALVE, TEMP BY-PASS
- (C) 11A3J466 STUD
- (D) 14A5C133 WASHER
- (E) 16A4C8 NUT
- (F) 35370394 FLANGE
- (G) 35A2D380 SCREW
- (H) 95433751 TEE
- (J) 23A7S23 BUSHING
- (K) 35321876 VALVE, PRESS RELIEF
- (L) 23A7S11 BUSHING
- (M) 35294735 ELBOW, 90°
- (N) 35295807 HOSE

- (P) 14A5C101 WASHER
- (Q) 109A23S24 ELBOW, 90°
- (R) 35113729 HOSE
- (S) 35294750 ELBOW, 90°
- (T) 35309236 HOSE
- (U) 35100664 ELBOW, 90°
- (V) 36751295 STRAINER
- (W) 35609098 PLUG
- (X) 20A11C2M225 O-RING
- (Y) 35296417 ELBOW, 90°
- (Z) 35370063 FILTER



REVISIONS	DATE	REVISIONS	DATE	CHARGE NOS.	NAME OF PART
E	4-14-57	A	6-14-55		OIL TEMP BY-PASS VLV. PIPING
F	2-10-57	B	6-14-55		INGERSOLL-RAND COMPANY
G	2-10-57	C	6-14-55		W. POOLE
H	2-10-57	D	6-14-55		MODEL NO.
I	2-10-57	E	6-14-55		XHP-750-S-CAT
J	2-10-57	F	6-14-55		35864578
K	2-10-57	G	6-14-55		
L	2-10-57	H	6-14-55		
M	2-10-57	I	6-14-55		
N	2-10-57	J	6-14-55		
O	2-10-57	K	6-14-55		
P	2-10-57	L	6-14-55		
Q	2-10-57	M	6-14-55		
R	2-10-57	N	6-14-55		
S	2-10-57	O	6-14-55		
T	2-10-57	P	6-14-55		
U	2-10-57	Q	6-14-55		
V	2-10-57	R	6-14-55		
W	2-10-57	S	6-14-55		
X	2-10-57	T	6-14-55		
Y	2-10-57	U	6-14-55		
Z	2-10-57	V	6-14-55		
		W	6-14-55		
		X	6-14-55		
		Y	6-14-55		
		Z	6-14-55		

SCR 557N
PN 35370063



REVISIONS		DATE	E/C NO.	CHARGE NOS.	DESCRIPTION	WORKING NO.	ALLOCATION NO.	WEEK NO.	E/C NO.
A.	ORIGINAL RELEASE	6-27-85	21993						
B.	ENG. P.R.	1-2-86	21179						
C.	ENG. P.R.	3-21-86	21224						
D.	ENG. P.R.	8-8-86	31801						
E.	ENG. P.R.	8-8-86	31801						


INGERSOLL-RAND COMPANY
PORTABLE COMPRESSOR DIVISION

ENGINE PIPING

35864586

1 OF 1


36745388
OIL FILTER ASSEMBLY



	DATE	NAME	INGENSOIL BRAND (OPTIONAL FORMER NAME)
A	6/21/80	G. GIVENS	
B	11-3-85	map	PORTABLE OPERATIONS
C			
D			

OIL FILTER COMPLETE

MOBILE	SHEET NO.	LOGGING NO.
XHP-750-S-CAT		358664818




INGERSOLL-RAND COMPANY
PORTLAND COMPRESSOR DIVISION


DESCRIPTION
BATTERY & MOUNTING

REFER TO PARTS LIST NO.

6-28-85	35864594	101	21993
DATE	ILLUSTRATION NO.	SHEET NO.	E.C.



DATE	CHANGE NOS.	NAME OF PART	DRAWING NO.
4	ORIGINAL RELEASE	CONTROL PANEL ASSEMBLY	35864610
5	PER. EIC 21815	6-28-85	
6	CHG. PER. PANEL	W POOLE	
7	CHG. BEARING, ROD END	W POOLE	
8	CHG. BEARING, ROD END	W POOLE	
9	CHG. BEARING, ROD END	W POOLE	
10	CHG. BEARING, ROD END	W POOLE	
11	CHG. BEARING, ROD END	W POOLE	
12	CHG. BEARING, ROD END	W POOLE	
13	CHG. BEARING, ROD END	W POOLE	
14	CHG. BEARING, ROD END	W POOLE	
15	CHG. BEARING, ROD END	W POOLE	
16	CHG. BEARING, ROD END	W POOLE	
17	CHG. BEARING, ROD END	W POOLE	
18	CHG. BEARING, ROD END	W POOLE	
19	CHG. BEARING, ROD END	W POOLE	
20	CHG. BEARING, ROD END	W POOLE	
21	CHG. BEARING, ROD END	W POOLE	
22	CHG. BEARING, ROD END	W POOLE	
23	CHG. BEARING, ROD END	W POOLE	
24	CHG. BEARING, ROD END	W POOLE	
25	CHG. BEARING, ROD END	W POOLE	
26	CHG. BEARING, ROD END	W POOLE	
27	CHG. BEARING, ROD END	W POOLE	
28	CHG. BEARING, ROD END	W POOLE	
29	CHG. BEARING, ROD END	W POOLE	
30	CHG. BEARING, ROD END	W POOLE	
31	CHG. BEARING, ROD END	W POOLE	
32	CHG. BEARING, ROD END	W POOLE	
33	CHG. BEARING, ROD END	W POOLE	
34	CHG. BEARING, ROD END	W POOLE	
35	CHG. BEARING, ROD END	W POOLE	
36	CHG. BEARING, ROD END	W POOLE	
37	CHG. BEARING, ROD END	W POOLE	
38	CHG. BEARING, ROD END	W POOLE	
39	CHG. BEARING, ROD END	W POOLE	
40	CHG. BEARING, ROD END	W POOLE	
41	CHG. BEARING, ROD END	W POOLE	
42	CHG. BEARING, ROD END	W POOLE	
43	CHG. BEARING, ROD END	W POOLE	
44	CHG. BEARING, ROD END	W POOLE	
45	CHG. BEARING, ROD END	W POOLE	
46	CHG. BEARING, ROD END	W POOLE	
47	CHG. BEARING, ROD END	W POOLE	
48	CHG. BEARING, ROD END	W POOLE	
49	CHG. BEARING, ROD END	W POOLE	
50	CHG. BEARING, ROD END	W POOLE	
51	CHG. BEARING, ROD END	W POOLE	
52	CHG. BEARING, ROD END	W POOLE	
53	CHG. BEARING, ROD END	W POOLE	
54	CHG. BEARING, ROD END	W POOLE	
55	CHG. BEARING, ROD END	W POOLE	
56	CHG. BEARING, ROD END	W POOLE	
57	CHG. BEARING, ROD END	W POOLE	
58	CHG. BEARING, ROD END	W POOLE	
59	CHG. BEARING, ROD END	W POOLE	
60	CHG. BEARING, ROD END	W POOLE	
61	CHG. BEARING, ROD END	W POOLE	
62	CHG. BEARING, ROD END	W POOLE	
63	CHG. BEARING, ROD END	W POOLE	
64	CHG. BEARING, ROD END	W POOLE	
65	CHG. BEARING, ROD END	W POOLE	
66	CHG. BEARING, ROD END	W POOLE	
67	CHG. BEARING, ROD END	W POOLE	
68	CHG. BEARING, ROD END	W POOLE	
69	CHG. BEARING, ROD END	W POOLE	
70	CHG. BEARING, ROD END	W POOLE	
71	CHG. BEARING, ROD END	W POOLE	
72	CHG. BEARING, ROD END	W POOLE	
73	CHG. BEARING, ROD END	W POOLE	
74	CHG. BEARING, ROD END	W POOLE	
75	CHG. BEARING, ROD END	W POOLE	
76	CHG. BEARING, ROD END	W POOLE	
77	CHG. BEARING, ROD END	W POOLE	
78	CHG. BEARING, ROD END	W POOLE	
79	CHG. BEARING, ROD END	W POOLE	
80	CHG. BEARING, ROD END	W POOLE	
81	CHG. BEARING, ROD END	W POOLE	
82	CHG. BEARING, ROD END	W POOLE	
83	CHG. BEARING, ROD END	W POOLE	
84	CHG. BEARING, ROD END	W POOLE	
85	CHG. BEARING, ROD END	W POOLE	
86	CHG. BEARING, ROD END	W POOLE	
87	CHG. BEARING, ROD END	W POOLE	
88	CHG. BEARING, ROD END	W POOLE	
89	CHG. BEARING, ROD END	W POOLE	
90	CHG. BEARING, ROD END	W POOLE	
91	CHG. BEARING, ROD END	W POOLE	
92	CHG. BEARING, ROD END	W POOLE	
93	CHG. BEARING, ROD END	W POOLE	
94	CHG. BEARING, ROD END	W POOLE	
95	CHG. BEARING, ROD END	W POOLE	
96	CHG. BEARING, ROD END	W POOLE	
97	CHG. BEARING, ROD END	W POOLE	
98	CHG. BEARING, ROD END	W POOLE	
99	CHG. BEARING, ROD END	W POOLE	
100	CHG. BEARING, ROD END	W POOLE	



REVISIONS	DATE	CHANGE NO.	NAME OF PART
1 ORIGINAL RELEASE	6-18-85	5-10-85	DECAL-WIRING DIAGRAM
2 PER E/C 21943	8-23-85		INGERSOLL-RAND COMPANY
3 CWO PER	8-24-85		W. POOLE
4 PAUL BELVER			
		E/C NO.	MODEL NO.
			XHP-750-S-CAT
			DRAWING NO.
			36502201



(A)	35252568	SCREW	(L)	35145259	SCREW
(B)	35252618	NUT	(M)	35252758	SCREW
(C)	35144344	SCREW	(N)	11A5C4	WASHER
(D)	35252493	SCREW	(P)	14A5C76	WASHER
(E)	35145077	NUT			
(F)	35144484	SCREW			
(G)	35144492	NUT			
(H)	3542D111	SCREW			
(I)	W30033	SPRING			
(K)	67A4C3	NUT			

INGERSOLL-RAND COMPANY
PORTABLE COMPRESSOR DIVISION

ENCLOSURE COMPLETE


REFER TO PARTS LIST NO.

DATE 6-27-85
ILLUSTRATION NO. 35864636
SHEET NO. 1 OF 4



1	35252493	SCREW
2	35145077	NUT
3	35144344	SCREW
4	35A2D109	SCREW
5	1445C76	WASHER
6	35A2055	SCREW
7	35252600	NUT
8	35252618	NUT
9	35144336	SCREW

INGERSOLL-RAND COMPANY "PORTAL" Counterbalance Loader	ENCLOSURE COMPLETE	ILLUSTRATION NO. 6-28-85	35864636
DESCRIPTION	REFER TO PARTS LIST NO.	DATE	REV.



(A)	35252493	SCREW	(K)	35A25107	SCREW
(B)	35145077	NUT	(L)	11A5C4	WASHER
(C)	35252725	SCREW	(M)	14A5C76	WASHER
(D)	35144484	SCREW	(N)	35252568	SCREW
(E)	35144492	NUT	(P)	35252618	NUT
(F)	83A2C97	SCREW			
(G)	14A5C36	WASHER			
(H)	21A4C9	NUT			
(J)	35144344	SCREW			

35504604
STRIP, L. H. FILLER
(A) (B)

35705441
PANEL, TOP FILLER
(K) (L) (M)

35704766
SUPPORT, REAR
(J) (B)

36746972
SUPPORT, REAR HOUSING
(N) (P)

35504596
STRIP, R. H. FILLER
(A) (B)

35518885
BRACE

35705623
HOUSING, L. H. REAR
(A) (B)

35705615
HOUSING, R. H. REAR
(A) (B)

DECAL SET PART NO. 35086933

INGERSOLL-RAND COMPANY
NEWARK, CONNECTICUT 06101

DESCRIPTION
ENCLOSURE COMPLETE

REFER TO PARTS LIST NO.

DATE
1-8-86

ILLUSTRATION NO.

35864636

SHEET NO.

4

E.C.

SECTION 10 — COMMON FASTENERS

Contents	Page	Contents	Page
Table 1 — SAE/Inch	1	Table 2 — ISO/Metric	3
Screws	1	Screws, Nuts & Washers	3
Nuts & Washers	2	Grade Identification	3
Grade Identification	2		

TABLE 1
SAE/Inch Screws

Part Number	Size	Description
109A2A311N	#10—24 UNC—3A x 1/4"	Hex Socket Head (Nylon Insert)
119A2A146	1/4"—20 UNC—3A x 1/4"	Hex Socket Head
119A2A148	1/4"—20 UNC—3A x 1/4"	Hex Socket Head
119A2A198N	1/4"—16 UNC—3A x 1/4"	Hex Socket Head (Nylon Insert)
119A2A206N	1/4"—16 UNC—3A x 1"	Hex Socket Head (Nylon Insert)
119A2A251	1/2"—13 UNC—3A x 1 1/4"	Hex Socket Head
121A2A175	1/4"—16 UNC—3A x 1"	Hex Socket Head
125A2C1012	#10—24 UNC—3A x 1 1/4"	Hex Socket Head
133A2C44	#4—40 UNC—3A x 1/2"	Hex Socket Head
35A2D110	1/4"—16 UNC—2A x 1/4"	Hex Head
35A2D111	1/4"—16 UNC—2A x 1"	Hex Head
35A2D112	1/4"—16 UNC—2A x 1 1/4"	Hex Head
35A2D113	1/4"—16 UNC—2A x 1 1/2"	Hex Head
35A2D117	1/4"—16 UNC—2A x 2"	Hex Head
35A2D118	1/4"—16 UNC—2A x 2 1/4"	Hex Head
35A2D119	1/4"—16 UNC—2A x 2 1/2"	Hex Head
35A2D120	1/4"—16 UNC—2A x 2 3/4"	Hex Head
35A2D122	1/4"—16 UNC—2A x 3 1/4"	Hex Head
35A2D127	1/4"—16 UNC—2A x 4 1/2"	Hex Head
35A2D131	1/4"—16 UNC—2A x 6"	Hex Head
35A2D168	3/16"—14 UNC—2A x 1 1/2"	Hex Head
35A2D174	3/16"—14 UNC—2A x 3"	Hex Head
35A2D215	1/2"—13 UNC—2A x 1/4"	Hex Head
35A2D216	1/2"—13 UNC—2A x 1/2"	Hex Head
35A2D217	1/2"—13 UNC—2A x 1"	Hex Head
35A2D219	1/2"—13 UNC—2A x 1 1/4"	Hex Head
35A2D221	1/2"—13 UNC—2A x 1 1/2"	Hex Head
35A2D223	1/2"—13 UNC—2A x 2"	Hex Head
35A2D229	1/2"—13 UNC—2A x 3 1/2"	Hex Head
35A2D231	1/2"—13 UNC—2A x 4"	Hex Head
35A2D232	1/2"—13 UNC—2A x 4 1/4"	Hex Head
35A2D3	1/4"—20 UNC—2A x 1/4"	Hex Head
35A2D323	1/4"—11 UNC—2A x 1 1/4"	Hex Head
35A2D325	1/4"—11 UNC—2A x 1 1/2"	Hex Head
35A2D326	1/4"—11 UNC—2A x 1 3/4"	Hex Head
35A2D327	1/4"—11 UNC—2A x 2"	Hex Head
35A2D328	1/4"—11 UNC—2A x 2 1/4"	Hex Head
35A2D329	1/4"—11 UNC—2A x 2 1/2"	Hex Head
35A2D330	1/4"—11 UNC—2A x 2 3/4"	Hex Head
35A2D331	1/4"—11 UNC—2A x 3 1/4"	Hex Head
35A2D380	1/4"—10 UNC—2A x 2 1/2"	Hex Head
35A2D382	1/4"—10 UNC—2A x 3"	Hex Head
35A2D384	1/4"—10 UNC—2A x 3 1/2"	Hex Head

35A2D386	1/4"—10 UNC—2A x 4"	Hex Head
35A2D388	1/4"—10 UNC—2A x 4 1/2"	Hex Head
35A2D390	1/2"—10 UNC—2A x 5"	Hex Head
35A2D4	1/4"—20 UNC—2A x 1/4"	Hex Head
35A2D5	1/4"—18 UNC—2A x 3"	Hex Head
35A2D54	1/4"—18 UNC—2A x 1/2"	Hex Head
35A2D57	1/4"—18 UNC—2A x 3/4"	Hex Head
35A2D58	1/4"—18 UNC—2A x 1"	Hex Head
35A2D60	1/4"—18 UNC—2A x 1 1/4"	Hex Head
35A2D62	1/4"—18 UNC—2A x 1 1/2"	Hex Head
35A2D64	1/4"—18 UNC—2A x 2"	Hex Head
35A2D7	1/4"—20 UNC—2A x 1 1/4"	Hex Head
35A2D8	1/4"—20 UNC—2A x 1 3/4"	Hex Head
35130293	1/4"—16 x 1/4"	Hex Head Self-Tapping
35130301	1/4"—18 x 1/4"	Hex Head Self-Tapping
35141365	1/4"—18 x 1/2"	Hex Head Self-Tapping
35144328	1/4"—20 x 1/4"	Whiz-Lock®
35144336	1/4"—18 x 1/2"	Whiz-Lock®
35144344	1/4"—16 x 1"	Whiz-Lock®
35144484	1/4"—20 x 1"	Whiz-Lock®
35145242	1/4"—20 x 1 1/4"	Whiz-Lock®
35148030	1/2"—13 x 1"	Hex Head Self-Tapping
35252451	1/4"—20 x 1"	Whiz-Lock®
35252493	1/4"—16 x 1/4"	Whiz-Lock®
35252568	1/2"—13 x 1 1/4"	Whiz-Lock®
35252741	1/2"—13 x 1 1/2"	Whiz-Lock®
35252758	1/2"—13 x 1"	Whiz-Lock®
35287119	1/4"—14 x 1/2"	Hex Head Self-Tapping
35321108	1/4"—18 x 1"	Whiz-Lock®
35334879	1/4"—18 x 1"	Hex Head Self-Tapping
36A2A275	1/4"—18 x 2"	Hex Head
87A2C93P	10—24 x 1/4"	Round Head Phillips
95095659	10—24 x 1/2"	Round Head Phillips

Whiz-Lock® is a Registered T.M. of MacLean-Fogg Nut Co.
(Alternate Suppliers are Acceptable for this Part Number)





SAE/Inch Nuts

Part Number	Size	Description
16A4C1	1/4"—20 UNC—2B	Hex
16A4C2	1/4"—18 UNC—2B	Hex
16A4C3	1/4"—16 UNC—2B	Hex
16A4C5	1/2"—13 UNC—2B	Hex
16A4C7	1/2"—11 UNC—2B	Hex
16A4C8	1/2"—10 UNC—2B	Hex
16A4C17	1/2"—11 UNC—2B	Hex
21A4C10	1/2"—24 UNC—2B	Hex
21A4C5	4—40 UNC—2B	Hex
21A4C8	8—32 UNC—2B	Hex
21A4C9	10—24 UNC—2B	Hex
22A4C1	1/2"—28 UNC—2B	Hex
22A4C2	1/4"—24 UNF—2B	Hex
22A4C3	1/4"—24 UNC—2B	Hex
22A4C5	1/2"—20 UNC—2B	Hex
23A4C3	1/4"—24 UNC—2B	Hex
23A4C4	1/4"—20 UNC—2B	Hex
23A4C5	1/2"—20 UNC—2B	Hex
23A4C8	1/2"—16 UNC—2B	Hex
35144492	1/4"—20	Whiz-Lock*
35145077	1/4"—16	Whiz-Lock*
35252600	1/4"—18	Whiz-Lock*
35252618	1/2"—13	Whiz-Lock*
35265388	10—24	Whiz-Lock*
35321504	1/4"—11	Hex
35326420	1/2"—13	Hex
35332980	1/2"—13	Hex
35336700	1/4"—18	Torque/Grade 8
66A4C3	1/4"—24	Nyloc
66A4C5	1/4"—20	Nyloc
67A4C1	1/4"—20	Nyloc
67A4C2	1/4"—18	Nyloc
67A4C3	1/4"—16	Nyloc
67A4C5	1/2"—13	Nyloc

SAE/Inch Washers

Part Number	Size	Description
11A5C1	#10	Flat (Commercial)
11A5C2	1/4"	Flat (Commercial)
11A5C3	1/4"	Flat (Commercial)
11A5C4	1/4"	Flat (Commercial)
11A5C6	1/2"	Flat (Commercial)
11A5C8	3/4"	Flat (Commercial)
12A5C2	1/4"	Flat (SAE)
12A5C3	1/4"	Flat (SAE)
12A5C4	1/4"	Flat (SAE)
12A5C6	1/2"	Flat (SAE)
12A5C13	1.25"	Flat (SAE)
12A5C15	1.50"	Flat (SAE)
12A5D24	#10	Flat (SAE)
14A5C101	1/2"	Spring Lock
14A5C110	1/4"	Spring Lock
14A5C119	1/4"	Spring Lock
14A5C120	1/4"	Spring Lock
14A5C133	1/4"	Spring Lock
14A5C28	#8	Spring Lock
14A5C36	#10	Spring Lock
14A5C55	1/4"	Spring Lock
14A5C55P	1/4"	Spring Lock, Cadmium Plate
14A5C65	1/4"	Spring Lock
14A5C65P	1/4"	Spring Lock, Cadmium Plate
14A5C76	1/4"	Spring Lock
14A5C9	#4	Spring Lock
14A5C91	1/4"	Spring Lock
35326233	1/4"	Spring Lock

SAE/Inch Capscrews
Grade Identification

Grade identification markings are normally stamped on the heads of capscrews, however these marks may vary slightly from manufacturer to manufacturer.				
SAE Grade	1 or 2	5	6 or 7	8
				
QUALITY OF MATERIAL	MATERIAL INDETERMINATE	MINIMUM COMMERCIAL	MEDIUM COMMERCIAL	BEST COMMERCIAL
USAGE	UNACCEPTABLE	PREFERRED	ALTERNATE IF PREFERRED NOT AVAILABLE	*

* Due to their material and hardness, grade 8 capscrews are not suitable for use on the pressurized air systems on an Ingersoll-Rand Portable Air Compressor. On uses other than pressure applications, grade 8 capscrews are acceptable.

TABLE 2
ISO/Metric Screws

Part Number	Size (mm)	Description
35271139	M12 x 1.75 x 40	Hex Head, Class 8.8
35271147	M12 x 1.75 x 30	Hex Head, Class 8.8
35271154	M10 x 1.50 x 30	Hex Head, Class 8.8
35271162	M8 x 1.25 x 30	Hex Head, Class 8.8
35271188	M10 x 1.5 x 25	Hex Head, Class 8.8
35272533	M12 x 1.75 x 35	Hex Head, Class 8.8
35272541	M16 x 2.25 x 40	Hex Head, Class 8.8
35273408	M8 x 1.25 x 20	Hex Head, Class 8.8
35273416	M8 x 1.25 x 25	Hex Head, Class 8.8
35273945	M10 x 1.5 x 55	Hex Head, Class 8.8
35275007	M6 x 1 x 25	Hex Head, Class 8.8
35279025	M8 x 1.25 x 20	Self-Tapping
35284678	M8 x 1.25 x 20	Hex Head, Class 8.8
35284793	M8 x 1.25 x 70	Hex Head, Class 8.8
35285584	M12 x 1.75 x 25	Hex Head, Class 12.9
35287648	M8 x 1.25 x 16	Hex Head, Class 8.8
35288422	M8 x 1.25 x 80	Hex Head, Class 8.8
35291640	M14 x 2 x 40	Hex Head, Class 8.8
35290113	M16 x 2.25 x 75	Hex Head, Class 8.8
35295013	M10 x 1.5 x 70	Hex Head, Class 8.8
35295351	M10 x 1.5 x 25	Hex Head, Class 8.8
35295484	M12 x 1.75 x 16	Hex Head, Class 8.8
35295757	M12 x 1.75 x 20	Hex Head, Class 8.8
35300623	M16 x 2.25 x 140	Hex Head, Class 8.8
35300771	M6 x 1 x 20	Self-Tapping
35301746	M12 x 1.75 x 55	Hex Head, Class 8.8
35307818	M6 x 1 x 10	Hex Head, Class 8.8
35309715	M16 x 2.25 x 25	Hex Head, Class 8.8
35317106	M6 x 1 x 25	Hex Head, Class 8.8
35317148	M8 x 1.25 x 60	Hex Head, Class 8.8
35321520	M16 x 2.25 x 30	Hex Head, Class 8.8
35322908	M6 x 1 x 20	Hex Head, Class 8.8
35327550	M8 x 1.25 x 70	Hex Head, Class 8.8

35330539	M12 x 1.75 x 100	Hex Head, Class 8.8
35353978	M10 x 1.25 x 50	Hex Head, Class 8.8
35356518	M20 x 2.5 x 90	Hex Head, Class 8.8
35358266	M10 x 1.5 x 160	Hex Head, Class 8.8
35358274	M16 x 2.25 x 25	Hex Head, Class 8.8
35361807	M16 x 2.25 x 120	Hex Head, Class 8.8
92304385	M10 x 1.5 x 16	Hex Head, Class 8.8
92304393	M10 x 1.5 x 20	Hex Head, Class 8.8
92304419	M10 x 1.5 x 40	Hex Head, Class 8.8
92304435	M12 x 1.75 x 25	Hex Head, Class 8.8
92304450	M12 x 1.75 x 50	Hex Head, Class 8.8
92329309	M10 x 1.5 x 35	Hex Head, Class 8.8
92341239	M20 x 2.5 x 40	Hex Head, Class 8.8
92367663	M16 x 2.25 x 35	Hex Head, Class 8.8
92368687	M6 x 1 x 72	Hex Head, Class 8.8

ISO/Metric Nuts

Part Number	Size (mm)	Description
35273366	M10 x 1.5	Lock, Nylon Insert
35275023	M8 x 1.25	Lock, Nylon Insert
35304047	M12 x 1.75	Lock, Nylon Insert
35356526	M20 x 2.5	Lock, Nylon Insert
35361815	M16 x 2.0	Lock, Nylon Insert
90103839	M16 x 2.0	Hex
90103854	M12 x 1.75	Hex
92304500	M6 x 1	Hex
92304526	M10 x 1.5	Hex

ISO/Metric Washers

Part Number	Size (mm)	Description
35317114	6	Flat
92304658	6	Spring Lock
92304674	10	Flat

ISO/Metric Capscrews
Grade Identification

Capscrews shall be identified with their property class symbol with the manufacturer's identification symbol at his option. Grade identification markings (8.8, etc.) are normally located at the top of the screw head, or alternatively, on the side of the head, and may either be raised or depressed at option of the manufacturer.

CLASS	4.6	5.8	8.8	9.8	10.9	12.9
SAE EQUIVALENT	EQUIVALENT TO SAE GRADE 1	EQUIVALENT TO SAE GRADE 2	EQUIVALENT TO SAE GRADE 5	APPROXIMATELY 9 PER CENT STRONGER THAN SAE GRADE 5	EQUIVALENT TO SAE GRADE 8	NO EQUIVALENT SAE GRADE
USAGE	UNACCEPTABLE	UNACCEPTABLE	PREFERRED	ALTERNATE IF PREFERRED NOT AVAILABLE	*	*

* Due to the material and hardness, class 10.9 and 12.9 capscrews are not suitable for use on the pressurized air systems on an Ingersoll-Rand Portable air Compressor. On uses other than pressure applications, class 10.9 and 12.9 capscrews are acceptable.