


HP ProLiant ML570 Generation 4 Server User Guide



March 2006 (First Edition)
Part Number 406862-001



© Copyright 2006 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation.

Linux is a U.S. registered trademark of Linus Torvalds.

March 2006 (First Edition)
Part Number 406862-001

Audience assumptions

This document is for the person who installs, administers, and troubleshoots servers and storage systems. HP assumes you are qualified in the servicing of computer equipment and trained in recognizing hazards in products with hazardous energy levels.

Contents

Component identification	7
Front panel components	7
Front panel LEDs and buttons	8
Rear panel components	9
Rear panel LEDs and buttons	10
System board components	11
System maintenance switches	12
NMI switch	13
System LEDs and internal health LED combinations	13
System board LEDs and Systems Insight Display codes	14
SAS and SATA device numbers	15
SAS and SATA hard drive LEDs	16
SAS and SATA hard drive LED combinations	16
Memory board LEDs and components	17
DIMM slots	20
Hot-plug power supply LEDs	20
Hot-plug fans	21
Hot-plug fan LEDs	22
Operations	23
Power up the server	23
Power down the server	23
Extend the server from the rack	23
Unlock and remove the tower bezel	25
Remove the rack bezel	26
Remove the access panel	27
Install the access panel	27
Setup	28
Optional installation services	28
Rack planning resources	29
Optimum environment	29
Space and airflow requirements	29
Temperature requirements	30
Power requirements	30
Electrical grounding requirements	30
Rack warnings and cautions	31
Identifying tower server shipping carton contents	32
Identifying rack server shipping carton contents	32
Installing hardware options	32
Setting up a tower server	33
Installing the server into the rack	34
Powering up and configuring the server	36
Installing the operating system	36
Registering the server	37
Hardware options installation	38
Processor option	38
Memory options	43
General memory configuration requirements	43
Memory boards and DIMMs	47

Configuring the memory	53
Hot-plug SAS and SATA hard drive option	54
Installing a hot-plug SAS or SATA hard drive	55
Removing a hot-plug SAS hard drive	56
Drive options	57
Optical drives	57
Removable media devices	58
Redundant hot-plug power supply option	62
Redundant hot-plug fans	63
Installing hot-plug fans	63
Replacing hot-plug fans	64
Expansion board options	65
Removing an expansion slot cover	66
Installing expansion boards	66
Tower-to-rack conversion	67
Removing the casters	68
Removing the tower cover	69
Installing the rack bezel	69
Rack-to-tower conversion	71
Removing the cable management arm	72
Removing the server from the rack	72
Removing the server rails	73
Installing the tower cover	73
Installing the casters	74
Installing the tower bezel	74
Cabling	76
Storage device cabling guidelines	76
Tape drive cabling to the USB connector	76
SAS cabling	77
Video connector cabling	77
Battery-backed write cache cabling	78
Software and configuration utilities	79
Configuration tools	79
SmartStart software	79
HP ROM-Based Setup Utility	80
Array Configuration Utility	81
HP ProLiant Essentials Rapid Deployment Pack	81
Re-entering the server serial number and product ID	81
Management tools	82
Automatic Server Recovery	82
ROMPaq utility	82
Integrated Lights-Out 2 technology	82
StorageWorks library and tape tools	82
HP Systems Insight Manager	83
Management Agents	83
Redundant ROM support	83
USB support	83
Diagnostic tools	84
HP Insight Diagnostics	84
Integrated Management Log	84
Array Diagnostic Utility	84
Remote support and analysis tools	84

HP Instant Support Enterprise Edition	84
Keeping the system current	85
Drivers	85
ProLiant Support Packs	85
Operating system version support	85
System Online ROM Flash Component Utility	85
Change control and proactive notification	86
Natural language search assistant	86
Care Pack	86
Troubleshooting	87
Troubleshooting resources	87
Pre-diagnostic steps	87
Important safety information	87
Symptom information	89
Prepare the server for diagnosis	90
Loose connections	90
Service notifications	90
Troubleshooting flowcharts	91
Start diagnosis flowchart	91
General diagnosis flowchart	92
Server power-on problems flowchart	94
POST problems flowchart	97
OS boot problems flowchart	98
Server fault indications flowchart	100
POST error messages and beep codes	102
Electrostatic discharge	103
Preventing electrostatic discharge	103
Grounding methods to prevent electrostatic discharge	103
Regulatory compliance notices	104
Regulatory compliance identification numbers	104
Federal Communications Commission notice	104
FCC rating label	104
Class A equipment	105
Class B equipment	105
Declaration of conformity for products marked with the FCC logo, United States only	105
Modifications	106
Cables	106
Canadian notice (Avis Canadien)	106
European Union regulatory notice	106
Disposal of waste equipment by users in private households in the European Union	107
Japanese notice	107
BSMI notice	107
Korean notice	108
Laser compliance	108
Battery replacement notice	108
Taiwan battery recycling notice	109
Power cord statement for Japan	109
Specifications	110
Server specifications	110
Environmental specifications	110


Technical support.....	112
Before you contact HP.....	112
HP contact information.....	112
Customer self repair.....	113
Acronyms and abbreviations.....	120
Index.....	123

Component identification

In this section

Front panel components	7
Front panel LEDs and buttons	8
Rear panel components.....	9
Rear panel LEDs and buttons	10
System board components.....	11
System LEDs and internal health LED combinations	13
System board LEDs and Systems Insight Display codes.....	14
SAS and SATA device numbers	15
SAS and SATA hard drive LEDs	16
SAS and SATA hard drive LED combinations.....	16
Memory board LEDs and components.....	17
DIMM slots	20
Hot-plug power supply LEDs	20
Hot-plug fans	21
Hot-plug fan LEDs	22


Front panel components



Item	Description
1	Drive blank for optional diskette or DVD-ROM drive
2	DVD-ROM drive
3	Video/USB connector
4	USB connector


Item	Description
5	Tape drive blank
6	SAS hard drives

Front panel LEDs and buttons




Item	Description	Status
1	UID button and LED	Blue = Activated Flashing blue = System being managed remotely Off = Deactivated
2	Internal health LED	Green = Normal (system on) Flashing amber = System health degraded Flashing red = System health critical
3	External health (power supply) LED	Green = Normal (system on) Flashing amber = Redundant power supply failure Flashing red = Power supply failure. No operational power supplies.
4	NIC 1 link/activity LED (embedded NIC only)	Green = Linked to network Flashing green = Linked with activity on the network Off = No network connection
5	NIC 2 link/activity LED (embedded NIC only)	Green = Linked to network Flashing green = Linked with activity on the network Off = No network connection
6	Power On/Standby button and system power LED	Green = System has AC power and is powered up. Amber = System has AC power and is in standby mode. Off = System has no AC power.

Rear panel components




Item	Description
1	NIC 1 connector
2	NIC 2 connector
3	USB connectors
4	iLO 2 connector
5	Parallel connector
6	PCI-X slot 1, 64-bit/100-MHz
7	PCI-X slot 2, 64-bit/100-MHz
8	PCI-X slot 3, 64-bit/100-MHz
9	PCI-X slot 4, 64-bit/100-MHz
10	PCI Express x4 slot 5
11	PCI Express x4 slot 6
12	PCI Express x4 slot 7
13	PCI Express x4 slot 8
14	PCI Express x4 slot 9
15	PCI Express x4 slot 10
16	Power supply (primary)
17	Power supply blank
18	T-15 Torx screwdriver
19	UID button and LED
20	Keyboard connector
21	Mouse connector
22	Video connector
23	Serial connector

Rear panel LEDs and buttons



Item	Description	Status
1	UID LED	Blue = Activated Flashing blue = System remotely managed Off = Deactivated
2	NIC activity LED (Integrated NC371i)	Green or flashing green = Network activity Off = No network activity
3	NIC link LED (Integrated NC371i)	Green = Linked to network Off = Not linked to network
4	iLO 2 NIC activity LED	Green or flashing green = Network activity Off = No network activity
5	iLO 2 NIC link LED	Green = Linked to network Off = Not linked to network
6	Power supply LED (primary and redundant)	Refer to "Hot-plug power supply LEDs (on page 20)"
7	Power supply LED (primary and redundant)	Refer to "Hot-plug power supply LEDs (on page 20)"

System board components



Item	Description
1	PCI Express x4 slot 10
2	PCI Express x4 slot 9
3	PCI Express x4 slot 8
4	PCI Express x4 slot 7
5	PCI Express x4 slot 6
6	PCI Express x4 slot 5
7	PCI-X slot 4, 64-bit/100-MHz
8	PCI-X slot 3, 64-bit/100-MHz
9	PCI-X slot 2, 64-bit/100-MHz
10	PCI-X slot 1, 64-bit/100-MHz
11	Memory board slot 1
12	Memory board slot 2
13	Front video/USB connector
14	Memory board slot 3
15	Memory board slot 4
16	PPM slot 1
17	PPM slot 2
18	Systems Insight Display
19	System maintenance switch (SW2)
20	PPM slot 4
21	NMI switch
22	PPM slot 3
23	Processor socket 4
24	Fan board signal connector
25	Processor socket 3

Item	Description
26	Processor socket 2
27	Fan board signal connector
28	Fan board power connector
29	Processor socket 1
30	Power connector
31	Internal USB connector
32	Fan connector
33	Fan connector
34	Power supply signal connector

System maintenance switches

The system maintenance switch (SW1) is an eight-position switch that is reserved. The default position for all eight positions is Off.

The system maintenance switch (SW2) is an eight-position switch that is used for system configuration. The default position for all eight positions is Off.

Position	Description	Function
S1	iLO 2 security	Off = iLO 2 security is enabled On = iLO 2 security is disabled
S2	Configuration lock	Off = System configuration can be changed On = System configuration is locked
S3	Reserved	Reserved
S4	Reserved	Reserved
S5	Password protection override	Off = No function On = Clears power-on password and administrator password
S6	Invalid configuration	Off = Normal On = ROM treats system configuration as invalid
S7	Reserved	Reserved
S8	Reserved	Reserved

When the system maintenance switch position 6 is set to the On position, the system is prepared to erase all system configuration settings from both CMOS and NVRAM.

⚠ CAUTION: Clearing CMOS and/or NVRAM deletes configuration information. Be sure to properly configure the server or data loss could occur.

NMI switch

The NMI switch allows administrators to perform a memory dump before performing a hard reset. Crash dump analysis is an essential part of eliminating reliability problems, such as hangs or crashes in operating systems, device drivers, and applications. Many crashes freeze a system, requiring you to do a hard reset. Resetting the system erases any information that would support root cause analysis.

Systems running Microsoft® Windows® operating systems experience a blue screen trap when the operating system crashes. When this happens, Microsoft® recommends that system administrators perform an NMI event by pressing a dump switch. The NMI event enables a hung system to become responsive again.

System LEDs and internal health LED combinations

When the internal health LED on the front panel illuminates either flashing amber or flashing red, the server is experiencing a health event. Combinations of illuminated system LEDs and the internal health LED indicate system status.



NOTE: The system management driver must be installed in order for the internal health LED to provide pre-failure and warranty conditions.


The front panel health LEDs indicate only the current hardware status. In some situations, HP SIM may report server status differently than the health LEDs because the software tracks additional system attributes.

System LED and color	Internal health LED color	Status
Processor failure, socket X (amber)	Flashing red	One or more of the following conditions may exist: <ul style="list-style-type: none">• Processor in socket X has failed.• Processor X is not installed in the socket.• ROM detected a failed processor during POST.
Processor failure, socket X (amber)	Flashing amber	Processor in socket X is in a pre-failure condition.
PPM failure, slot X (amber)	Flashing red	<ul style="list-style-type: none">• PPM in slot X has failed.• PPM is not installed in slot X, but the corresponding processor is installed.
DIMM failure, slot X (amber)	Flashing red	<ul style="list-style-type: none">• DIMM in slot X has failed.• DIMM has experienced a multi-bit error.
DIMM failure, slot X (amber)	Flashing amber	<ul style="list-style-type: none">• DIMM in slot X has reached single-bit correctable error threshold.• DIMM in slot X is in a pre-failure condition.
DIMM bank error (all slots in one bank, amber)	Flashing red	The bank is not populated entirely or DIMMs do not all match within the bank.
DIMM failure (all slots, amber)	Flashing red	<ul style="list-style-type: none">• No valid or usable memory is installed in the system.• The banks are not populated in the correct order.
System temperature alert (amber)	Flashing red	System temperature has exceeded OS cautionary level or critical hardware level.
Fan (amber)	Flashing red	A required fan has failed.
Fan (amber)	Flashing amber	A redundant fan has failed.

System board LEDs and Systems Insight Display codes

In normal operations, all the LEDs are off unless one of the components fails. When a component fails, the LED illuminates amber.

The Systems Insight Display codes provide more specific information for troubleshooting the server. The codes are shown in the following table.




Code	Component	Status
01	Power supply cable(s)	System board to power supply cables: defective cables or cables not installed
04	Fan board cable(s)	Fan board power or signal cables are not installed.
05	Memory board	Base memory failure (memory board 1 is not installed or no valid memory configuration is present)
06	SAS backplane power cable	SAS backplane or cable is not present
08	System interlock	Main system interlock catch-all. Indicates an interlock problem not flagged by codes 01 to 07.
f1	Processor 1 unsupported	Processor 1 unsupported. Replace with a supported processor.
f2	Processor 2 unsupported	Processor 2 unsupported. Replace with a supported processor.
f3	Processor 3 unsupported	Processor 3 unsupported. Replace with a supported processor.
f4	Processor 4 unsupported	Processor 4 unsupported. Replace with a supported processor.
P1	Processor 1 is missing	Processor 1 is missing, and is required to boot. Install Processor 1. If processor 4 is installed and the system is booting up, the P1 code and Port 84/85 will be displayed for 1 second each to show the unit is booting.
U1	PPM 1 is missing	Processor 1 is installed without PPM 1. Install PPM 1.
U2	PPM 2 is missing	Processor 2 is installed without PPM 2. Install PPM 2.
U3	PPM 3 is missing	Processor 3 is installed without PPM 3. Install PPM 3.
U4	PPM 4 is missing	Processor 4 is installed without PPM 4. Install PPM 4.

Code	Component	Status
A0	Pre POST code	Standby mode
P5	Power supply	No power from the power supply
_5	Power backplane	No 5-V power from the power supply backplane board
33	Power backplane	No 3.3-V power from the power supply backplane board
15	1.5-V regulator	No 1.5-V power from the voltage regulator on the system board
Ut	Vtt regulator	No power from the Vtt regulator on the system
5U	PPM failure	No power from the PPM
nb	No boot	Indicates a no-boot situation


SAS and SATA device numbers

The server supports a combination of up to 18 SAS and SATA hard drives in the SAS/SATA hard drive cage. SAS/SATA devices are numbered 1 through 18.

HP recommends populating hard drive bays starting with the lowest SAS device number.



SAS and SATA hard drive LEDs



Item	Description
1	Fault/ID LED (amber/blue)
2	Online LED (green)

SAS and SATA hard drive LED combinations

Online/Activity LED (green)	Fault/UID LED (amber/blue)	Interpretation
On, off, or flashing	Alternating amber and blue	The drive has failed, or a predictive failure alert has been received for this drive; it also has been selected by a management application.
On, off, or flashing	Steadily blue	The drive is operating normally, and it has been selected by a management application.
On	Amber, flashing regularly (1 Hz)	A predictive failure alert has been received for this drive. Replace the drive as soon as possible.
On	Off	The drive is online, but it is not active currently.
Flashing regularly (1 Hz)	Amber, flashing regularly (1 Hz)	Do not remove the drive. Removing a drive may terminate the current operation and cause data loss. The drive is part of an array that is undergoing capacity expansion or stripe migration, but a predictive failure alert has been received for this drive. To minimize the risk of data loss, do not replace the drive until the expansion or migration is complete.
Flashing regularly (1 Hz)	Off	Do not remove the drive. Removing a drive may terminate the current operation and cause data loss. The drive is rebuilding, or it is part of an array that is undergoing capacity expansion or stripe migration.
Flashing irregularly	Amber, flashing regularly (1 Hz)	The drive is active, but a predictive failure alert has been received for this drive. Replace the drive as soon as possible.
Flashing irregularly	Off	The drive is active, and it is operating normally.

Online/Activity LED (green)	Fault/UID LED (amber/blue)	Interpretation
Off	Steadily amber	A critical fault condition has been identified for this drive, and the controller has placed it offline. Replace the drive as soon as possible.
Off	Amber, flashing regularly (1 Hz)	A predictive failure alert has been received for this drive. Replace the drive as soon as possible.
Off	Off	The drive is offline, a spare, or not configured as part of an array.

Memory board LEDs and components


Error indicators remain illuminated when the system is powered off so that the status of the LEDs can still be seen. This matches the behavior of all the other error indicators in the server.

Error indicators will only be cleared if:

- The locking switch is locked after the board is reinstalled
- The system has been rebooted
- The board is removed from the system

⚠ CAUTION: When the memory board locking switch is unlocked in a mode that does not support hot-add or hot-replace capabilities, audio alarms and visual alerts occur. Removing the memory board at this point causes server failure.

- To end the audio alarms and visual alerts, move the memory board locking switch back to the locked position. This action does not result in data corruption or server failure.
- If removal of a single memory board is required and it is the only memory board, power down the server and make the necessary memory changes.



Item	Description	Status
1	Release latch	—
2	Ejector lever	—

Item	Description	Status
3	Locking switch	—
4	Removable	Green = OK to remove the board Off = Do not remove if the system is on
5	DIMM 1 LED	Green = DIMM installed Amber = Failed or degraded DIMM Flashing amber = DIMM configuration error Off = No DIMM installed
6	DIMM 2 LED	Green = DIMM installed Amber = Failed or degraded DIMM Flashing amber = DIMM configuration error Off = No DIMM installed
7	DIMM 3 LED	Green = DIMM installed Amber = Failed or degraded DIMM Flashing amber = DIMM configuration error Off = No DIMM installed
8	DIMM 4 LED	Green = DIMM installed Amber = Failed or degraded DIMM Flashing amber = DIMM configuration error Off = No DIMM installed
9	DIMM 5 LED	Green = DIMM installed Amber = Failed or degraded DIMM Flashing amber = DIMM configuration error Off = No DIMM installed
10	DIMM 6 LED	Green = DIMM installed Amber = Failed or degraded DIMM Flashing amber = DIMM configuration error Off = No DIMM installed
11	Online spare LED	Green = Online spare mode Amber = Degraded online spare mode Flashing amber = Invalid AMP mode* Off = Not in Online Spare mode
12	Hot-plug mirrored LED	Green = Mirrored mode Amber = Degraded mirrored mode Flashing amber = Invalid AMP mode* Off = Not in Mirrored mode
13	Hot-plug RAID LED	Green = RAID mode Amber = Degraded RAID mode Flashing amber = Invalid AMP mode* Off = Not in RAID mode

Item	Description	Status
14	Board status LED	<p>Off = Power off - memory board locking switch not engaged or invalid memory configuration.</p> <p>Green = Normal operation</p> <p>Flashing green = Board is rebuilding</p> <p>Flashing amber = DIMM on this board encountered memory errors</p> <p>Flashing amber = one of the following conditions:</p> <ul style="list-style-type: none"> • Unlocking a memory board that should not be removed • Attempting to insert a memory board at runtime that fails

*The following applies to an invalid AMP error. This error occurs when the current memory configuration is not valid for the configured AMP mode:

- To keep the selected mode, modify the DIMM/board configuration. Refer to the memory overview section ("[Memory board LEDs and components](#)" on page 17).
- To change the selected mode, run RBSU and change the AMP mode. Refer to "HP ROM-Based Setup Utility (on page 80)" for more information.




NOTE: If the Online Spare, Mirrored, and RAID LEDs are off, the server is in Advanced ECC mode. Refer to "HP ROM-Based Setup Utility (on page 80)" for more information.

The following table illustrates the different LED combinations for a correctly configured memory board.


LED	Advanced ECC memory	Online spare memory	Hot-plug mirrored memory	Hot-plug RAID memory
Board status	Green	Green	Green	Green
DIMM 1 to 6, if populated	Green	Green	Green	Green
Online spare status	Off	Green	Off	Off
Mirrored status	Off	Off	Green	Off
RAID status	Off	Off	Off	Green
Board removable	Off	Off	Green	Green

DIMM slots



Item	Description
1	DIMM slot 1, PC2-3200R
2	DIMM slot 2, PC2-3200R
3	DIMM slot 3, PC2-3200R
4	DIMM slot 4, PC2-3200R
5	DIMM slot 5, PC2-3200R
6	DIMM slot 6, PC2-3200R

Hot-plug power supply LEDs




Item	Description
1	Power LED (primary power supply)

Item	Description
2	Failure LED (primary power supply)
3	Power LED (redundant power supply)
4	Failure LED (redundant power supply)


Power LED (green)	Failure LED (amber)	Status
Off	Off	No AC power to all power supply units
Off	On	No AC power to this power supply unit only or power supply failure (includes over voltage and over temperature)
Flashing	Off	AC present/Standby outputs on
On	Off	Power supply DC outputs On and OK
Off	Flashing	Power supply failure (current limit)

Hot-plug fans



Item	Description	Configuration
1	Fan 1	Redundant
2	Fan 2	Primary
3	Fan 3	Redundant
4	Fan 4	Primary
5	Fan 5	Redundant
6	Fan 6	Primary

Hot-plug fan LEDs



Status
Green = Operating normally
Amber = Failed
Off = No power

Operations

In this section

Power up the server	23
Power down the server.....	23
Extend the server from the rack	23
Unlock and remove the tower bezel.....	25
Remove the rack bezel.....	26
Remove the access panel	27
Install the access panel	27

Power up the server

To power up the server, press the Power On/Standby button.

Power down the server

 **WARNING:** To reduce the risk of personal injury, electric shock, or damage to the equipment, remove the power cord to remove power from the server. The front panel Power On/Standby button does not completely shut off system power. Portions of the power supply and some internal circuitry remain active until AC power is removed.

 **IMPORTANT:** If installing a hot-plug device, it is not necessary to power down the server.

1. Back up the server data.
2. Shut down the operating system as directed by the operating system documentation.
3. If the server is installed in a rack, press the UID LED button on the front panel. Blue LEDs illuminate on the front and rear panels of the server.
4. Press the Power On/Standby button to place the server in standby mode. When the server activates standby power mode, the system power LED changes to amber.
5. If the server is installed in a rack, locate the server by identifying the illuminated rear UID LED button.
6. Disconnect the power cords.

The system is now without power.

Extend the server from the rack

1. Release the two levers on the lower outside corners of the rack.


 **NOTE:** If the server is in a rack and in the shipping configuration, remove the two shipping screws directly behind the levers.

 **IMPORTANT:** If the server is installed in a telco rack, remove the server from the rack to access internal components.

2. Extend the server on the rack rails until the server rail-release latches engage.




NOTE: The release latches will lock into place when the rails are fully extended.



⚠ WARNING: To reduce the risk of personal injury or equipment damage, be sure that the rack is adequately stabilized before extending a component from the rack.

⚠ WARNING: To reduce the risk of personal injury, be careful when pressing the server rail-release latches and sliding the server into the rack. The sliding rails could pinch your fingers.


3. After performing the installation or maintenance procedure, slide the server back into the rack by pressing the server rail-release latches.




Unlock and remove the tower bezel

Tower servers have a bezel that must be unlocked and opened before accessing the hard drive cage, diskette drive, DVD drive, and the Power On/Standby button. In addition, the bezel is also removable when converting a tower server to a rack server.


1. Turn the key (provided with the server) counterclockwise to unlock the bezel.



2. Open the bezel.



3. Remove the tower bezel if necessary.




Remove the rack bezel

The rack bezel must remain installed during normal server operations. The rack bezel remains installed for all hardware options installations, except for the following situations:

- Removing or replacing a SAS hard drive cage
- Converting the server from a rack model to a tower model


To remove the rack bezel:

1. Extend or remove the server from the rack ("[Extend the server from the rack](#)" on page 23).
2. Remove the tape drive blank or the tape drive.



3. Using the Torx T-15 screwdriver, remove the three screws on each side of the rack bezel.
4. Push down on the latch connected to the media bay.

5. Pull the rack bezel away from the chassis.



Remove the access panel

- ⚠ WARNING:** To reduce the risk of personal injury from hot surfaces, allow the drives and the internal system components to cool before touching them.
- ⚠ CAUTION:** Do not operate the server for long periods with the access panel open or removed. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage.
 1. Power down the server if the standard cable management solution is installed ("[Power down the server](#)" on page 23).
- 📝 NOTE:** If the optional cable management arm is installed, you can extend the server and perform hot-plug installation or maintenance procedures without powering down the server.
 2. Extend or remove the server from the rack ("[Extend the server from the rack](#)" on page 23).
 3. Lift up on the hood latch handle and remove the access panel.

Install the access panel

1. Place the access panel on top of the server with the hood latch open. Allow the panel to extend past the rear of the server approximately 8 mm (0.2 in).
2. Engage the anchoring pin with the corresponding hole in the latch.
3. Push down on the hood latch. The access panel slides to a closed position.

Setup

In this section

Optional installation services	28
Rack planning resources	29
Optimum environment.....	29
Rack warnings and cautions	31
Identifying tower server shipping carton contents	32
Identifying rack server shipping carton contents	32
Installing hardware options	32
Setting up a tower server.....	33
Installing the server into the rack	34
Powering up and configuring the server	36
Installing the operating system	36
Registering the server.....	37

Optional installation services

Delivered by experienced, certified engineers, HP Care Pack services help you keep your servers up and running with support packages tailored specifically for HP ProLiant systems. HP Care Packs let you integrate both hardware and software support into a single package. A number of service level options are available to meet your needs.

HP Care Pack Services offer upgraded service levels to expand your standard product warranty with easy-to-buy, easy-to-use support packages that help you make the most of your server investments. Some of the Care Pack services are:

- Hardware support
 - 6-Hour Call-to-Repair
 - 4-Hour 24x7 Same Day
 - 4-Hour Same Business Day
- Software support
 - Microsoft®
 - Linux
 - HP ProLiant Essentials (HP SIM and RDP)
 - VMWare
- Integrated hardware and software support
 - Critical Service
 - Proactive 24
 - Support Plus
 - Support Plus 24
- Startup and implementation services for both hardware and software

For more information on Care Packs, refer to the HP website (http://www.hp.com/hps/carepack/servers/cp_proliant.html).

Rack planning resources

The rack resource kit ships with all HP branded or Compaq branded 9000, 10000, and H9 series racks. For more information on the content of each resource, refer to the rack resource kit documentation.

If you intend to deploy and configure multiple servers in a single rack, refer to the white paper on high-density deployment at the HP website (<http://www.hp.com/products/servers/platforms>).

Optimum environment

When installing the server, select a location that meets the environmental standards described in this section.

Space and airflow requirements

Tower server

In a tower configuration, leave at least a 7.6-cm (3-in) clearance space at the front and back of the server for proper ventilation.

Rack server

To allow for servicing and adequate airflow, observe the following space and airflow requirements when deciding where to install a rack:

- Leave a minimum clearance of 63.5 cm (25 in) in front of the rack.
- Leave a minimum clearance of 76.2 cm (30 in) behind the rack.
- Leave a minimum clearance of 121.9 cm (48 in) from the back of the rack to the back of another rack or row of racks.

HP servers draw in cool air through the front door and expel warm air through the rear door. Therefore, the front and rear rack doors must be adequately ventilated to allow ambient room air to enter the cabinet, and the rear door must be adequately ventilated to allow the warm air to escape from the cabinet.

△ CAUTION: To prevent improper cooling and damage to the equipment, do not block the ventilation openings.

When vertical space in the rack is not filled by a server or rack component, the gaps between the components cause changes in airflow through the rack and across the servers. Cover all gaps with blanking panels to maintain proper airflow.

△ CAUTION: Always use blanking panels to fill empty vertical spaces in the rack. This arrangement ensures proper airflow. Using a rack without blanking panels results in improper cooling that can lead to thermal damage.

The 9000 and 10000 Series Racks provide proper server cooling from flow-through perforations in the front and rear doors that provide 64 percent open area for ventilation.

△ CAUTION: When using a Compaq branded 7000 Series rack, you must install the high airflow rack door insert [P/N 327281-B21 (42U) or P/N 157847-B21 (22U)] to provide proper front-to-back airflow and cooling.

- ⚠ CAUTION:** If a third-party rack is used, observe the following additional requirements to ensure adequate airflow and to prevent damage to the equipment:
- Front and rear doors—If the 42U rack includes closing front and rear doors, you must allow 5,350 sq cm (830 sq in) of holes evenly distributed from top to bottom to permit adequate airflow (equivalent to the required 64 percent open area for ventilation).
 - Side—The clearance between the installed rack component and the side panels of the rack must be a minimum of 7 cm (2.75 in).

Temperature requirements

To ensure continued safe and reliable equipment operation, install or position the system in a well-ventilated, climate-controlled environment.

The maximum recommended ambient operating temperature (TMRA) for most server products is 35°C (95°F). The temperature in the room where the rack is located must not exceed 35°C (95°F).

- ⚠ CAUTION:** To reduce the risk of damage to the equipment when installing third-party options:
- Do not permit optional equipment to impede airflow around the server or to increase the internal rack temperature beyond the maximum allowable limits.
 - Do not exceed the manufacturer's TMRA.

Power requirements

Installation of this equipment must comply with local and regional electrical regulations governing the installation of information technology equipment by licensed electricians. This equipment is designed to operate in installations covered by NFPA 70, 1999 Edition (National Electric Code) and NFPA-75, 1992 (code for Protection of Electronic Computer/Data Processing Equipment). For electrical power ratings on options, refer to the product rating label or the user documentation supplied with that option.

- ⚠ WARNING:** To reduce the risk of personal injury, fire, or damage to the equipment, do not overload the AC supply branch circuit that provides power to the rack. Consult the electrical authority having jurisdiction over wiring and installation requirements of your facility.

- ⚠ CAUTION:** Protect the server from power fluctuations and temporary interruptions with a regulating uninterruptible power supply (UPS). This device protects the hardware from damage caused by power surges and voltage spikes and keeps the system in operation during a power failure.

When installing more than one server, you may need to use additional power distribution devices to safely provide power to all devices. Observe the following guidelines:

- Balance the server power load between available AC supply branch circuits.
- Do not allow the overall system AC current load to exceed 80 percent of the branch circuit AC current rating.
- Do not use common power outlet strips for this equipment.
- Provide a separate electrical circuit for the server.

Electrical grounding requirements

The server must be grounded properly for proper operation and safety. In the United States, you must install the equipment in accordance with NFPA 70, 1999 Edition (National Electric Code), Article 250, as well as any local and regional building codes. In Canada, you must install the equipment in accordance with Canadian Standards Association, CSA C22.1, Canadian Electrical Code. In all other countries, you must install the equipment in accordance with any regional or national electrical wiring codes, such as the International Electrotechnical Commission (IEC) Code 364, parts 1 through 7.

Furthermore, you must be sure that all power distribution devices used in the installation, such as branch wiring and receptacles, are listed or certified grounding-type devices.

Because of the high ground-leakage currents associated with multiple servers connected to the same power source, HP recommends the use of a PDU that is either permanently wired to the building's branch circuit or includes a nondetachable cord that is wired to an industrial-style plug. NEMA locking-style plugs or those complying with IEC 60309 are considered suitable for this purpose. Using common power outlet strips for the server is not recommended.

Rack warnings and cautions

- ⚠ WARNING:** To reduce the risk of personal injury or damage to the equipment, be sure that:
 - The leveling jacks are extended to the floor.
 - The full weight of the rack rests on the leveling jacks.
 - The stabilizing feet are attached to the rack if it is a single-rack installation.
 - The racks are coupled together in multiple-rack installations.
 - Only one component is extended at a time. A rack may become unstable if more than one component is extended for any reason.

- ⚠ WARNING:** To reduce the risk of personal injury or equipment damage when unloading a rack:
 - At least two people are needed to safely unload the rack from the pallet. An empty 42U rack can weigh as much as 115 kg (253 lb), can stand more than 2.1 m (7 ft) tall, and may become unstable when being moved on its casters.
 - Never stand in front of the rack when it is rolling down the ramp from the pallet. Always handle the rack from both sides.

- ⚠ WARNING:** When installing a server in a telco rack, be sure that the rack frame is adequately secured to the top and bottom of the building structure.

- ⚠ WARNING:** This server is very heavy. To reduce the risk of personal injury or damage to the equipment:
 - Observe local occupational health and safety requirements and guidelines for manual material handling.
 - Get help to lift and stabilize the product during installation or removal, especially when the product is not fastened to the rails. When the server weighs more than 22.5 kg (50 lb), at least two people must lift the server into the rack together. A third person may be required to help align the server if the server is installed higher than chest level.
 - Use caution when installing the server in or removing the server from the rack; it is unstable when not fastened to the rails.

- ⚠ WARNING:** To reduce the risk of personal injury from hot surfaces, allow the drives and the internal system components to cool before touching them.

- ⚠ WARNING:** To reduce the risk of personal injury, electric shock, or damage to the equipment, remove the power cord to remove power from the server. The front panel Power On/Standby button does not completely shut off system power. Portions of the power supply and some internal circuitry remain active until AC power is removed.

- ⚠ CAUTION:** Protect the server from power fluctuations and temporary interruptions with a regulating uninterruptible power supply (UPS). This device protects the hardware from damage caused by power surges and voltage spikes and keeps the system in operation during a power failure.

⚠ CAUTION: Do not operate the server for long periods with the access panel open or removed. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage.

Identifying tower server shipping carton contents

Unpack the server shipping carton and locate the materials and documentation necessary for installing the server.

The contents of the server shipping carton include:

- Server
- Power cord
- Keyboard
- Mouse
- Hardware documentation, Documentation CD, and software products

In addition to the supplied items, you may need:

- Hardware options
- Operating system or application software
- PDU

Identifying rack server shipping carton contents

Unpack the server shipping carton and locate the materials and documentation necessary for installing the server. All the rack mounting hardware necessary for installing the server into the rack is included with the rack or the server.

The contents of the server shipping carton include:

- Server
- Power cord
- Hardware documentation, Documentation CD, and software products
- Rack-mounting hardware

In addition to the supplied items, you may need:

- Hardware options
- Operating system or application software
- PDU
- Keyboard
- Mouse

Installing hardware options


Install any hardware options before initializing the server. For options installation information, refer to the option documentation. For server-specific information, refer to "Hardware options installation (on page 38)."

Setting up a tower server

Follow these steps to set up a tower model server. If you are going to install the server into a rack, refer to the rack installation section ("[Installing the server into the rack](#)" on page 34).

1. Connect peripheral devices to the server.


⚠ WARNING: To reduce the risk of electric shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into RJ-45 connectors.



Item	Description
1	NIC 1 connector
2	NIC 2 connector
3	USB connectors
4	iLO 2 connector
5	Parallel connector
6	PCI-X slot 1, 64-bit/100-MHz
7	PCI-X slot 2, 64-bit/100-MHz
8	PCI-X slot 3, 64-bit/100-MHz
9	PCI-X slot 4, 64-bit/100-MHz
10	PCI Express x4 slot 5
11	PCI Express x4 slot 6
12	PCI Express x4 slot 7
13	PCI Express x4 slot 8
14	PCI Express x4 slot 9
15	PCI Express x4 slot 10
16	Power supply (primary)
17	Power supply blank
18	T-15 Torx screwdriver
19	UID button and LED
20	Keyboard connector

Item	Description
21	Mouse connector
22	Video connector
23	Serial connector

2. Connect the power cord to the power supply.
3. Open the power cord retaining clip and thread the power cord through the retaining clip.
4. Snap the tab into place to secure the power cord.



5. Connect the power cord to the AC power source.



WARNING: To reduce the risk of electric shock or damage to the equipment:

- **Do not disable the power cord grounding plug. The grounding plug is an important safety feature.**
- **Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.**
- **Unplug the power cord from the power supply to disconnect power to the equipment.**
- **Do not route the power cord where it can be walked on or pinched by items placed against it. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server.**


Installing the server into the rack

To install the server into a rack with square, round, or threaded holes, refer to the instructions that ship with the rack hardware kit.

If you are installing the server into a telco rack, order the appropriate option kit at the RackSolutions.com website (<http://www.racksolutions.com/hp>). Follow the server-specific instructions on the website to install the rack brackets.

1. Connect peripheral devices to the server.


⚠ WARNING: To reduce the risk of electric shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into RJ-45 connectors.



Item	Description
1	NIC 1 connector
2	NIC 2 connector
3	USB connectors
4	iLO 2 connector
5	Parallel connector
6	PCI-X slot 1, 64-bit/100-MHz
7	PCI-X slot 2, 64-bit/100-MHz
8	PCI-X slot 3, 64-bit/100-MHz
9	PCI-X slot 4, 64-bit/100-MHz
10	PCI Express x4 slot 5
11	PCI Express x4 slot 6
12	PCI Express x4 slot 7
13	PCI Express x4 slot 8
14	PCI Express x4 slot 9
15	PCI Express x4 slot 10
16	Power supply (primary)
17	Power supply blank
18	T-15 Torx screwdriver
19	UID button and LED
20	Keyboard connector
21	Mouse connector
22	Video connector
23	Serial connector

2. Connect the power cord to the power supply.
3. Open the power cord retaining clip and thread the power cord through the retaining clip.

4. Snap the tab into place to secure the power cord.



5. Connect the power cord to the AC power source.



WARNING: To reduce the risk of electric shock or damage to the equipment:

- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
- Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.
- Unplug the power cord from the power supply to disconnect power to the equipment.
- Do not route the power cord where it can be walked on or pinched by items placed against it. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server.

Powering up and configuring the server

To power up the server, press the Power On/Standby button.

While the server boots, RBSU is automatically configured to prepare the server for operating system installation.

To manually configure the utilities, press the **F9** key when prompted during the boot process to change the server settings using RBSU. The system is set up by default for the English language.



NOTE: If an array controller has been added or is embedded in the system, the ORCA utility provides a default RAID configuration based on the size and number of hard drives installed.

For more information on the automatic configuration, refer to the *HP ROM-Based Setup Utility User Guide* located on the Documentation CD.

Installing the operating system

To operate properly, the server must have a supported operating system. For the latest information on supported operating systems, refer to the HP website (<http://www.hp.com/go/supportos>).

Two methods are available to install an operating system on the server:

- SmartStart assisted installation—Insert the SmartStart CD into the CD-ROM drive and reboot the server.
- Manual installation—Insert the operating system CD into the CD-ROM drive and reboot the server. This process may require you to obtain additional drivers from the HP website (<http://www.hp.com/support>).

Follow the on-screen instructions to begin the installation process.

For information on using these installation paths, refer to the SmartStart installation poster in the HP ProLiant Essentials Foundation Pack, included with the server.

Registering the server

To register the server, refer to the HP Registration website (<http://register.hp.com>).

Hardware options installation

In this section

Processor option.....	38
Memory options.....	43
Hot-plug SAS and SATA hard drive option.....	54
Drive options.....	57
Redundant hot-plug power supply option.....	62
Redundant hot-plug fans.....	63
Expansion board options.....	65
Tower-to-rack conversion.....	67
Rack-to-tower conversion.....	71

Processor option

The server supports up to four processors. With two or more processors installed, the server supports boot functions through the processor installed in processor socket 1.

Server PPMs provide the proper power to each processor. Each PPM must be installed in the slot adjacent to its processor.

 **CAUTION:** To prevent thermal instability and damage to the server, do not separate the processor from the heatsink. The processor, heatsink, and retaining clip make up a single assembly.

 **CAUTION:** To prevent possible server malfunction, do not mix processors of different speeds or cache sizes. Refer to the label on the processor heatsink for a description of the processor.

 **IMPORTANT:** Populate the processors in the following order: 1, 2, 4, 3.

 **IMPORTANT:** If upgrading processor speed or adding additional processors, update the system ROM before installing the processor.

 **IMPORTANT:** Processor socket 1 and PPM slot 1 must be populated at all times or the server does not function.


 **IMPORTANT:** Always install a PPM when you install a processor. The system fails to boot if the PPM is missing.

 **IMPORTANT:** To ensure proper cooling, be sure the processor baffle is installed at all times.


To install a processor:

1. Power down the server (on page [23](#)).
2. Do one of the following:
 - Unlock and remove the bezel ("[Unlock and remove the tower bezel](#)" on page [25](#)).
 - Extend the server from the rack (on page [23](#)).
3. Remove the access panel (on page [27](#)).

4. Remove the processor air baffle.




5. Unlock the processor retaining bracket.




6. Open the processor retaining bracket.
7. Open the processor locking lever.

CAUTION: Failure to completely open the processor locking lever prevents the processor from seating during installation, leading to hardware damage.



8. Align the processor assembly with the socket.

IMPORTANT: Determine the correct processor orientation by observing the guide pins on the base of the processor retaining bracket and the three corresponding guide slots on the processor assembly.




9. Install the processor assembly and close the processor locking lever.


CAUTION: To prevent possible server malfunction or damage to the equipment, be sure to completely close the processor locking lever.




NOTE: Your heatsink may appear different than shown.



10. Close and lock the processor retaining bracket.




11. Release and remove the PPM hold-down.



12. Install the PPM.

 **IMPORTANT:** Always install a PPM when you install a processor. The system fails to boot if the corresponding PPM is missing.



 **NOTE:** The appearance of compatible PPMs may vary.

13. Install the PPM retaining bracket.
14. Install the processor air baffle.
15. Install the access panel (on page 27).
16. Do one of the following:
 - Install and lock the bezel.
 - Slide the server back into the rack.

Memory options

This server supports up to four memory boards. Each memory board contains six DIMM slots for a total of 24 DIMM slots in the server. Memory can be expanded by installing PC2-3200R Registered DDR2 DRAM DIMMs.

The server supports a host of AMP options to optimize server availability:

- Advanced ECC (hot-add enabled) ("[Advanced ECC Memory](#)" on page 44)
- Advanced ECC (hot-add disabled) ("[Advanced ECC Memory](#)" on page 44)
- Online spare memory (on page 45)
- Hot-plug mirrored memory (dual- and quad-board) ("[Hot-plug mirrored memory](#)" on page 46)
- Hot-plug RAID memory (on page 47)

Hot-plug operations can be hot-add or hot-replace. Hot-add makes additional memory resources available to the OS. Hot-replace allows failed or degraded DIMMs to be replaced while the server is running.

The maximum supported memory per memory board is 16 GB using four 4-GB dual-rank DIMMs. Although six DIMM slots exist per board, the system architecture allows a maximum of only four dual-rank DIMMs per memory board to optimize performance.

For an overview of single- and dual-rank DIMMs, refer to "[Single- and Dual-Rank DIMMs](#) (on page 44)."

For DIMM slot locations and bank assignments, refer to "[DIMM Slots](#) (on page 20)."

General memory configuration requirements

The following configuration requirements apply regardless of the AMP mode.

- DIMMs must be installed in pairs.
- DIMM pairs in a memory bank must contain DIMMs with the same part number.
- Always populate the memory boards in sequential order: Board 1, Board 2, Board 3, and Board 4. Any deviation from this requirement results in the server booting in Advanced ECC mode and Advanced ECC guidelines apply.
- Always populate the DIMMs in sequential order per bank: Bank A, Bank B, and Bank C.
- Dual-rank DIMMs ("[Single- and Dual-rank DIMMs](#)" on page 44) must be populated before single-rank DIMMs (see table).
- If dual-rank DIMMs are installed in Bank A and Bank B, no additional DIMMs may be installed in Bank C.
- The following table lists all seven valid combinations of single- and dual-rank DIMM configurations for a memory board. "Single" indicates a bank of single-rank DIMMs. "Dual" indicates a bank of dual-rank DIMMs.



NOTE: A bank contains two DIMMs.

Configuration	Bank A	Bank B	Bank C
1	Single		
2	Single	Single	
3	Single	Single	Single
4	Dual		
5	Dual	Single	
6	Dual	Single	Single
7	Dual	Dual	

- The system can be configured for any AMP mode in RBSU. RBSU displays a warning message if the selected AMP mode is not supported by the current configuration. However, if the DIMM configuration at POST does not meet the requirements for the AMP mode selected in RBSU, the server defaults to Advanced ECC. The system indicates this by displaying a message during POST and the status LED for the configured AMP mode flashes amber.
- Unpopulated memory boards (those without any installed DIMMs) can be installed in the server for storing extra memory boards.
- If the server contains more than 4 GB of memory, consult the OS documentation about accessing the full amount of installed memory.

Single- and Dual-rank DIMMs

PC2-3200 DIMMs can either be single- or dual-rank. While it is not normally important for you to differentiate between these two types of DIMMs, certain DIMM configuration requirements are based on these classifications.

Certain configuration requirements exist with single- and dual-rank DIMMs that allow the architecture to optimize performance. A dual-rank DIMM is similar to having two separate DIMMs on the same module. Although only a single DIMM module, a dual-rank DIMM acts as if it were two separate DIMMs. The primary reason for the existence of dual-rank DIMMs is to provide the largest capacity DIMM given the current DIMM technology. If the maximum DIMM technology allows for creating 2-GB single-rank DIMMs, a dual-rank DIMM using the same technology would be 4-GB.

Understanding the existence of single- and dual-rank DIMMs is all that is necessary for understanding the memory population guidelines of this server.

Advanced ECC Memory

Advanced ECC Memory is the default memory protection mode for this server. In Advanced ECC, the server is protected against correctable memory errors. The server provides notification if the level of correctable errors exceeds a pre-defined threshold rate. The server does not fail because of correctable memory errors. Advanced ECC provides additional protection over Standard ECC in that it is possible to correct certain memory errors that would otherwise be uncorrectable and result in a server failure. Whereas Standard ECC can correct single-bit memory errors, Advanced ECC can correct single-bit memory errors and multi-bit memory errors if all failed bits are on the same DRAM device on the DIMM.

The following guidelines apply to Advanced ECC Memory:

- All general memory requirements apply ("[Memory board LEDs and components](#)" on page 17).
- Advanced ECC mode is supported with 1, 2, 3, or 4 memory boards.
- Hot-add is always enabled for Advanced ECC.
- Board insertions do not convert the AMP mode while the server is running. A server cannot be converted from Advanced ECC to Online Spare Memory, mirrored memory, or Hot-Plug RAID memory by inserting a board while the server is running. Board insertions in Advanced ECC are solely for making additional memory resources available to the OS.
- Advanced ECC is the only mode in which hot-add operations are supported. This is the only mode in which the amount of memory available to the OS can be increased without a reboot.
- Hot-add is performed by adding a memory board while the server is running, and the additional memory is made available to the OS without a reboot. The following rules apply to hot-add operations:
 - Boards must be inserted sequentially.
 - Multiple hot-add board insertions can be performed on the same server. For example, if a server has three empty memory board slots, three hot-add board insertions can be performed.

- If multiple hot-add operations are performed, allow one board insertion operation to complete (as indicated by the memory board LEDs and OS logs) before inserting another memory board.
- If a memory board (which contains DIMMs) is unlocked while in Advanced ECC mode, audio alarms and visual alerts occur.

⚠ CAUTION: When the memory board locking switch is unlocked in a mode that does not support hot-add or hot-replace capabilities, audio alarms and visual alerts occur. Removing the memory board at this point causes server failure.

To end the audio alarms and visual alerts, move the memory board locking switch back to the locked position. This action does not result in data corruption or server failure.

If removal of a single memory board is required and it is the only memory board, power down the server and make the necessary memory changes.

Online spare memory

Online Spare Memory provides a higher level of memory protection than Advanced ECC. With Online Spare Memory, the probability of a server failing because of uncorrectable memory errors is reduced.

In this mode, memory that is receiving a high rate of correctable memory errors is automatically disengaged and a replacement set of memory is used in its place. Since DIMMs that are receiving a high rate of correctable memory errors have an increased probability of receiving an uncorrectable memory error (which results in a server failure), the server experiences higher availability. The degraded memory can be replaced during scheduled downtime and poses no additional risk to the server.

Online Spare Memory is supported with one to four memory boards installed. On this server, each installed memory board is protected by its own spare memory. No OS support is required.

The following guidelines apply to Online Spare Memory:

- All general memory requirements apply ("[Memory board LEDs and components](#)" on page 17).
- Online Spare Memory is supported with 1, 2, 3, or 4 memory boards.
- Each board must have a valid Online Spare configuration. No dependencies exist for the configuration between different memory boards.
- Each memory board includes its own Online Spare Bank. All boards operate independently in Online Spare mode. Each board can failover to its Online Spare Bank independent of the other memory boards. Some boards can be in Online Spare degraded mode while others are still in operational Online Spare mode.
- The minimum valid Online Spare configuration for a memory board requires at least one bank of dual-rank DIMMs or two banks of single-rank DIMMs ("[Single- and Dual-rank DIMMs](#)" on page 44). If the server does not meet these requirements, an error message is displayed during POST and the server defaults to Advanced ECC and Advanced ECC guidelines apply.
- The server automatically configures the optimal Online Spare solution.
- Online Spare Memory does not support any hot-plug operations.

HP recommends the following configurations. These configurations result in optimal use of memory. Other configurations are valid, but do not result in the maximum amount of installed memory being available to the OS.

- If only single-rank DIMMs are used on a memory board, all DIMMs should be of the same size on that memory board.
- If only dual-rank DIMMs are used on a memory board, all DIMMs should be of the same size on that memory board.
- If a mixture of single- and dual-rank DIMMs are used on a memory board, the dual-rank DIMMs should be two times the size of any single-rank DIMM.

After installing DIMMs, use RBSU to configure the system for online spare memory support.

Hot-plug mirrored memory

Hot-Plug mirrored memory (mirrored memory) provides a higher level of memory protection than either Advanced ECC or Online Spare Memory. With mirrored memory, the server is protected against uncorrectable memory errors that would otherwise result in server failure. Mirrored memory allows the server to keep two copies of all memory data on separate memory boards.

If an uncorrectable error is encountered, the proper data is retrieved from the memory board that does not contain the error. In addition, mirrored memory allows failed or degraded DIMMs to be replaced while the server is running without requiring server downtime. The memory board with the failed DIMM(s) can be removed, failed DIMMs replaced, and the board re-inserted into the server without any interruption to the OS.

Mirrored memory is supported with either two or four memory boards installed. No OS support is required.

Mirrored memory has two configurations: dual-board and quad-board. Single-board mirrored memory is not supported. For either mode, choose "Mirrored" in RBSU.

The following guidelines apply to mirrored memory:

- All general memory requirements apply ("[Memory board LEDs and components](#)" on page 17).
- Mirrored memory is supported with two or four memory boards.
- Memory boards 1 and 2 are populated for dual-board mirrored memory. Boards 1, 2, 3, and 4 are populated for quad-board mirrored memory. Any deviation from these guidelines results in the server booting in Advanced ECC mode and Advanced ECC guidelines apply.
- Memory boards 1 and 2 form a mirrored pair for dual-board mirrored memory. For quad-board mirrored memory, memory boards 3 and 4 form an additional mirrored pair.
- Memory boards within a mirrored pair must have the same amount of total memory. However, each board of the mirrored pair may have different DIMM configurations as long as they have equal total size. For example, memory boards 1 and 2 could each contain 2 GB of physical memory per board with board 1 containing two 1-GB DIMMs and board 2 containing four 512-MB DIMMs.
- The amount of memory between mirrored pairs can be different in quad-board mirrored memory mode. For example, memory pair 1 (boards 1 and 2) can contain 2 GB each while memory pair 2 (boards 3 and 4) contain 4 GB each.
- In quad-board mirrored memory, the two pairs of memory boards operate independently. One of the pairs of memory boards can be degraded while the other pair of memory boards can still be fully mirrored.
- Hot-add operations are not permitted. Board removals and insertions in mirrored memory are solely for the purpose of hot-replace operations.
- For hot-replace to function properly, the memory board must be re-inserted into the location from which it was removed. If the board is placed into the incorrect slot (for example, if board 2 is removed in dual-board mirroring mode and re-inserted into memory slots 3 or 4), a configuration error occurs. Attempting to insert a board into the improper position results in audio alarms and visual alerts.
- Replace only one board at a time. That is, if memory boards 2 and 4 both contain memory errors, remove board 2, replace the failed DIMMs, and replace board 2 before proceeding to board 4.
- If a board is inserted into a valid memory slot but with an invalid DIMM configuration (including too much or too little memory), a DIMM configuration error occurs and a visual alert occurs. Refer to Memory Board LEDs ("[Memory board LEDs and components](#)" on page 17).
- If you remove a board while the server is running and do not replace the board, the next reboot results in the system defaulting to Advanced ECC and Advanced ECC guidelines apply.

Hot-plug RAID memory

Hot-plug RAID memory (RAID memory) provides a similar level of memory protection as mirrored memory but obtains this protection using less total memory. For example, in a RAID memory configuration, 25% of the installed memory is not available to the OS. In a mirrored memory configuration, however, 50% of the installed memory is not available to the OS. RAID memory protects the server against uncorrectable memory errors that would otherwise result in a server failure.

Although mirrored memory keeps two copies of all memory data, RAID memory keeps only one copy of all memory data and additional parity information. If an uncorrectable memory error is encountered, the server can create the proper data using the parity information and the information from the other memory boards that contain no failures.

As with mirrored memory, RAID memory allows failed or degraded DIMMs to be replaced while the server is running without requiring server downtime. The memory board with the failed DIMM(s) can be removed, failed DIMMs replaced, and the board re-inserted into the server without any interruption to the OS.

RAID memory is only supported if all four memory boards are installed. No OS support is required.

The following guidelines apply to Hot-Plug RAID memory:

- All general memory requirements apply ("[Memory board LEDs and components](#)" on page 17).
- RAID memory is only supported with four memory boards.
- All four memory boards must have the same amount of total memory. However, each board may have different DIMM configurations as long as they have equal total size. Any deviation from this rule results in the server booting in Advanced ECC mode and Advanced ECC guidelines apply.
- No hot-add operations are supported in RAID memory, only hot-replace.
- If you remove a board while the server is running and do not replace it, the next reboot results in the system reverting to Advanced ECC and Advanced ECC guidelines apply.

Memory boards and DIMMs



NOTE: The ProLiant ML570 G3/G4 memory board operates at different front-side bus speeds:

- In HP ProLiant ML570 Generation 4 Servers, the G3/G4 memory board operates at 667 MHz or 800 MHz, depending on the front-side bus speed of the installed processor.
- In HP ProLiant ML570 Generation 3 Servers, the G3/G4 memory board operates at 667 MHz with no performance gain over ProLiant ML570 G3 memory boards.



IMPORTANT: Installing a ProLiant ML570 G3 memory board in an HP ProLiant ML570 G4 Server forces the front-side bus speed to 667 MHz. If the installed processor has an 800-MHz front-side bus, a message displays at POST.



IMPORTANT: The HP ProLiant ML570 G4 Server does not support hot-add of ProLiant ML570 G3 memory boards. Inserting the memory board generates an audio alert and the memory board LEDs flash. The memory board does not power up. The board can be removed without powering down the server.

Memory board and DIMM installation, removal, and replacement procedures can be either hot-plug or non-hot-plug, depending on how the server is configured. Hot-plug operations can be hot-add or hot-replace. Hot-add makes additional memory resources available to the OS. Hot-replace allows failed or degraded DIMMs to be replaced while the server is running. Hot-add is only supported with Microsoft® Windows® 2003 or later. Hot-replace has no OS requirements.

The following table illustrates AMP modes that support hot-plug features.

Advanced Memory Protection Mode	Hot-Replace Supported	Hot-Add Supported
Advanced ECC		X
Online Spare Memory		
Hot-Plug Mirrored Memory	X	
Hot-Plug RAID Memory	X	

When the server is configured for mirrored or RAID memory, you can perform a hot-replacement procedure in the following manner without powering down the server or experiencing server downtime:

1. Remove a memory board.
2. Replace failed or degraded DIMM(s).
3. Reinstall the memory board in the slot from which it was removed.

The replacement procedures in this section apply to both hot-plug and non-hot-plug memory procedures, except as noted.

 **IMPORTANT:** Be sure to power down the server when performing board removal procedures in a server that is not configured for Mirrored or Hot-Plug RAID Memory.

Observe the following warnings when performing a hot-plug replacement procedure.

 **WARNING:** Always comply with all electrostatic and thermal guidelines to prevent bodily injury and ensure a properly functioning system when performing hot-plug operations.

 **WARNING:** To prevent personal injury from hazardous energy:

- Remove watches, rings, or other metal objects.
- Use tools with insulated handles.
- Do not place tools or metal parts on top of batteries.

Removing and installing a memory board (hot-plug)

 **NOTE:** The ProLiant ML570 G3/G4 memory board operates at different front-side bus speeds:

- In HP ProLiant ML570 Generation 4 Servers, the G3/G4 memory board operates at 667 MHz or 800 MHz, depending on the front-side bus speed of the installed processor.
- In HP ProLiant ML570 Generation 3 Servers, the G3/G4 memory board operates at 667 MHz with no performance gain over ProLiant ML570 G3 memory boards.

 **IMPORTANT:** Installing a ProLiant ML570 G3 memory board in an HP ProLiant ML570 G4 Server forces the front-side bus speed to 667 MHz. If the installed processor has an 800-MHz front-side bus, a message displays at POST.

 **IMPORTANT:** The HP ProLiant ML570 G4 Server does not support hot-add of ProLiant ML570 G3 memory boards. Inserting the memory board generates an audio alert and the memory board LEDs flash. The memory board does not power up. The board can be removed without powering down the server.


1. Do one of the following:
 - Unlock and remove the bezel ("[Unlock and remove the tower bezel](#)" on page 25).
 - Extend the server from the rack (on page 23).
2. Remove the access panel (on page 27).
3. Determine which memory board is to be removed by locating the memory board that displays an amber Board Status LED. The Board Removal LED must be green. Take note of the failed DIMM, if applicable.

4. Unlock the memory board locking switch.

CAUTION: Do not attempt to unlock the memory board in an operational server when the board removal LED is not green. This generates an audio alarm and causes the memory board LEDs to flash amber. Proceeding to remove the memory board causes server failure.


CAUTION: To prevent server failure during a hot-plug removal procedure, do not remove the memory board from the server until the board status LED stops flashing.

5. Unlock and open the memory board ejector lever.
6. Remove the memory board and place it on a flat surface.




NOTE: While the memory board with the failed or degraded DIMM is being removed, the system continues to read and write from the operational memory board(s).


7. Do one of the following:
 - Remove a DIMM.



- Install a DIMM.



8. Align the memory board with the memory slot and memory board guide clips.
9. Install the memory board and close the ejector lever.
10. Move the locking switch to the locked position.



NOTE: In hot-plug procedures, all LEDs now turn off except the board status LED, which flashes green while the board is rebuilding. This process may take several minutes.

11. Observe the memory board LEDs to be sure that the memory is functioning properly ("[Memory board LEDs and components](#)" on page 17). The LED states are valid when the memory board has finished rebuilding.
12. Install the access panel (on page 27).
13. Do one of the following:
 - Install and lock the bezel.
 - Slide the server back into the rack.

Removing and installing a memory board (non-hot-plug)



NOTE: The ProLiant ML570 G3/G4 memory board operates at different front-side bus speeds:

- In HP ProLiant ML570 Generation 4 Servers, the G3/G4 memory board operates at 667 MHz or 800 MHz, depending on the front-side bus speed of the installed processor.
- In HP ProLiant ML570 Generation 3 Servers, the G3/G4 memory board operates at 667 MHz with no performance gain over ProLiant ML570 G3 memory boards.




IMPORTANT: Installing a ProLiant ML570 G3 memory board in an HP ProLiant ML570 G4 Server forces the front-side bus speed to 667 MHz. If the installed processor has an 800-MHz front-side bus, a message displays at POST.




IMPORTANT: The HP ProLiant ML570 G4 Server does not support hot-add of ProLiant ML570 G3 memory boards. Inserting the memory board generates an audio alert and the memory board LEDs flash. The memory board does not power up. The board can be removed without powering down the server.

1. Do one of the following:
 - Unlock and remove the bezel ("[Unlock and remove the tower bezel](#)" on page [25](#)).
 - Extend the server from the rack (on page [23](#)).
2. Remove the access panel (on page [27](#)).
3. Determine which memory board is to be removed by locating the memory board that displays an amber board status LED. Take note of the failed DIMM, if applicable.
4. Power down the server (on page [23](#)).
5. Unlock the memory board locking switch.
6. Unlock and open the memory board ejector lever.
7. Remove the memory board and place it on a flat surface.




8. Do one of the following:

- Remove a DIMM.




- Install a DIMM.



9. Align the memory board with the memory slot and the memory board guide clips.
10. Install the memory board into the server and close the ejector lever.

11. Move the locking switch to the locked position.



12. Configure the memory ("Configuring the memory" on page 53).
13. Install the access panel (on page 27).
14. Do one of the following:
 - Install and lock the bezel.
 - Slide the server back into the rack.

Configuring the memory

Configuring the memory system of the server requires configuring both hardware and software.

To configure the memory:

1. Install the correct amount of memory for the desired AMP mode. For a list of AMP options, refer to "Memory Options (on page 43, "Single- and Dual-rank DIMMs" on page 44)." For more information, refer to "General Memory Configuration Requirements (on page 43)."
2. Test the DIMMs for all AMP modes, except Advanced ECC, before configuring the AMP mode in RBSU. The two testing methods are:
 - POST memory test (on page 53)
 - ROM-Based Diagnostics test ("ROM-based diagnostics" on page 54)



NOTE: If the total amount of memory has changed, the POST Memory Test will run automatically. Additional memory testing is not necessary.

3. Select the AMP mode ("Selecting the AMP mode" on page 54).

POST memory test

1. Power on the server ("Power up the server" on page 23).
2. Press the **F9** key, when prompted, to enter RBSU.
3. Select **Advanced Options**.
4. Change POST Speed Up to **Disable**.
5. Press any key to return to the RBSU main menu.
6. Press the **F10** key, when prompted, to exit RBSU. The server reboots and tests all memory in the system.

7. Once the memory has been tested, re-enable POST Speed Up for faster system boot, if desired.

ROM-based diagnostics

1. Power on the server ("[Power up the server](#)" on page 23).
2. Press the **F10** key, when prompted, to enter the System Maintenance menu.
3. Select **Diagnostics**.
4. Run the **Memory Diagnostics**.
5. Once the memory has been tested, exit the utility and reboot.
6. Select the AMP mode ("[Selecting the AMP mode](#)" on page 54).

Selecting the AMP mode

1. Upon reboot, press the **F9** key, when prompted, to enter RBSU.
2. Select **System Options**.
3. Select **Advanced Memory Protection**.
4. Select the desired memory mode.
 - Advanced ECC (hot-add enabled)
 - Advanced ECC (hot-add disabled)
 - Online Spare Memory with Advanced ECC
 - Hot-Plug Mirrored Memory with Advanced ECC
 - Hot-Plug RAID Memory with Advanced ECC
5. Press the **Escape** key twice to go back to the main RBSU menu.
6. Press the **F10** key, when prompted, to exit RBSU. The server reboots and tests all memory in the system.



IMPORTANT: To reconfigure the memory mode after initial setup, you must reboot the system, enter RBSU, and select the desired AMP mode.


Hot-plug SAS and SATA hard drive option

When adding hard drives to the server, observe the following general guidelines:


- The system automatically sets all drive numbers.
- If only one hard drive is used, install it in the bay with the lowest drive number ("[SAS and SATA device numbers](#)" on page 15).
- Hard drives must be SFF types.
- Drives should be the same capacity to provide the greatest storage space efficiency when drives are grouped together into the same drive array.

Installing a hot-plug SAS or SATA hard drive


- 1. Remove the SAS or SATA hard drive blank.



- 2. Prepare the hard drive.



3. Install the hard drive.




4. Determine the status of the hard drive from the hot-plug SAS hard drive LED combinations.

Removing a hot-plug SAS hard drive

CAUTION: To prevent improper cooling and thermal damage, do not operate the server unless all bays are populated with either a component or a blank.

1. Determine the status of the hard drive from the hot-plug SAS hard drive LED combinations.
2. Back up all server data on the hard drive.
3. Remove the hard drive.



Drive options

Optical drives


The standard configuration for this server is one DVD drive (in the right drive bay) and one drive blank (in the left drive bay). An optional DVD-ROM or diskette drive may be installed in the left drive bay.

A diskette drive cannot be installed in the right drive bay.


△ CAUTION: Always populate each media bay with either a device or a blank. Proper airflow can only be maintained when the bays are populated. Unpopulated drive bays can lead to improper cooling and thermal damage.

To install an optional drive:

1. Power down the server (on page 23).
2. Use a T-15 Torx screwdriver to eject the drive blank, and pull the drive blank out of the chassis.



3. Install the optional drive into the server.



Removable media devices


A half-height SCSI tape drive or a half-height USB tape drive may be installed in the removable media bay. A half-height CD-ROM, DVD-ROM, CD-R, or DVD-R drive is not supported.

Removing the tape drive blank

1. Unlock and open the tower bezel ("[Unlock and remove the tower bezel](#)" on page 25) (tower servers only).

CAUTION: Always populate each media bay with either a device or a blank. Proper airflow can only be maintained when the bays are populated. Unpopulated drive bays can lead to improper cooling and thermal damage.

2. Pull the tape drive blank out of the chassis.



3. Store the blank for later use.


Installing a tape drive

1. Power down the server (on page 23).
2. Do one of the following:
 - Unlock and remove the bezel ("[Unlock and remove the tower bezel](#)" on page 25).
 - Extend the server from the rack (on page 23).
3. Remove the access panel (on page 27).
4. Remove the processor air baffle ("[Processor option](#)" on page 38).
5. Remove all expansion boards ("[Expansion board options](#)" on page 65).




NOTE: If you are installing a USB tape drive, you do not have to remove the system board. You can omit steps 8 through 11.

6. Remove the center wall.




7. Remove all memory boards ("[Removing and installing a memory board \(hot-plug\)](#)" on page 48, "[Removing and installing a memory board \(non-hot-plug\)](#)" on page 51).
8. Remove the memory cage.



9. Disconnect all required cables from the system board.

10. Remove the system board.



11. Remove the tape drive blank ("[Unlock and remove the tower bezel](#)" on page 25).



NOTE: Most devices have holes designed to correspond with the wire retainers that are installed in the upper slot of the guide clips. For devices that have holes designed to correspond to the lower slot of the guide clip, the wire retainer must be removed and reinstalled in the lower slot of the clip.

12. If the device has holes that correspond to the lower slot, adjust the wire retainers on both sides of the device:

- a.** Push the wire retainer from behind to remove the wire retainer from the upper slot.
- b.** Install the wire retainer in the lower slot. Be sure the wire retainer is snapped into place before installing on a media device.


13. Attach the plastic guides to the tape drive:



NOTE: The plastic clips and the wire retainers are located inside the tape drive blank. Each plastic clip is labeled with an "L" for left or an "R" for right.

- a.** Align the left plastic clip to the drive.
- b.** Insert the wire retainer into the hole closest to the front of the drive on the left side.
- c.** Slide your finger along the wire retainer until the other side of the wire retainer snaps into place in the back of the tape drive.

- d. Repeat for the right plastic clip.




14. Connect the power cable from the server to the tape drive.

15. Connect one end of the data cable to the tape drive and thread the other end into the server through the tape drive bay.

 **NOTE:** The appropriate cables should ship in the individual option kits or with the device being installed.

 **IMPORTANT:** Route the USB cable under the mid fan cage.

16. Slide the tape drive into the bay until it is seated securely.



17. Connect the power and data cables ("[System board components](#)" on page 11).

18. Install the system board.

19. Install the memory cage.

20. Install the memory boards ("[Removing and installing a memory board \(hot-plug\)](#)" on page 48, "[Removing and installing a memory board \(non-hot-plug\)](#)" on page 51).

21. Install any expansion boards ("[Installing expansion boards](#)" on page 66).

22. Install the center wall.

23. Install the processor air baffle ("Processor option" on page 38).
24. Install the access panel. ("Install the access panel" on page 27)
25. Do one of the following:
 - Install and lock the bezel.
 - Slide the server back into the rack.
26. Power up the server (on page 23).


Redundant hot-plug power supply option

The server supports a second hot-plug power supply to provide redundant power to the system in the event of a failure in the primary power supply. You can install or replace a second hot-plug power supply without powering down the server.


CAUTION: If only one power supply is installed, do not remove the power supply unless the server has been powered down. Removing the only operational power supply will cause an immediate power loss.

NOTE: To remove the primary hot-plug power supply, remove the shipping screw under the power supply handle. Use the T-15 Torx screwdriver ("Rear panel components" on page 9).

1. Remove the power supply blank.



2. Install the redundant hot-plug power supply.



3. Connect the power cord to the redundant power supply.
4. Secure the power cords to the retaining clip ("Setting up a tower server" on page 33).
5. Connect the power cord to the power source.
6. Be sure that the power supply LED is green.
7. Be sure that the front panel external health LED is green ("Front panel LEDs and buttons" on page 8).



IMPORTANT: For maximum server availability, be sure that the two power supplies are powered by separate AC power sources.



NOTE: If the server will be shipped to another location after configuration, install a shipping screw into each power supply.

Redundant hot-plug fans

The server supports redundant hot-plug fans to provide proper airflow to the system if a primary fan fails.

In the standard configuration, primary fans 2, 4, and 6 cool the server.

For the redundant configuration, fans 1, 3, and 5 are added to back up the primary fans. This configuration allows the server to continue operation in non-redundant mode if a fan failure occurs.

For full redundancy, all fans must be installed.

For fan locations, refer to "Hot-plug fans (on page 21)."

Installing hot-plug fans



WARNING: To prevent personal injury from hazardous energy:


- Remove watches, rings, or other metal objects.
- Use tools with insulated handles.
- Do not place tools or metal parts on top of batteries.

1. Do one of the following:
 - Unlock and remove the bezel ("Unlock and remove the tower bezel" on page 25).
 - Extend the server from the rack (on page 23).

2. Remove the access panel (on page 27).
3. Install fans 1, 3 and 5.



NOTE: Any hot-plug fan provided in the redundant hot-plug fan cage option kit can be installed in any of the hot-plug fan slots. Fans are keyed to fit only one way in the slot.



4. Observe the LED on each installed fan to be sure it is green.
5. Observe the internal system health LED on the front panel to be sure it is green ("[Front panel LEDs and buttons](#)" on page 8).
6. Install the access panel. ("[Install the access panel](#)" on page 27)
7. Do one of the following:
 - Install and lock the bezel.
 - Slide the server back into the rack.



NOTE: If the front panel internal system health LED is not green after you install hot-plug fans, reset the hot-plug fan or refer to the troubleshooting section.

Replacing hot-plug fans




IMPORTANT: Remove and replace one fan at a time. If the system detects two fan failures while in full redundant mode, the server will shut down to avoid thermal damage.

When all redundant fans are installed, individual fans can be hot-swapped at any time.

1. Do one of the following:
 - Unlock and remove the bezel ("[Unlock and remove the tower bezel](#)" on page 25).
 - Extend the server from the rack (on page 23).
2. Remove the access panel (on page 27).

- Remove the failed hot-plug fan.



- Install a new hot-plug fan ("Installing hot-plug fans" on page 63).
- Replace additional fans if needed.
- Observe the internal system health LED on the front panel and the LEDs on each installed fan to be sure it is green.



NOTE: If the front panel internal system health LED is not green after you install hot-plug fans, reseal the hot-plug fan or refer to the troubleshooting section.

- Install the access panel (on page 27).
- Do one of the following:
 - Install and lock the bezel.
 - Slide the server back into the rack.

Expansion board options

The server supports PCI Express and PCI-X expansion boards. For location, refer to "Rear panel components (on page 9)."


Slot	Expansion card type	Capable speed
1	PCI-X	100 MHz* (slots 1 and 2 share the same bus)
2	PCI-X	100 MHz* (slots 1 and 2 share the same bus)
3	PCI-X	100 MHz* (slots 3 and 4 share the same bus)
4	PCI-X	100 MHz* (slots 3 and 4 share the same bus)
5	PCI Express	x4
6	PCI Express	x4
7	PCI Express	x4
8	PCI Express	x4

Slot	Expansion card type	Capable speed
9	PCI Express	x4
10	PCI Express	x4

*HP recommends that cards with speeds of at least 100 MHz be installed in these slots. If cards with lower bus speeds are installed, the bus speed will be reduced. However, server performance will not suffer if the speed on one bus is slower than the speed on a different bus.

Removing an expansion slot cover

1. Power down the server (on page 23).
2. Do one of the following:
 - Unlock and remove the bezel ("[Unlock and remove the tower bezel](#)" on page 25).
 - Extend the server from the rack (on page 23).
3. Remove the access panel (on page 27).
4. Remove the expansion slot cover.




CAUTION: To prevent improper cooling and thermal damage, do not operate the server unless all PCI slots have either an expansion slot cover or an expansion board installed.

Installing expansion boards


CAUTION: To prevent damage to the server or expansion boards, do **not** remove or install expansion boards before powering down the server and disconnecting all AC power cords.

1. Power down the server (on page 23).
2. Do one of the following:
 - Unlock and remove the bezel ("[Unlock and remove the tower bezel](#)" on page 25).
 - Extend the server from the rack (on page 23).
3. Remove the access panel (on page 27).
4. Remove the expansion slot cover ("[Removing an expansion slot cover](#)" on page 66).

5. Open the retaining clip and unlock the PCI slot release lever.



6. Install the expansion board.
7. Lock the PCI slot release lever and close the retaining clip.



8. Connect any required internal or external cables to the expansion board. For additional information, refer to the documentation that ships with the expansion board.
9. Install the access panel (on page 27).
10. Do one of the following:
 - Install and lock the bezel.
 - Slide the server back into the rack.

Tower-to-rack conversion

The tower-to-rack conversion kit includes all equipment required to convert the tower model server into a rack model server, and to install the server into most square- or round-hole racks.

The tower-to-rack conversion kit includes:

- Rack rail assemblies
- Server rails
- Cable management arm bracket
- Cable management arm support bracket (screw retaining plate)
- Installation screws
- Cable management arm
- Rack bezel assembly
- Tower-to-rack conversion installation instructions document

In addition to the items supplied in the conversion kit, use the Torx T-15 screwdriver ("[Rear panel components](#)" on page 9).

Before proceeding with the tower-to-rack conversion:

1. Power down the server (on page 23).
2. Disconnect all power cords from the server.
3. Disconnect all remaining external cables from the server rear panel ("[Rear panel components](#)" on page 9).
4. Remove all hot-plug power supplies ("[Redundant hot-plug power supply option](#)" on page 62).
5. Back up all server data on the hard drives.
6. Remove all hot-plug hard drives ("[Removing a hot-plug SAS hard drive](#)" on page 56).
7. Remove the tower bezel ("[Unlock and remove the tower bezel](#)" on page 25).

Removing the casters

⚠ WARNING: The server is very heavy, up to 63.5 kg (140 lb). To reduce the risk of personal injury or damage to the equipment:


- Remove all power supplies and hard drives to reduce the weight of the server before lifting it.
- Observe local occupational health and safety requirements and guidelines for manual material handling.
- Use more than one person to lift and stabilize the server.

⚠ CAUTION: Be sure to lock the casters and have the access panel in place before turning or reorienting the server position.

To remove the casters:


1. Place the server on a flat, level surface with the access panel down.

2. Remove the three T-15 Torx screws from each of the four casters and remove the casters.



Removing the tower cover

1. Remove the two T-15 Torx screws that secure the tower cover to the server.
2. Slide the tower cover toward the rear of the server and pull the cover away from the chassis.




3. Turn the server over so that the access panel is on top.


Installing the rack bezel

1. Remove the access panel (on page 27).

2. Remove the front fan cage.




3. Remove the tower bezel retaining clips from the front panel.



4. Remove the media blank. ("[Removing the tape drive blank](#)" on page 58)
5. Install the fan cage.
6. Align the three tabs on each side of the rack bezel with the corresponding slots in the chassis.
7. Secure the rack bezel to the server:
 - a. Be sure the latch locks in place on the inside of the media bay.

Removing the cable management arm

Pull the release pin and slide the cable management arm out from the inner rail.



Removing the server from the rack


⚠ WARNING: The server is very heavy, up to 63.5 kg (140 lb). To reduce the risk of personal injury or damage to the equipment:

- Remove all power supplies and hard drives to reduce the weight of the server before lifting it.
- Observe local occupational health and safety requirements and guidelines for manual material handling.
- Use more than one person to lift and stabilize the server.

1. Extend the server on the rack rails until the server rail-release latches engage.



NOTE: The release latches will lock into place when the rails are fully extended.




2. Pull the server rail-release latches and extend the server until the server is free from the rack.

3. Remove the server from the rack.
4. Place the server on a flat, level surface with the access panel facing down.

Removing the server rails


1. Release the latch while pressing the rail against the side of the chassis and slide the rail toward the rear of the server, lining up the keys with the larger keyholes.
2. Remove the rail.



3. Repeat steps 1 and 2 for the other rail.


Installing the tower cover

1. Remove the rack bezel (rack servers only) ("[Remove the rack bezel](#)" on page 26).
2. Place the tower cover onto the unit and slide it toward the front of the server.
3. Be sure the ten metal hooks (five per side) on the inside of the cover engage the chassis.
4. Use a T-15 Torx screwdriver to install the two T-15 screws to secure the tower cover.



Installing the casters

Use a T-15 Torx screwdriver to install the three T-15 Torx screws into each of the four casters.




Installing the tower bezel

1. Set the server in its upright tower position.

CAUTION: Be sure to lock the casters and have the access panel in place before turning or reorienting the server position.

2. Install the two retention clips on the front of the server.
3. Line up the hinges of the tower bezel with the corresponding slots on the chassis and slide the hinges onto the pins.



4. Close the front bezel.
5. Install the power supply, if applicable ("[Redundant hot-plug power supply option](#)" on page 62).
6. Install the hard drives, if applicable ("[Installing a hot-plug SAS or SATA hard drive](#)" on page 55).

7. Connect all cables ("[Rear panel components](#)" on page 9).
8. Power up the server (on page [23](#)).

Cabling

In this section


Storage device cabling guidelines.....	76
Tape drive cabling to the USB connector.....	76
SAS cabling	77
Video connector cabling	77
Battery-backed write cache cabling	78

Storage device cabling guidelines

- ⚠ **CAUTION:** To prevent damage to the equipment, be sure that the server is powered down, all cables are disconnected from the back of the server, and the power cord is disconnected from the grounded (earthed) AC outlet before installing devices.
- ⚠ **CAUTION:** To prevent damage to electrical components, properly ground the server before beginning any installation procedure. Improper grounding can cause electrostatic discharge.


Tape drive cabling to the USB connector

 **IMPORTANT:** Route the USB cable under the mid fan cage.




Item	Description
1	USB connector on the system board
2	USB connector on the media device


SAS cabling



Video connector cabling



Battery-backed write cache cabling



Software and configuration utilities

In this section

Configuration tools	79
Management tools.....	82
Diagnostic tools	84
Remote support and analysis tools.....	84
Keeping the system current	85

Configuration tools

SmartStart software

SmartStart is a collection of software that optimizes single-server setup, providing a simple and consistent way to deploy server configuration. SmartStart has been tested on many ProLiant server products, resulting in proven, reliable configurations.

SmartStart assists the deployment process by performing a wide range of configuration activities, including:

- Configuring hardware using embedded configuration utilities, such as RBSU and ORCA
- Preparing the system for installing "off-the-shelf" versions of leading operating system software
- Installing optimized server drivers, management agents, and utilities automatically with every assisted installation
- Testing server hardware using the Insight Diagnostics Utility ("[HP Insight Diagnostics](#)" on page 84)
- Installing software drivers directly from the CD. With systems that have internet connection, the SmartStart Autorun Menu provides access to a complete list of ProLiant system software.
- Enabling access to the Array Configuration Utility (on page 81), Array Diagnostic Utility (on page 84), and Erase Utility

SmartStart is included in the HP ProLiant Essentials Foundation Pack. For more information about SmartStart software, refer to the HP ProLiant Essentials Foundation Pack or the HP website (<http://www.hp.com/servers/smartstart>).

SmartStart Scripting Toolkit

The SmartStart Scripting Toolkit is a server deployment product that delivers an unattended automated installation for high-volume server deployments. The SmartStart Scripting Toolkit is designed to support ProLiant BL, ML, and DL servers. The toolkit includes a modular set of utilities and important documentation that describes how to apply these new tools to build an automated server deployment process.

Using SmartStart technology, the Scripting Toolkit provides a flexible way to create standard server configuration scripts. These scripts are used to automate many of the manual steps in the server configuration process. This automated server configuration process cuts time from each server deployed, making it possible to scale server deployments to high volumes in a rapid manner.

For more information, and to download the SmartStart Scripting Toolkit, refer to the HP website (<http://www.hp.com/servers/sstoolkit>).

HP ROM-Based Setup Utility

RBSU, an embedded configuration utility, performs a wide range of configuration activities that may include:

- Configuring system devices and installed options
- Displaying system information
- Selecting the primary boot controller
- Configuring memory options
- Language selection

For more information on RBSU, refer to the *HP ROM-Based Setup Utility User Guide* on the Documentation CD or the HP website (<http://www.hp.com/servers/smartstart>).

Boot options

After the auto-configuration process completes, or after the server reboots upon exit from RBSU, the POST sequence runs, and then the boot option screen is displayed. This screen is visible for several seconds before the system attempts to boot from a diskette, CD, or hard drive. During this time, the menu on the screen allows you to install an operating system or make changes to the server configuration in RBSU.

BIOS Serial Console

BIOS Serial Console allows you to configure the serial port to view POST error messages and run RBSU remotely through a serial connection to the server COM port. The server that you are remotely configuring does not require a keyboard and mouse.

For more information about BIOS Serial Console, refer to the *BIOS Serial Console User Guide* on the Documentation CD or the HP website (<http://www.hp.com/servers/smartstart>).

Configuring memory

After installing the required DIMMs, configure the server memory:

1. To power up the server, press the Power On/Standby button.
2. Access RBSU by pressing the **F9** key during powerup when prompted.
3. Select **System Options**.
4. Select **Advanced Memory Protection**.
5. Select the appropriate mode:
 - Advanced ECC
 - Online spare
 - Mirrored memory
 - Hot-plug RAID memory
6. Press the **Enter** key.
7. Press the **Escape** key twice to return to the RBSU menu.
8. Press the **F10** key to exit RBSU.

Array Configuration Utility

ACU is a browser-based utility with the following features:

- Runs as a local application or remote service
- Supports online array capacity expansion, logical drive extension, assignment of online spares, and RAID or stripe size migration
- Suggests the optimum configuration for an unconfigured system
- Provides different operating modes, enabling faster configuration or greater control over the configuration options
- Remains available any time that the server is on
- Displays on-screen tips for individual steps of a configuration procedure

For optimum performance, the minimum display settings are 800 × 600 resolution and 256 colors. Servers running Microsoft® operating systems require Internet Explorer 5.5 (with Service Pack 1) or later. For Linux servers, refer to the README.TXT file for additional browser and support information.

For more information, refer to the *HP Array Configuration Utility User Guide* on the Documentation CD or the HP website (<http://www.hp.com>).

HP ProLiant Essentials Rapid Deployment Pack

The RDP software is the preferred method for rapid, high-volume server deployments. The RDP software integrates two powerful products: Altiris Deployment Solution and the HP ProLiant Integration Module.

The intuitive graphical user interface of the Altiris Deployment Solution console provides simplified point-and-click and drag-and-drop operations that enable you to deploy target servers, including server blades, remotely. It enables you to perform imaging or scripting functions and maintain software images.

For more information about the RDP, refer to the HP ProLiant Essentials Rapid Deployment Pack CD or refer to the HP website (<http://www.hp.com/servers/rdp>).

Re-entering the server serial number and product ID

After you replace the system board, you must re-enter the server serial number and the product ID.

1. During the server startup sequence, press the **F9** key to access RBSU.
2. Select the **System Options** menu.
3. Select **Serial Number**. The following warning is displayed:

```
WARNING! WARNING! WARNING! The serial number is loaded into the system
during the manufacturing process and should NOT be modified. This option
should only be used by qualified service personnel. This value should
always match the serial number sticker located on the chassis.
```
4. Press the **Enter** key to clear the warning.
5. Enter the serial number and press the **Enter** key.
6. Select **Product ID**.
7. Enter the product ID and press the **Enter** key.
8. Press the **Esc** key to close the menu.
9. Press the **Esc** key to exit RBSU.
10. Press the **F10** key to confirm exiting RBSU. The server will automatically reboot.

Management tools

Automatic Server Recovery

ASR is a feature that causes the system to restart when a catastrophic operating system error occurs, such as a blue screen, ABEND, or panic. A system fail-safe timer, the ASR timer, starts when the System Management driver, also known as the Health Driver, is loaded. When the operating system is functioning properly, the system periodically resets the timer. However, when the operating system fails, the timer expires and restarts the server.

ASR increases server availability by restarting the server within a specified time after a system hang or shutdown. At the same time, the HP SIM console notifies you by sending a message to a designated pager number that ASR has restarted the system. You can disable ASR from the HP SIM console or through RBSU.

ROMPaq utility

Flash ROM enables you to upgrade the firmware (BIOS) with system or option ROMPaq utilities. To upgrade the BIOS, insert a ROMPaq diskette into the diskette drive and boot the system.

The ROMPaq utility checks the system and provides a choice (if more than one exists) of available ROM revisions. This procedure is the same for both system and option ROMPaq utilities.

For more information about the ROMPaq utility, refer to the HP website (<http://www.hp.com/servers/manage>).

Integrated Lights-Out 2 technology

The iLO 2 subsystem is a standard component of selected ProLiant servers that provides server health and remote server manageability. The iLO 2 subsystem includes an intelligent microprocessor, secure memory, and a dedicated network interface. This design makes iLO 2 independent of the host server and its operating system. The iLO 2 subsystem provides remote access to any authorized network client, sends alerts, and provides other server management functions.

Using iLO 2, you can:

- Remotely power up, power down, or reboot the host server.
- Send alerts from iLO 2 regardless of the state of the host server.
- Access advanced troubleshooting features through the iLO 2 interface.
- Diagnose iLO 2 using HP SIM through a web browser and SNMP alerting.

For more information about iLO 2 features, refer to the iLO 2 documentation on the Documentation CD or on the HP website (<http://www.hp.com/servers/lights-out>).

StorageWorks library and tape tools

HP StorageWorks L&TT provides functionality for firmware downloads, verification of device operation, maintenance procedures, failure analysis, corrective service actions, and some utility functions. It also provides seamless integration with HP hardware support by generating and emailing support tickets that deliver a snapshot of the storage system.

For more information, and to download the utility, refer to the StorageWorks L&TT website (<http://h18006.www1.hp.com/products/storageworks/ltt>).

HP Systems Insight Manager

HP SIM is a web-based application that allows system administrators to accomplish normal administrative tasks from any remote location, using a web browser. HP SIM provides device management capabilities that consolidate and integrate management data from HP and third-party devices.



IMPORTANT: You must install and use HP SIM to benefit from the Pre-Failure Warranty for processors, SCSI hard drives, and memory modules.

For additional information, refer to the Management CD in the HP ProLiant Essentials Foundation Pack or the HP SIM website (<http://www.hp.com/go/hpsim>).

Management Agents

Management Agents provide the information to enable fault, performance, and configuration management. The agents allow easy manageability of the server through HP SIM software, and third-party SNMP management platforms. Management Agents are installed with every SmartStart assisted installation or can be installed through the HP PSP. The Systems Management homepage provides status and direct access to in-depth subsystem information by accessing data reported through the Management Agents. For additional information, refer to the Management CD in the HP ProLiant Essentials Foundation Pack or the HP website (<http://www.hp.com/servers/manage>).

Redundant ROM support

The server enables you to upgrade or configure the ROM safely with redundant ROM support. The server has a 4-MB ROM that acts as two, separate 2-MB ROMs. In the standard implementation, one side of the ROM contains the current ROM program version, while the other side of the ROM contains a backup version.



NOTE: The server ships with the same version programmed on each side of the ROM.

Safety and security benefits

When you flash the system ROM, ROMPaq writes over the backup ROM and saves the current ROM as a backup, enabling you to switch easily to the alternate ROM version if the new ROM becomes corrupted for any reason. This feature protects the existing ROM version, even if you experience a power failure while flashing the ROM.

USB support

HP provides both standard USB support and legacy USB support. Standard support is provided by the OS through the appropriate USB device drivers. Before the OS loads, HP provides support for USB devices through legacy USB support, which is enabled by default in the system ROM. HP hardware supports USB version 1.1 or 2.0, depending on the version of the hardware.

Legacy USB support provides USB functionality in environments where USB support is normally not available. Specifically, HP provides legacy USB functionality for:

- POST
- RBSU
- Diagnostics
- DOS
- Operating environments which do not provide native USB support

For more information on ProLiant USB support, refer to the HP website (<http://h18004.www1.hp.com/products/servers/platforms/usb-support.html>).

Diagnostic tools

HP Insight Diagnostics

HP Insight Diagnostics is a proactive server management tool, available in both offline and online versions, that provides diagnostics and troubleshooting capabilities to assist IT administrators who verify server installations, troubleshoot problems, and perform repair validation.

HP Insight Diagnostics Offline Edition performs various in-depth system and component testing while the OS is not running. To run this utility, launch the SmartStart CD.

HP Insight Diagnostics Online Edition is a web-based application that captures system configuration and other related data needed for effective server management. Available in Microsoft® Windows® and Linux versions, the utility helps to ensure proper system operation.

For more information or to download the utility, refer to the HP website (<http://www.hp.com/servers/diags>).

Integrated Management Log

The IML records hundreds of events and stores them in an easy-to-view form. The IML timestamps each event with 1-minute granularity.

You can view recorded events in the IML in several ways, including the following:

- From within HP SIM ("HP Systems Insight Manager" on page 83)
- From within Survey Utility
- From within operating system-specific IML viewers
 - For NetWare: IML Viewer
 - For Windows®: IML Viewer
 - For Linux: IML Viewer Application
- From within HP Insight Diagnostics (on page 84)

For more information, refer to the Management CD in the HP ProLiant Essentials Foundation Pack.

Array Diagnostic Utility

ADU is tool that collects information about array controllers and generates a list of detected problems. ADU can be accessed from the SmartStart CD ("SmartStart software" on page 79) or downloaded from the HP website (<http://www.hp.com>).

Remote support and analysis tools

HP Instant Support Enterprise Edition

ISEE is a proactive remote monitoring and diagnostic tool to help manage your systems and devices, a feature of HP support. ISEE provides continuous hardware event monitoring and automated notification to identify and prevent potential critical problems. Through remote diagnostic scripts and vital system configuration information collected about your systems, ISEE enables fast restoration of your systems. Install ISEE on your systems to help mitigate risk and prevent potential critical problems.

For more information on ISEE, refer to the HP website (http://www.hp.com/hps/hardware/hw_enterprise.html).

To download HP ISEE, visit the HP website (http://www.hp.com/hps/hardware/hw_downloads.html).

For installation information, refer to the HP ISEE Client Installation and Upgrade Guide (ftp://ftp.hp.com/pub/services/hardware/info/isee_client.pdf).

Keeping the system current

Drivers

The server includes new hardware that may not have driver support on all operating system installation media.

If you are installing a SmartStart-supported operating system, use the SmartStart software (on page 79) and its Assisted Path feature to install the operating system and latest driver support.



NOTE: If you are installing drivers from the SmartStart CD or the Software Maintenance CD, refer to the SmartStart website (<http://www.hp.com/servers/smartstart>) to be sure that you are using the latest version of SmartStart. For more information, refer to the documentation provided with the SmartStart CD.

If you do not use the SmartStart CD to install an operating system, drivers for some of the new hardware are required. These drivers, as well as other option drivers, ROM images, and value-add software can be downloaded from the HP website (<http://www.hp.com/support>).



IMPORTANT: Always perform a backup before installing or updating device drivers.

ProLiant Support Packs

PSPs represent operating system-specific bundles of ProLiant optimized drivers, utilities, and management agents. Refer to the PSP website (<http://h18000.www1.hp.com/products/servers/management/psp.html>).

Operating system version support

Refer to the operating system support matrix (<http://www.hp.com/go/supportos>).

System Online ROM Flash Component Utility

The Online ROM Flash Component Utility enables system administrators to efficiently upgrade system or controller ROM images across a wide range of servers and array controllers. This tool has the following features:

- Works offline and online
- Supports Microsoft® Windows® 2000, Windows® Server 2003, and Linux operating systems



IMPORTANT: This utility supports operating systems that may not be supported by the server. For operating systems supported by the server, refer to the HP website (<http://www.hp.com/go/supportos>).

- Integrates with other software maintenance, deployment, and operating system tools
- Automatically checks for hardware, firmware, and operating system dependencies, and installs only the correct ROM upgrades required by each target server

To download the tool and for more information, refer to the HP website (<http://h18000.www1.hp.com/support/files/index.html>).

Change control and proactive notification

HP offers Change Control and Proactive Notification to notify customers 30 to 60 days in advance of upcoming hardware and software changes on HP commercial products.

For more information, refer to the HP website (<http://h18023.www1.hp.com/solutions/pcsolutions/pcn.html>).

Natural language search assistant

The natural language search assistant (http://www.hp.com/support/natural_language_search) is a search engine that finds information on HP products, including ProLiant servers. The search engine responds to queries entered in question form.

Care Pack

HP Care Pack Services offer upgraded service levels to extend and expand standard product warranty with easy-to-buy, easy-to-use support packages that help you make the most of your server investments. Refer to the Care Pack website (http://www.hp.com/hps/carepack/servers/cp_proliant.html).

Troubleshooting

In this section

Troubleshooting resources	87
Pre-diagnostic steps	87
Loose connections	90
Service notifications.....	90
Troubleshooting flowcharts	91
POST error messages and beep codes.....	102

Troubleshooting resources

The *HP ProLiant Servers Troubleshooting Guide* provides simple procedures for resolving common problems as well as a comprehensive course of action for fault isolation and identification, error message interpretation, issue resolution, and software maintenance.

To obtain the guide, refer to any of the following sources and then select the *HP ProLiant Servers Troubleshooting Guide*:

- The server-specific Documentation CD
- The Business Support Center on the HP website (<http://www.hp.com/support>). Navigate to the server technical support page. Under self-help resources, select **ProLiant Troubleshooting Guide**.
- The Technical Documentation website (<http://www.docs.hp.com>). Select **Enterprise Servers, Workstations and Systems Hardware**, and then the appropriate server.

Pre-diagnostic steps

 **WARNING:** To avoid potential problems, **ALWAYS** read the warnings and cautionary information in the server documentation before removing, replacing, reseating, or modifying system components.

 **IMPORTANT:** This guide provides information for multiple servers. Some information may not apply to the server you are troubleshooting. Refer to the server documentation for information on procedures, hardware options, software tools, and operating systems supported by the server.

1. Review the important safety information (on page 87).
2. Gather symptom information (on page 89).
3. Prepare the server for diagnosis (on page 90).
4. Use the Start diagnosis flowchart (on page 91) to begin the diagnostic process.

Important safety information

Familiarize yourself with the safety information in the following sections before troubleshooting the server.



Important safety information

Before servicing this product, read the *Important Safety Information* document provided with the server.

Symbols on equipment

The following symbols may be placed on equipment to indicate the presence of potentially hazardous conditions.



This symbol indicates the presence of hazardous energy circuits or electric shock hazards. Refer all servicing to qualified personnel.

WARNING: To reduce the risk of injury from electric shock hazards, do not open this enclosure. Refer all maintenance, upgrades, and servicing to qualified personnel.



This symbol indicates the presence of electric shock hazards. The area contains no user or field serviceable parts. Do not open for any reason.

WARNING: To reduce the risk of injury from electric shock hazards, do not open this enclosure.



This symbol on an RJ-45 receptacle indicates a network interface connection.

WARNING: To reduce the risk of electric shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into this receptacle.



This symbol indicates the presence of a hot surface or hot component. If this surface is contacted, the potential for injury exists.

WARNING: To reduce the risk of injury from a hot component, allow the surface to cool before touching.



63.5 kg

140 lb

This symbol indicates that the component exceeds the recommended weight for one individual to handle safely.

WARNING: To reduce the risk of personal injury or damage to the equipment, observe local occupational health and safety requirements and guidelines for manual material handling.



These symbols, on power supplies or systems, indicate that the equipment is supplied by multiple sources of power.

WARNING: To reduce the risk of injury from electric shock, remove all power cords to completely disconnect power from the system.

Warnings and cautions

-  **WARNING:** Only authorized technicians trained by HP should attempt to repair this equipment. All troubleshooting and repair procedures are detailed to allow only subassembly/module-level repair. Because of the complexity of the individual boards and subassemblies, no one should attempt to make repairs at the component level or to make modifications to any printed wiring board. Improper repairs can create a safety hazard.

⚠ WARNING: To reduce the risk of personal injury or damage to the equipment, be sure that:

- The leveling feet are extended to the floor.
- The full weight of the rack rests on the leveling feet.
- The stabilizing feet are attached to the rack if it is a single-rack installation.
- The racks are coupled together in multiple-rack installations.
- Only one component is extended at a time. A rack may become unstable if more than one component is extended for any reason.

⚠ WARNING: To reduce the risk of electric shock or damage to the equipment:

- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
- Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.
- Unplug the power cord from the power supply to disconnect power to the equipment.
- Do not route the power cord where it can be walked on or pinched by items placed against it. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server.



63.5 kg

140 lb

WARNING: To reduce the risk of personal injury or damage to the equipment:

- Observe local occupation health and safety requirements and guidelines for manual handling.
 - Obtain adequate assistance to lift and stabilize the chassis during installation or removal.
 - The server is unstable when not fastened to the rails.
 - When mounting the server in a rack, remove the power supplies and any other removable module to reduce the overall weight of the product.
-

⚠ CAUTION: To properly ventilate the system, you must provide at least 7.6 cm (3.0 in) of clearance at the front and back of the server.

⚠ CAUTION: The server is designed to be electrically grounded (earthed). To ensure proper operation, plug the AC power cord into a properly grounded AC outlet only.

Symptom information

Before troubleshooting a server problem, collect the following information:

- What events preceded the failure? After which steps does the problem occur?
- What has been changed since the time the server was working?
- Did you recently add or remove hardware or software? If so, did you remember to change the appropriate settings in the server setup utility, if necessary?
- How long has the server exhibited problem symptoms?
- If the problem occurs randomly, what is the duration or frequency?

To answer these questions, the following information may be useful:

- Run HP Insight Diagnostics (on page 84) and use the survey page to view the current configuration or to compare it to previous configurations.
- Refer to your hardware and software records for information.
- Refer to server LEDs and their statuses.

Prepare the server for diagnosis

1. Be sure the server is in the proper operating environment with adequate power, air conditioning, and humidity control. Refer to the server documentation for required environmental conditions.
2. Record any error messages displayed by the system.
3. Remove all diskettes and CDs from the media drives.
4. Power down the server and peripheral devices if you will be diagnosing the server offline. Always perform an orderly shutdown, if possible. This means you must:
 - a. Exit any applications.
 - b. Exit the operating system.
 - c. Power down the server (on page 23).
5. Disconnect any peripheral devices not required for testing (any devices not necessary to power up the server). Do not disconnect the printer if you want to use it to print error messages.
6. Collect all tools and utilities, such as a Torx screwdriver, loopback adapters, ESD wrist strap, and software utilities, necessary to troubleshoot the problem.
 - You must have the appropriate Health Drivers and Management Agents installed on the server.



NOTE: To verify the server configuration, connect to the System Management homepage and select **Version Control Agent**. The VCA gives you a list of names and versions of all installed HP drivers, Management Agents, and utilities, and whether they are up to date.

- HP recommends you have access to the SmartStart CD for value-added software and drivers required during the troubleshooting process.
- HP recommends you have access to the server documentation for server-specific information.

Loose connections

Action:

- Be sure all power cords are securely connected.
- Be sure all cables are properly aligned and securely connected for all external and internal components.
- Remove and check all data and power cables for damage. Be sure no cables have bent pins or damaged connectors.
- If a fixed cable tray is available for the server, be sure the cords and cables connected to the server are correctly routed through the tray.
- Be sure each device is properly seated.
- If a device has latches, be sure they are completely closed and locked.
- Check any interlock or interconnect LEDs that may indicate a component is not connected properly.
- If problems continue to occur, remove and reinstall each device, checking the connectors and sockets for bent pins or other damage.

Service notifications

To view the latest service notifications, refer to the HP website (<http://www.hp.com/go/bizsupport>). Select the appropriate server model, and then click the **Troubleshoot a Problem** link on the product page.

Troubleshooting flowcharts

To effectively troubleshoot a problem, HP recommends that you start with the first flowchart in this section, "Start diagnosis flowchart (on page 91)," and follow the appropriate diagnostic path. If the other flowcharts do not provide a troubleshooting solution, follow the diagnostic steps in "General diagnosis flowchart (on page 92)." The General diagnosis flowchart is a generic troubleshooting process to be used when the problem is not server-specific or is not easily categorized into the other flowcharts.


The available flowcharts include:

- Start diagnosis flowchart (on page 91)
- General diagnosis flowchart (on page 92)
- Server power-on problems flowchart (on page 94)
- POST problems flowchart (on page 97)
- OS boot problems flowchart (on page 98)
- Server fault indications flowchart (on page 100)

Start diagnosis flowchart

Use the following flowchart to start the diagnostic process.

Item	Refer to
1	"General diagnosis flowchart (on page 92)"
2	"Power-on problems flowchart (" Server power-on problems flowchart " on page 94)"
3	"POST problems flowchart (on page 97)"
4	"OS boot problems flowchart (on page 98)"
5	"Server fault indications flowchart (on page 100)"




General diagnosis flowchart

The General diagnosis flowchart provides a generic approach to troubleshooting. If you are unsure of the problem, or if the other flowcharts do not fix the problem, use the following flowchart.

Item	Refer to
1	"Symptom information (on page 89)"
2	"Loose connections (on page 90)"
3	"Service notifications (on page 90)"

Item	Refer to
4	<p>The most recent version of a particular server or option firmware is available on the following websites:</p> <ul style="list-style-type: none"> • HP Support website (http://www.hp.com/support) • HP ROM-BIOS/Firmware Updates website (http://h18023.www1.hp.com/support/files/server/us/romflash.html)
5	<p>"General memory problems are occurring" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)</p>
6	<p>Server maintenance and service guide, located on the Documentation CD or the HP website (http://www.hp.com/products/servers/platforms)</p>
7	<ul style="list-style-type: none"> • Server maintenance and service guide, located on the Documentation CD or the HP website (http://www.hp.com/products/servers/platforms) • "Hardware problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
8	<ul style="list-style-type: none"> • "Server information you need" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • "Operating system information you need" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
9	<p>"HP contact information (on page 112)"</p>



Server power-on problems flowchart

Symptoms:

- The server does not power on.
- The system power LED is off or amber.
- The external health LED is red or amber.

- The internal health LED is red or amber.




NOTE: For the location of server LEDs and information on their statuses, refer to the server documentation.

Possible causes:

- Improperly seated or faulty power supply
- Loose or faulty power cord
- Power source problem
- Power on circuit problem
- Improperly seated component or interlock problem
- Faulty internal component

Item	Refer to
1	"Component identification (on page 7)"
2	"HP Insight Diagnostics (on page 84)" or in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
3	"Loose connections (on page 90)"
4	Server maintenance and service guide, located on the Documentation CD, or the HP website (http://www.hp.com/products/servers/platforms)
5	"Integrated Management Log (on page 84)" or in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
6	"Power source problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
7	<ul style="list-style-type: none"> • "Power supply problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • Server maintenance and service guide, located on the Documentation CD, or the HP website (http://www.hp.com/products/servers/platforms)
8	"System open circuits and short circuits" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)



POST problems flowchart

Symptoms:

- Server does not complete POST




NOTE: The server has completed POST when the system attempts to access the boot device.

- Server completes POST with errors

Possible problems:

- Improperly seated or faulty internal component
- Faulty KVM device
- Faulty video device

Item	Refer to
1	"POST error messages and beep codes"
2	"Video problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
3	KVM or iLO 2 documentation
4	"Loose connections (on page 90)"
5	"Symptom information (on page 89)"
6	Server maintenance and service guide, located on the Documentation CD or the HP website (http://www.hp.com/products/servers/platforms)
7	"Port 85 and iLO messages" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
8	"General memory problems are occurring" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
9	<ul style="list-style-type: none"> • "Hardware problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • Server maintenance and service guide, located on the Documentation CD or the HP website (http://www.hp.com/products/servers/platforms)
10	<ul style="list-style-type: none"> • "Server information you need" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • "Operating system information you need" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)



OS boot problems flowchart


Symptoms:

- Server does not boot a previously installed operating system
- Server does not boot SmartStart

Possible causes:

- Corrupted operating system
- Hard drive subsystem problem

Item	Refer to
1	HP ROM-Based Setup Utility User Guide (http://www.hp.com/servers/smartstart)
2	"POST problems flowchart (on page 97)"
3	<ul style="list-style-type: none"> • "Hard drive problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • Controller documentation
4	"HP Insight Diagnostics (on page 84)" or in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
5	<ul style="list-style-type: none"> • "CD-ROM and DVD drive problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • Controller documentation • "Loose connections (on page 90)"
6	"General memory problems are occurring" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
7	<ul style="list-style-type: none"> • "Operating system problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • "HP contact information (on page 112)"
8	<ul style="list-style-type: none"> • "Hardware problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • Server maintenance and service guide, located on the Documentation CD or the HP website (http://www.hp.com/products/servers/platforms)
9	"General diagnosis flowchart (on page 92)"



Server fault indications flowchart

Symptoms:

- Server boots, but a fault event is reported by Insight Management Agents (on page 83)
- Server boots, but the internal health LED, external health LED, or component health LED is red or amber




NOTE: For the location of server LEDs and information on their statuses, refer to the server documentation.

Possible causes:

- Improperly seated or faulty internal or external component
- Unsupported component installed
- Redundancy failure
- System overtemperature condition

Item	Refer to
1	"Management agents (on page 83)" or in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
2	<ul style="list-style-type: none"> • "Integrated Management Log (on page 84)" or in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • "Event list error messages" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
3	"Component identification (on page 7)"
4	System Management Homepage (https://localhost:2381)
5	"Power-on problems flowchart ("Server power-on problems flowchart" on page 94)"
6	<ul style="list-style-type: none"> • "Smart Array SCSI Diagnosis feature" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • Server maintenance and service guide, located on the Documentation CD or the HP website (http://www.hp.com/products/servers/platforms) • "HP contact information (on page 112)"
7	"HP Insight Diagnostics (on page 84)" or in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support)
8	<ul style="list-style-type: none"> • "Hardware problems" in the <i>HP ProLiant Servers Troubleshooting Guide</i> located on the Documentation CD or on the HP website (http://www.hp.com/support) • Server maintenance and service guide, located on the Documentation CD or the HP website (http://www.hp.com/products/servers/platforms)



POST error messages and beep codes

For a complete listing of error messages, refer to the "POST error messages" in the *HP ProLiant Servers Troubleshooting Guide* located on the Documentation CD or on the HP website (<http://www.hp.com/support>).

⚠ WARNING: To avoid potential problems, ALWAYS read the warnings and cautionary information in the server documentation before removing, replacing, reseating, or modifying system components.

Electrostatic discharge

In this section

Preventing electrostatic discharge.....	103
Grounding methods to prevent electrostatic discharge	103

Preventing electrostatic discharge

To prevent damaging the system, be aware of the precautions you need to follow when setting up the system or handling parts. A discharge of static electricity from a finger or other conductor may damage system boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device.

To prevent electrostatic damage:

- Avoid hand contact by transporting and storing products in static-safe containers.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free workstations.
- Place parts on a grounded surface before removing them from their containers.
- Avoid touching pins, leads, or circuitry.
- Always be properly grounded when touching a static-sensitive component or assembly.

Grounding methods to prevent electrostatic discharge

Several methods are used for grounding. Use one or more of the following methods when handling or installing electrostatic-sensitive parts:

- Use a wrist strap connected by a ground cord to a grounded workstation or computer chassis. Wrist straps are flexible straps with a minimum of 1 megohm ± 10 percent resistance in the ground cords. To provide proper ground, wear the strap snug against the skin.
- Use heel straps, toe straps, or boot straps at standing workstations. Wear the straps on both feet when standing on conductive floors or dissipating floor mats.
- Use conductive field service tools.
- Use a portable field service kit with a folding static-dissipating work mat.

If you do not have any of the suggested equipment for proper grounding, have an authorized reseller install the part.

For more information on static electricity or assistance with product installation, contact an authorized reseller.

Regulatory compliance notices

In this section

Regulatory compliance identification numbers.....	104
Federal Communications Commission notice	104
Declaration of conformity for products marked with the FCC logo, United States only.....	105
Modifications.....	106
Cables	106
Canadian notice (Avis Canadien)	106
European Union regulatory notice	106
Disposal of waste equipment by users in private households in the European Union	107
Japanese notice	107
BSMI notice	107
Korean notice	108
Laser compliance	108
Battery replacement notice	108
Taiwan battery recycling notice.....	109
Power cord statement for Japan	109

Regulatory compliance identification numbers

For the purpose of regulatory compliance certifications and identification, this product has been assigned a unique regulatory model number. The regulatory model number can be found on the product nameplate label, along with all required approval markings and information. When requesting compliance information for this product, always refer to this regulatory model number. The regulatory model number is not the marketing name or model number of the product.

Federal Communications Commission notice

Part 15 of the Federal Communications Commission (FCC) Rules and Regulations has established Radio Frequency (RF) emission limits to provide an interference-free radio frequency spectrum. Many electronic devices, including computers, generate RF energy incidental to their intended function and are, therefore, covered by these rules. These rules place computers and related peripheral devices into two classes, A and B, depending upon their intended installation. Class A devices are those that may reasonably be expected to be installed in a business or commercial environment. Class B devices are those that may reasonably be expected to be installed in a residential environment (for example, personal computers). The FCC requires devices in both classes to bear a label indicating the interference potential of the device as well as additional operating instructions for the user.

FCC rating label

The FCC rating label on the device shows the classification (A or B) of the equipment. Class B devices have an FCC logo or ID on the label. Class A devices do not have an FCC logo or ID on the label. After you determine the class of the device, refer to the corresponding statement.

Class A equipment

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at personal expense.

Class B equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit that is different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

Declaration of conformity for products marked with the FCC logo, United States only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding this product, contact us by mail or telephone:

- Hewlett-Packard Company
P. O. Box 692000, Mail Stop 530113
Houston, Texas 77269-2000
- 1-800-HP-INVENT (1-800-474-6836). (For continuous quality improvement, calls may be recorded or monitored.)

For questions regarding this FCC declaration, contact us by mail or telephone:

- Hewlett-Packard Company
P. O. Box 692000, Mail Stop 510101
Houston, Texas 77269-2000
- 1-281-514-3333

To identify this product, refer to the part, series, or model number found on the product.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hewlett-Packard Company may void the user's authority to operate the equipment.

Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods in order to maintain compliance with FCC Rules and Regulations.

Canadian notice (Avis Canadien)

Class A equipment

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Class B equipment

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

European Union regulatory notice

This product complies with the following EU Directives:

- Low Voltage Directive 73/23/EEC
- EMC Directive 89/336/EEC

Compliance with these directives implies conformity to applicable harmonized European standards (European Norms) which are listed on the EU Declaration of Conformity issued by Hewlett-Packard for this product or product family.

This compliance is indicated by the following conformity marking placed on the product:



This marking is valid for non-Telecom products and EU harmonized Telecom products (e.g. Bluetooth).



This marking is valid for EU non-harmonized Telecom products.

*Notified body number (used only if applicable—refer to the product label)

Disposal of waste equipment by users in private households in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Japanese notice

ご使用になっている装置にVCCIマークが付いていましたら、次の説明文をお読み下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。

VCCIマークが付いていない場合には、次の点にご注意下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

BSMI notice

警告使用者:

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

Korean notice

Class A equipment

A급 기기 (업무용 정보통신기기)

이 기기는 업무용으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 만약 잘못판매 또는 구입하였을 때에는 가정용으로 교환하시기 바랍니다.

Class B equipment

B급 기기 (가정용 정보통신기기)

이 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역에서는 물론 모든지역에서 사용할 수 있습니다.

Laser compliance

This product may be provided with an optical storage device (that is, CD or DVD drive) and/or fiber optic transceiver. Each of these devices contains a laser that is classified as a Class 1 Laser Product in accordance with US FDA regulations and the IEC 60825-1. The product does not emit hazardous laser radiation.

Each laser product complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated May 27, 2001; and with IEC 60825-1:1993/A2:2001.

- ⚠ WARNING: Use of controls or adjustments or performance of procedures other than those specified herein or in the laser product's installation guide may result in hazardous radiation exposure. To reduce the risk of exposure to hazardous radiation:**
- **Do not try to open the module enclosure. There are no user-serviceable components inside.**
 - **Do not operate controls, make adjustments, or perform procedures to the laser device other than those specified herein.**
 - **Allow only HP Authorized Service technicians to repair the unit.**

The Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration implemented regulations for laser products on August 2, 1976. These regulations apply to laser products manufactured from August 1, 1976. Compliance is mandatory for products marketed in the United States.

Battery replacement notice

- ⚠ WARNING: The computer contains an internal lithium manganese dioxide, a vanadium pentoxide, or an alkaline battery pack. A risk of fire and burns exists if the battery pack is not properly handled. To reduce the risk of personal injury:**

- **Do not attempt to recharge the battery.**
- **Do not expose the battery to temperatures higher than 60°C (140°F).**
- **Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.**



Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. To forward them to recycling or proper disposal, please use the public collection system or return them to HP, an authorized HP Partner, or their agents.

For more information about battery replacement or proper disposal, contact an authorized reseller or an authorized service provider.

Taiwan battery recycling notice

The Taiwan EPA requires dry battery manufacturing or importing firms in accordance with Article 15 of the Waste Disposal Act to indicate the recovery marks on the batteries used in sales, giveaway or promotion. Contact a qualified Taiwanese recycler for proper battery disposal.



Power cord statement for Japan

製品には、同梱された電源コードをお使い下さい。
同梱された電源コードは、他の製品では使用出来ません。

Specifications

In this section

Server specifications	110
Environmental specifications	110

Server specifications

The following information pertains to the rack configuration.

Specification	Value
Dimension	
Height	26.67 cm (10.5 in)
Depth	67.31 cm (26.5 in)
Width	44.45 cm (17.5 in)
Weight (maximum)	63.5 kg (140 lb)
Weight (no drives installed)	41.28 kg (91 lb)
Input requirement	
Rated input voltage	100-127 VAC 200-240 VAC
Rated input frequency	50 Hz-60 Hz
Rated input current	12 A at 100 VAC 8 A at 200 VAC
Rated input power	1161 W at 100 VAC 1598 W at 200 VAC
BTUs per hour	3960 at 100 VAC 5450 at 200 VAC
Power supply output	
Power supply output	910 W (low line) 1300 W (high line)

* 100 to 127 VAC is required for 8 A; 200 to 240 VAC is required for 4 A.

Environmental specifications

Specification	Value
Temperature range*	
Operating	10°C to 35°C (50°F to 95°F)
Shipping	-40°C to 70°C (-40°F to 158°F)
Maximum wet bulb temperature	28°C (82.4°F)

Specification	Value
Relative humidity (noncondensing)**	
Operating	10% to 90%
Non-operating	5% to 95%

* All temperature ratings shown are for sea level. An altitude derating of 1°C per 300 m (1.8°F per 1,000 ft) to 3048 m (10,000 ft) is applicable. No direct sunlight allowed.

** Storage maximum humidity of 95% is based on a maximum temperature of 45°C (113°F). Altitude maximum for storage corresponds to a pressure minimum of 70 KPa.

Technical support

In this section

Before you contact HP.....	112
HP contact information.....	112
Customer self repair	113

Before you contact HP

Be sure to have the following information available before you call HP:

- Technical support registration number (if applicable)
- Product serial number
- Product model name and number
- Applicable error messages
- Add-on boards or hardware
- Third-party hardware or software
- Operating system type and revision level

HP contact information

For the name of the nearest HP authorized reseller:

- In the United States, refer to the HP US service locator webpage (http://www.hp.com/service_locator).
- In other locations, refer to the HP website (<http://www.hp.com>).

For HP technical support:

- In North America:
 - Call 1-800-HP-INVENT (1-800-474-6836). This service is available 24 hours a day, 7 days a week. For continuous quality improvement, calls may be recorded or monitored.
 - If you have purchased a Care Pack (service upgrade), call 1-800-633-3600. For more information about Care Packs, refer to the HP website (<http://www.hp.com>).
- Outside North America, call the nearest HP Technical Support Phone Center. For telephone numbers for worldwide Technical Support Centers, refer to the HP website (<http://www.hp.com>).

Customer self repair

HP products are designed with many Customer Self Repair (CSR) parts to minimize repair time and allow for greater flexibility in performing defective parts replacement. If during the diagnosis period HP (or HP service providers or service partners) identifies that the repair can be accomplished by the use of a CSR part, HP will ship that part directly to you for replacement. There are two categories of CSR parts:

- **Mandatory**—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.
- **Optional**—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

NOTE: Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

Based on availability and where geography permits, CSR parts will be shipped for next business day delivery. Same day or four-hour delivery may be offered at an additional charge where geography permits. If assistance is required, you can call the HP Technical Support Center and a technician will help you over the telephone. HP specifies in the materials shipped with a replacement CSR part whether a defective part must be returned to HP. In cases where it is required to return the defective part to HP, you must ship the defective part back to HP within a defined period of time, normally five (5) business days. The defective part must be returned with the associated documentation in the provided shipping material. Failure to return the defective part may result in HP billing you for the replacement. With a customer self repair, HP will pay all shipping and part return costs and determine the courier/carrier to be used.

For more information about HP's Customer Self Repair program, contact your local service provider. For the North American program, refer to the HP website (<http://www.hp.com/go/selfrepair>).

Réparation par le client (CSR)

Les produits HP comportent de nombreuses pièces CSR (Customer Self Repair = réparation par le client) afin de minimiser les délais de réparation et faciliter le remplacement des pièces défectueuses. Si pendant la période de diagnostic, HP (ou ses partenaires ou mainteneurs agréés) détermine que la réparation peut être effectuée à l'aide d'une pièce CSR, HP vous l'envoie directement. Il existe deux catégories de pièces CSR:

- **Obligatoire** - Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.
- **Facultatif** - Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

REMARQUE: Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

Les pièces CSR sont livrées le jour ouvré suivant, dans la limite des stocks disponibles et selon votre situation géographique. Si votre situation géographique le permet et que vous demandez une livraison le jour même ou dans les 4 heures, celle-ci vous sera facturée. Pour bénéficier d'une assistance téléphonique, appelez le Centre d'assistance technique HP. Dans les documents envoyés avec la pièce de rechange CSR, HP précise s'il est nécessaire de lui retourner la pièce défectueuse. Si c'est le cas, vous devez le faire dans le délai indiqué, généralement cinq (5) jours ouvrés. La pièce et sa documentation

doivent être retournées dans l'emballage fourni. Si vous ne retournez pas la pièce défectueuse, HP se réserve le droit de vous facturer les coûts de remplacement. Dans le cas d'une pièce CSR, HP supporte l'ensemble des frais d'expédition et de retour, et détermine la société de courses ou le transporteur à utiliser.

Pour plus d'informations sur le programme CSR de HP, contactez votre Mainteneur Agrée local. Pour plus d'informations sur ce programme en Amérique du Nord, consultez le site Web HP (<http://www.hp.com/go/selfrepair>).

Riparazione da parte del cliente

Per abbreviare i tempi di riparazione e garantire una maggiore flessibilità nella sostituzione di parti difettose, i prodotti HP sono realizzati con numerosi componenti che possono essere riparati direttamente dal cliente (CSR, Customer Self Repair). Se in fase di diagnostica HP (o un centro di servizi o di assistenza HP) identifica il guasto come riparabile mediante un ricambio CSR, HP lo spedisce direttamente al cliente per la sostituzione. Vi sono due categorie di parti CSR:

- **Obbligatorie** – Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.
- **Opzionali** – Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese addizionali a seconda del tipo di garanzia previsto per il prodotto.

NOTA: alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

In base alla disponibilità e alla località geografica, le parti CSR vengono spedite con consegna entro il giorno lavorativo seguente. La consegna nel giorno stesso o entro quattro ore è offerta con un supplemento di costo solo in alcune zone. In caso di necessità si può richiedere l'assistenza telefonica di un addetto del centro di supporto tecnico HP. Nel materiale fornito con una parte di ricambio CSR, HP specifica se il cliente deve restituire dei componenti. Qualora sia richiesta la resa ad HP del componente difettoso, lo si deve spedire ad HP entro un determinato periodo di tempo, generalmente cinque (5) giorni lavorativi. Il componente difettoso deve essere restituito con la documentazione associata nell'imballo di spedizione fornito. La mancata restituzione del componente può comportare la fatturazione del ricambio da parte di HP. Nel caso di riparazione da parte del cliente, HP sostiene tutte le spese di spedizione e resa e sceglie il corriere/vettore da utilizzare.

Per ulteriori informazioni sul programma CSR di HP contattare il centro di assistenza di zona. Per il programma in Nord America fare riferimento al sito Web **HP** (<http://www.hp.com/go/selfrepair>).

Customer Self Repair

HP Produkte enthalten viele CSR-Teile (Customer Self Repair), um Reparaturzeiten zu minimieren und höhere Flexibilität beim Austausch defekter Bauteile zu ermöglichen. Wenn HP (oder ein HP Servicepartner) bei der Diagnose feststellt, dass das Produkt mithilfe eines CSR-Teils repariert werden kann, sendet Ihnen HP dieses Bauteil zum Austausch direkt zu. CSR-Teile werden in zwei Kategorien unterteilt:

- **Zwingend** – Teile, für die das Customer Self Repair-Verfahren zwingend vorgegeben ist. Wenn Sie den Austausch dieser Teile von HP vornehmen lassen, werden Ihnen die Anfahrt- und Arbeitskosten für diesen Service berechnet.
- **Optional** – Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

HINWEIS: Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

CSR-Teile werden abhängig von der Verfügbarkeit und vom Lieferziel am folgenden Geschäftstag geliefert. Für bestimmte Standorte ist eine Lieferung am selben Tag oder innerhalb von vier Stunden gegen einen Aufpreis verfügbar. Wenn Sie Hilfe benötigen, können Sie das HP technische Support Center anrufen und sich von einem Mitarbeiter per Telefon helfen lassen. Den Materialien, die mit einem CSR-Ersatzteil geliefert werden, können Sie entnehmen, ob das defekte Teil an HP zurückgeschickt werden muss. Wenn es erforderlich ist, das defekte Teil an HP zurückzuschicken, müssen Sie dies innerhalb eines vorgegebenen Zeitraums tun, in der Regel innerhalb von fünf (5) Geschäftstagen. Das defekte Teil muss mit der zugehörigen Dokumentation in der Verpackung zurückgeschickt werden, die im Lieferumfang enthalten ist. Wenn Sie das defekte Teil nicht zurückschicken, kann HP Ihnen das Ersatzteil in Rechnung stellen. Im Falle von Customer Self Repair kommt HP für alle Kosten für die Lieferung und Rücksendung auf und bestimmt den Kurier-/Frachtdienst.

Weitere Informationen über das HP Customer Self Repair Programm erhalten Sie von Ihrem Servicepartner vor Ort. Informationen über das CSR-Programm in Nordamerika finden Sie auf der HP Website unter (<http://www.hp.com/go/selfrepair>).

Reparaciones del propio cliente

Los productos de HP incluyen muchos componentes que el propio usuario puede reemplazar (*Customer Self Repair*, CSR) para minimizar el tiempo de reparación y ofrecer una mayor flexibilidad a la hora de realizar sustituciones de componentes defectuosos. Si, durante la fase de diagnóstico, HP (o los proveedores o socios de servicio de HP) identifica que una reparación puede llevarse a cabo mediante el uso de un componente CSR, HP le enviará dicho componente directamente para que realice su sustitución. Los componentes CSR se clasifican en dos categorías:

- **Obligatorio:** componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.
- **Opcional:** componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

NOTA: Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

Según la disponibilidad y la situación geográfica, los componentes CSR se enviarán para que lleguen a su destino al siguiente día laborable. Si la situación geográfica lo permite, se puede solicitar la entrega en el mismo día o en cuatro horas con un coste adicional. Si precisa asistencia técnica, puede llamar al Centro de asistencia técnica de HP y recibirá ayuda telefónica por parte de un técnico. Con el envío de materiales para la sustitución de componentes CSR, HP especificará si los componentes defectuosos deberán devolverse a HP. En aquellos casos en los que sea necesario devolver algún componente a HP, deberá hacerlo en el periodo de tiempo especificado, normalmente cinco días laborables. Los componentes defectuosos deberán devolverse con toda la documentación relacionada y con el embalaje de envío. Si no enviara el componente defectuoso requerido, HP podrá cobrarle por el de sustitución. En el caso de todas sustituciones que lleve a cabo el cliente, HP se hará cargo de todos los gastos de envío y devolución de componentes y escogerá la empresa de transporte que se utilice para dicho servicio.

Para obtener más información acerca del programa de Reparaciones del propio cliente de HP, póngase en contacto con su proveedor de servicios local. Si está interesado en el programa para Norteamérica, visite la página web de HP siguiente (<http://www.hp.com/go/selfrepair>).

Customer Self Repair

Veel onderdelen in HP producten zijn door de klant zelf te repareren, waardoor de reparatieduur tot een minimum beperkt kan blijven en de flexibiliteit in het vervangen van defecte onderdelen groter is. Deze onderdelen worden CSR-onderdelen (Customer Self Repair) genoemd. Als HP (of een HP Service Partner) bij de diagnose vaststelt dat de reparatie kan worden uitgevoerd met een CSR-onderdeel, verzendt HP dat onderdeel rechtstreeks naar u, zodat u het defecte onderdeel daarmee kunt vervangen. Er zijn twee categorieën CSR-onderdelen:

- **Verplicht:** Onderdelen waarvoor reparatie door de klant verplicht is. Als u HP verzoekt deze onderdelen voor u te vervangen, worden u voor deze service reiskosten en arbeidsloon in rekening gebracht.
- **Optioneel:** Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garanteservice voor het product.

OPMERKING: Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

Afhankelijk van de leverbaarheid en de locatie worden CSR-onderdelen verzonden voor levering op de eerstvolgende werkdag. Levering op dezelfde dag of binnen vier uur kan tegen meerkosten worden aangeboden, indien dit mogelijk is gezien de locatie. Indien assistentie gewenst is, belt u een HP Service Partner om via de telefoon technische ondersteuning te ontvangen. HP vermeldt in de documentatie bij het vervangende CSR-onderdeel of het defecte onderdeel aan HP moet worden geretourneerd. Als het defecte onderdeel aan HP moet worden teruggezonden, moet u het defecte onderdeel binnen een bepaalde periode, gewoonlijk vijf (5) werkdagen, retourneren aan HP. Het defecte onderdeel moet met de bijbehorende documentatie worden geretourneerd in het meegeleverde verpakkingsmateriaal. Als u het defecte onderdeel niet terugzendt, kan HP u voor het vervangende onderdeel kosten in rekening brengen. Bij reparatie door de klant betaalt HP alle verzendkosten voor het vervangende en geretourneerde onderdeel en kiest HP zelf welke koerier/transportonderneming hiervoor wordt gebruikt.

Neem contact op met een Service Partner voor meer informatie over het Customer Self Repair programma van HP. Informatie over Service Partners vindt u op de **HP website** (<http://www.hp.nl/services/servicepartners>).

Reparo feito pelo cliente

Os produtos da HP são projetados com muitas peças para reparo feito pelo cliente (CSR) de modo a minimizar o tempo de reparo e permitir maior flexibilidade na substituição de peças com defeito. Se, durante o período de diagnóstico, a HP (ou fornecedores/parceiros de serviço da HP) concluir que o reparo pode ser efetuado pelo uso de uma peça CSR, a peça de reposição será enviada diretamente ao cliente. Existem duas categorias de peças CSR:

- **Obrigatória** – Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.
- **Opcional** – Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

OBSERVAÇÃO: Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

Conforme a disponibilidade e o local geográfico, as peças CSR serão enviadas no primeiro dia útil após o pedido. Onde as condições geográficas permitirem, a entrega no mesmo dia ou em quatro horas pode

ser feita mediante uma taxa adicional. Se precisar de auxílio, entre em contato com o Centro de suporte técnico da HP para que um técnico o ajude por telefone. A HP especifica nos materiais fornecidos com a peça CSR de reposição se a peça com defeito deve ser devolvida à HP. Nos casos em que isso for necessário, é preciso enviar a peça com defeito à HP dentro do período determinado, normalmente cinco (5) dias úteis. A peça com defeito deve ser enviada com a documentação correspondente no material de transporte fornecido. Caso não o faça, a HP poderá cobrar a reposição. Para as peças de reparo feito pelo cliente, a HP paga todas as despesas de transporte e de devolução da peça e determina a transportadora/serviço postal a ser utilizado.

Para obter mais informações sobre o programa de reparo feito pelo cliente da HP, entre em contato com o fornecedor de serviços local. Para o programa norte-americano, visite o site da HP (<http://www.hp.com/go/selfrepair>).

顧客自己修理保証サービス

修理時間を短縮し、故障部品の交換における高い柔軟性を確保するために、HP製品には多数の顧客自己修理（CSR）部品があります。診断の際に、CSR部品を使用すれば修理ができるとHP（HPまたはHP正規保守代理店）が判断した場合、HPはその部品を直接、お客様に発送し、お客様に交換していただきます。CSR部品には以下の2通りがあります。

- **必須** - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。
- **任意** - 顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、別途費用を負担していただくことなく保証サービスを受けることができます。

注：HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

部品供給が可能な場合、地域によっては、CSR部品を翌営業日に届くように発送します。また、地域によっては、追加費用を負担いただくことにより同日または4時間以内に届くように発送することも可能な場合があります。サポートが必要なときは、HPの修理受付窓口に電話していただければ、技術者が電話でアドバイスします。交換用のCSR部品または同梱物には、故障部品をHPに返送する必要があるかどうかが表示されています。故障部品をHPに返送する必要がある場合は、指定期限内（通常は5営業日以内）に故障部品をHPに返送してください。故障部品を返送する場合は、届いた時の梱包箱に関連書類とともに入れてください。故障部品を返送しない場合、HPから部品費用が請求されます。顧客自己修理の際には、HPは送料および部品返送料を全額負担し、使用する宅配便会社や運送会社を指定します。

客户自行维修

HP 产品提供许多客户自行维修 (CSR) 部件，以尽可能缩短维修时间和在更换缺陷部件方面提供更大的灵活性。如果在诊断期间 HP（或 HP 服务提供商或服务合作伙伴）确定可以通过使用 CSR 部件完成维修，HP 将直接把该部件发送给您进行更换。有两类 CSR 部件：

- **强制性的** — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。
- **可选的** — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

注：某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

CSR 部件将在下一个工作日发运（取决于备货情况和允许的地理范围）。在允许的地理范围内，可在当天或四小时内发运，但要收取额外费用。如果需要帮助，您可以致电 HP 技术支持中心，将会有技术人员通过电话为您提供帮助。HP 会在随更换的 CSR 部件发运的材料中指明是否必须将有缺陷的部件返还给 HP。如果要求您将缺陷的部件返还给 HP，那么您必须在指定期限内（通常是五 (5) 个工作日）将缺陷部件发给 HP。有缺陷的部件必须随所提供的发运材料中的相关文件一起返还。如果未能送还有缺陷的部件，HP 可能会要求您支付更换费用。客户自行维修时，HP 将承担所有相关运输和部件返回费用，并指定快递商/承运商。

有关 HP 客户自行维修计划的详细信息，请与您当地的服务提供商联系。有关北美地区的计划，请访问 HP 网站 (<http://www.hp.com/go/selfrepair>)。

客戶自行維修

HP 產品設計了許多「客戶自行維修」(CSR) 的零件以減少維修時間，並且使得更換瑕疵零件時能有更大的彈性。如果在診斷期間 HP (或 HP 服務供應商或維修夥伴) 辨認出此項維修工作可以藉由使用 CSR 零件來完成，則 HP 將直接寄送該零件給您作更換。CSR 零件分為兩種類別：

- **強制的** — 客戶自行維修所使用的零件是強制性的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。
- **選購的** — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。

備註：某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

基於材料取得及環境允許的情況下，CSR 零件將於下一個工作日以快遞寄送。在環境的允許下當天或四小時內送達，則可能需要額外的費用。若您需要協助，可致電「HP 技術支援中心」，會有一位技術人員透過電話來協助您。不論損壞的零件是否必須退回，HP 皆會在與 CSR 替換零件一起運送的材料中註明。若要將損壞的零件退回 HP，您必須在指定的一段時間內（通常為五 (5) 個工作天），將損壞的零件寄回 HP。損壞的零件必須與寄送資料中隨附的相關技術文件一併退還。如果無法退還損壞的零件，HP 可能向您收取替換費用。針對客戶自行維修情形，HP 將負責所有運費及零件退還費用並指定使用何家快遞/貨運公司。

如需 HP 的「客戶自行維修」方案詳細資訊，請連絡您當地的服務供應商。至於北美方案，請參閱 HP 網站 (<http://www.hp.com/go/selfrepair>)。

고객 셀프 수리

HP 제품은 수리 시간을 최소화하고 결함이 있는 부품 교체 시 더욱 융통성을 발휘할 수 있도록 하기 위해 고객 셀프 수리(CSR) 부품을 다량 사용하여 설계되었습니다. 진단 기간 동안 HP(또는 HP 서비스 공급업체 또는 서비스 협력업체)에서 CSR 부품을 사용하여 수리가 가능하다고 판단되면 HP는 해당 부품을 바로 사용자에게 보내어 사용자가 교체할 수 있도록 합니다. CSR 부품에는 두 가지 종류가 있습니다.

- **고객 셀프 수리가 의무 사항인 필수 부품.** 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.
- **고객 셀프 수리가 선택 사항인 부품.** 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

참고: 일부 HP 부품은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 만족스러운 고객 보증을 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다. 이러한 부품들은 Illustrated Parts Catalog에 "No"라고 표시되어 있습니다.

CSR 부품은 재고 상태와 지리적 조건이 허용하는 경우 다음 영업일 납품이 가능하도록 배송이 이루어집니다. 지리적 조건이 허용하는 경우 추가 비용이 청구되는 조건으로 당일 또는 4시간 배송이 가능할 수도 있습니다. 도움이 필요하시면 HP 기술 지원 센터로 전화하십시오. 전문 기술자가 전화로 도움을 줄 것입니다. HP는 결함이 발생한 부품을 HP로 반환해야 하는지 여부를 CSR 교체 부품과 함께 배송된 자료에 지정합니다. 결함이 발생한 부품을 HP로 반환해야 하는 경우에는 지정된 기간 내(통상 영업일 기준 5일)에 HP로 반환해야 합니다. 이 때 결함이 발생한 부품은 제공된 포장 재료에 넣어 관련 설명서와 함께 반환해야 합니다. 결함이 발생한 부품을 반환하지 않는 경우 HP가 교체 부품에 대해 비용을 청구할 수 있습니다. 고객 셀프 수리의 경우, HP는 모든 운송 및 부품 반환 비용을 부담하며 이용할 운송업체 및 택배 서비스를 결정합니다.

HP 고객 셀프 수리 프로그램에 대한 자세한 내용은 가까운 서비스 제공업체에 문의하십시오. 북미 지역의 프로그램에 대해서는 HP 웹 사이트(<http://www.hp.com/go/selfrepair>)를 참조하십시오.

Acronyms and abbreviations

ABEND

abnormal end

ACU

Array Configuration Utility

AMP

Advanced Memory Protection

ASR

Automatic Server Recovery

DDR

double data rate

IEC

International Electrotechnical Commission

iLO 2

Integrated Lights-Out 2

IML

Integrated Management Log

NEMA

National Electrical Manufacturers Association

NFPA

National Fire Protection Association

NIC

network interface controller

NVRAM

non-volatile memory

ORCA

Option ROM Configuration for Arrays

PCI Express

peripheral component interconnect express

PCI-X

peripheral component interconnect extended

PDU

power distribution unit

POST

Power-On Self Test

PPM

processor power module

PSP

ProLiant Support Pack

RBSU

ROM-Based Setup Utility

SAS

serial attached SCSI

SATA

serial ATA

SDRAM

synchronous dynamic RAM

SIM

Systems Insight Manager

TMRA

recommended ambient operating temperature

UID

unit identification

USB

universal serial bus

VCA

Version Control Agent

WOL

Wake-on LAN

Index

A

- access panel 27
- ACU (Array Configuration Utility) 81
- ADU (Array Diagnostic Utility) 84
- Advanced Memory Protection mode, selecting 54
- airflow requirements 30
- Altiris Deployment Solution 81
- Altiris eXpress Deployment Server 81
- array configuration 81
- Array Configuration Utility (ACU) 81
- Array Diagnostic Utility (ADU) 84
- ASR (Automatic Server Recovery) 82, 120
- authorized reseller 112
- Automatic Server Recovery (ASR) 82, 120
- Autorun menu 79

B

- batteries, replacing 87
- battery 13, 108
- bezel, attaching 74
- bezel, front 25
- bezel, rack 26, 69
- bezel, removing 25, 26
- bezel, tower 23
- BIOS Serial Console 80
- BIOS upgrade 82
- blue screen event 13
- BSMI notice 107
- buttons 7

C

- cable management arm 72
- cables 90, 106
- cabling 76, 77
- cabling, storage system 76
- Canadian notice 106
- Care Pack 28, 86
- casters, removing 68
- cautions 88
- Change Control 86
- component identification 7, 13

- components 7
- configuration of system 36, 79
- configuration tools 79
- connection problems 90
- connectors 7, 77
- contacting HP 112
- crash dump analysis 13
- creating a disk image 81
- CSR (customer self repair) 113
- customer self repair 113

D

- Declaration of Conformity 105
- deployment software 81
- diagnosing problems 90
- diagnostic tools 79, 81, 82, 84
- diagnostics utility 84
- DIMM slot locations 20
- DIMM slots 20
- DIMMs 44
- DIMMs, single- and dual-rank 44
- diskette image creation 81
- drive LEDs 16
- drivers 85

E

- electrical grounding requirements 30
- electrostatic discharge 103
- environmental requirements 29
- environmental specifications 110
- European Union notice 106
- expansion boards 64, 65, 66
- expansion slot covers, removing 66
- extending server from rack 23

F

- fan LED 22
- fans 14, 21, 63
- fans, installing 63
- features 7
- Federal Communications Commission (FCC)
 - notice 104, 105, 106

flash ROM 82
flowcharts 91, 92, 97, 98
front panel buttons 8
front panel components 7
front panel LEDs 8

G

general diagnosis flowchart 92
grounding methods 103
grounding requirements 30

H

hard drive LEDs 16
hard drives 16
hard drives, determining status of 16
hard drives, installing 54, 55
hardware options 38
hardware options installation 32, 38
health driver 82
health LEDs 13
hot-plug power supply 20
HP Insight Diagnostics 84
HP ProLiant Essentials Foundation Pack 36, 83
HP ProLiant Essentials Rapid Deployment Pack 81
HP Systems Insight Manager, overview 83
HP Technical Support 112

I

identification number, server 104
iLO (Integrated Lights-Out) 82
IML (Integrated Management Log) 84
Important Safety Information document 87
Insight Diagnostics 84
installation services 28
installation, server options 32, 38
installing operating system 36
Instant Support Enterprise Edition 84
Integrated Lights-Out (iLO) 82
Integrated Management Log (IML) 84
internal health LED 13

J

Japanese notice 107

K

Korean notices 108

L

laser devices 108
LED, fan 22
LEDs 7, 13, 16
LEDs, hard drive 16
LEDs, SAS hard drive 16
LEDs, SATA hard drive 16
loose connections 90

M

Management Agents 83
management tools 82
memory 43, 45, 46, 47, 48, 51
memory board LEDs and components 17
memory boards, removing and installing 48, 51
memory dump 13
memory slot LEDs 17
memory, configuring 53, 54, 80
memory, mirrored 46, 81
memory, online spare 45
memory, RAID 47
memory, single- and dual-rank DIMMs 44

N

Natural Language Search Assistant 86
NIC (network interface controller) 120
NMI switch 13

O

Online ROM Flash Component Utility 85
operating system crash 13
operating systems 36, 85
optical device 57
optimum environment 29
options installation 32, 38
ORCA (Option ROM Configuration for Arrays) 36
OS boot problems flowchart 98

P

phone numbers 112
POST memory test 53
POST problems flowchart 97
power cord 88, 109
power distribution unit 30
Power On/Standby button 23
power requirements 30
power supplies 62
power supply blank 62

- power supply LEDs 20
- powering down 23
- powering up 23
- preparation procedures 90
- problem diagnosis 87
- processors 38
- ProLiant Support Packs 85
- PSPs, overview 85

R

- rack installation 28, 34
- rack resources 29
- rack stability 88
- rack warnings 31, 88
- rack-to-tower conversion 71
- RAID configuration 36
- RBSU (ROM-Based Setup Utility) 53, 80
- rear components 9
- rear panel buttons 10
- rear panel components 9
- rear panel LEDs 10
- redundant ROM 83
- registering the server 37
- regulatory compliance notices 104, 106
- remote support and analysis tools 84
- removing server from rack 72
- required information 112
- requirements, airflow 29
- requirements, power 30
- requirements, space 29
- requirements, temperature 30
- resetting the system 13
- ROM redundancy 83
- ROM-Based Diagnostics test 54
- ROM-Based Setup Utility (RBSU) 80
- ROMPaq utility 82, 83

S

- safety considerations 87
- safety information 83
- SAS cabling 77
- SAS drives 16, 54, 55, 56
- SAS hard drive LEDs 16
- SATA hard drive 16
- scripted installation 79
- serial number 81
- series number 104
- server features and options 38
- server rails, removing 73
- server, installation 34

- service notifications 90
- site requirements 30
- SmartStart autorun menu 79
- SmartStart Scripting Toolkit 79
- SmartStart software 36
- SmartStart, overview 79
- space requirements 29
- specifications 110
- start diagnosis flowchart 91
- static electricity 103
- storage system, cabling 76
- StorageWorks Library and Tape Tools (L&TT) 82
- support 84, 112
- support packs 79
- supported operating systems 85
- symbols on equipment 88
- system board battery 108
- system board LEDs 14
- system maintenance switch 12, 13
- Systems Insight Manager 83

T

- Taiwan battery recycling notice 109
- tape drive blank 58
- tape drives 58
- technical support 112
- telephone numbers 112
- temperature requirements 30
- tower bezel, installing 74
- tower bezel, removing 25
- tower cover, installing 73
- tower cover, removing 69
- tower server, setting up 33
- tower to rack conversion 67
- troubleshooting 87

U

- UID LEDs 23
- updating the system ROM 83
- USB support 83
- utilities 79, 80, 81, 82, 83, 84
- utilities, deployment 79, 80, 81

V

- ventilation 29
- video connector 7, 77

W

- warnings 88