

**INSTRUCTION MANUAL  
P8315 DUMMY CAMERA WITH BLINKING LED**

**GEBRAUCHSANWEISUNG  
P8315 DUMMY KAMERA MIT BLINKENDER LED**



INSTRUCTION MANUAL  
P8315 DUMMY CAMERA WITH  
BLINKING LED

-Deterrence against intruders-

Congratulations on your purchase of the Dummy Camera with Blinking LED.

This product was designed to protect you against burglars and intruders. Due to the striking similarity to a real camera, with real lens, integrated video cable, flashing LED light and the pan-tilt mechanism, the intruders think that all events around your home or business are filmed - like a highly secure bank. The video cable is fixed at the camera bottom, so the installation can be carried out easily. You don't have to spend a lot of money for security systems. Protect your property in a cheap and effective way with the Dummy Camera. Leave your home or business with a safe feeling.

#### INSTALLATION

After unpacking the camera and the wall mount, install 2 X AA batteries. Remove the screw holding the mount to the camera body. The inner housing will slide out of the outer housing. Install batteries according to diagram in battery holder. Re-assemble unit. Choose a suitable location for the camera at the entrance or other sensitive area. The unit should be shielded from direct rainfall. Using the mount as a template, mark and drill two small holes into the wall. Insert the plastic anchors into the holes. Using your screwdriver finish the installation with the two provided screws.

#### POSITION

The Dummy Camera with Blinking LED is equipped with a pan-tilt mechanism. To adjust the slewing range, loosen the screw holding the pan-tilt arm to the camera body. Rotate the camera until the angle is correct. Re-tighten the screw. To adjust the inclination, firmly move the body of the camera until the angle is correct. If the camera is too loose on the arm, tighten the screw.

#### MAINTENANCE

Replace batteries as necessary.

P3 INTERNATIONAL CORPORATION  
LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your unit, or if your unit requires repair please contact:

P3 INTERNATIONAL CORPORATION  
TECHNICAL SUPPORT  
71 West 23<sup>rd</sup> Street  
Suite 1201  
New York, NY 10010-4102  
**Tel: 212-741-7289**  
Fax: 212-741-2288

GEBRAUCHSANWEISUNG  
P8315 DUMMY KAMERA MIT  
BLINKENDER LED

- Abschreckung gegen ungebetene Besucher -

Herzlichen Glückwunsch zum Kauf Ihrer Kamera Attrappe mit blinkender LED.

Diese Produkt soll Sie gegen Einbrecher und ungebetene Besucher schützen. Durch die täuschend echte Nachahmung einer blinkenden Kamera mit Wandhalterung und integriertem Videokabel denken ungebetene Besucher, daß alle Vorgänge um ihr Haus gefilmt werden - wie im Schaltraum einer hochgesicherten Bank. Das Videokabel ist fest am Kamerafuß betestigt, somit entfällt eine komplizierte Montage.

Sie müssen kein Vermögen für Sicherheits-Systeme ausgeben. Schützen Sie Ihr Hab und Gut preiswert und wirksam mit dieser Kamera-Attrappe. Verlassen Sie Ihr Haus mit sicherem Gefühl.

#### MONTAGE

Nachdem Sie die Kamera Attrappe mit Wandhalterung aus der Verpackung entnommen haben, müssen Sie zwei AA Batterien einlegen. Lockern Sie dazu die Schraube an der Unterseite des Gehäuses. Das innere Gehäuse lässt sich nun ohne Mühe herauschieben. Legen Sie nun die Batterien mit der richtigen Polarität ein. Schieben Sie das Innengehäuse wieder ein und befestigen Sie die Schraube an der Unterseite. Nun suchen Sie sich einen geeigneten Platz im Eingangsbereich oder an einer anderen einbruchgefährdeten Stelle Ihres Hauses für die Montage aus. Die Kamera Attrappe sollte nach Möglichkeit an einer trockenen Stelle befestigt werden. Zwei Löcher für die Aufnahme der mitgelieferten Dübel müssen lediglich in die Wand gebohrt werden.

Nachdem sich die Dübel in der Wand befinden, setzt man den Wandhalter mit den Schraublöchern darüber, um die jeweils mitgelieferten Schrauben durch das Schaubloch des Wandhalters in den Dübel zu stecken. Mit einem Schraubenzieher werden nun die Schrauben jeweils bis zum Anschlag

festgedreht.  
Somit ist die Kamera Attrappe inkl. Halter an der Wand befestigt.

#### AUSRICHTUNG

Die Kamera-Attrappe hat einen Schwenk-/Neige-Wandhalter.

Um die richtige Position im Schwenkbereich einzustellen, wird die vertikale Kreuzschraube im Gehäuse soweit gelöst, bis das Gehäuse schwenkbar ist. Nachdem die richtige Stellung fixiert ist, wird die Kreuzschraube wieder fest angezogen. Die Neigung wird nach dem Lösen der horizontalen Kreuzschraube eingestellt und danach durch das Festdrehen derselben fixiert.

Nun ist die P3 Kamera-Attrappe richtig ausgerichtet.

#### Wartung

Wenn die rote LED nicht mehr blinkt, müssen die Batterien ausgewechselt werden (einmal jährlich).