


Component Checklist



HARDWARE			
Security Allen Key	Security Set Screw (x2)	Standard Set Screw (x2)	
			
			Coach Bolt (x4)

Tools Required:

- Power Drill
- 4.5mm (0.18") Drill Bit
- 10mm (3/8") Socket Wrench Shifter
- Phillips Head Screw Driver

IMPORTANT INFORMATION:


- ! **IMPORTANT - Install Telehook Ceiling Mount as per installation instruction.**
- ! This product supports a maximum load of 100kg (220lbs.).
- ! The manufacturer accepts no responsibility for incorrect installation.

Step 1. Check Components


Check you have received all parts against the component checklist and hardware above.

Step 2. Ceiling Mount

Timber Stud




Masonry




TIP: Use Mount as a drilling template.

IMPORTANT! Any structural elements must be capable of supporting the combined weight of all the equipment and devices being mounted. If in doubt, consult a structural engineer.


Step 3.



Step 4.



Step 5.



Installation Complete