



Wi-NR

SURE SHOT

RIFLE for Wii™

LIFE-LIKE ACCESSORY
FOR Wii™ SHOOTER GAMES



Blaster Mode



Sawed-off Rifle Mode



Rifle Mode

Finally a realistic, surefire accessory that brings even more fun to Wii™ shooting games. The Wii™ Sure Shot controller accessory gives you realistic shooting action and improved aim. Just insert your Wii Remote™ and Nunchuk and you are ready to do battle.

- Features a removable stock and barrel for use in three different modes
- Contains a real functioning trigger for operating the Wii Remote
- Authentic size and feel with high quality construction
- Easy to use and lightweight
- Works with numerous Wii shooting and hunting games
- Uses a distinct toy gun white color and orange tip for safety

The Wii Sure Shot requires a Wii Remote and Nunchuk to play (not included).

	Quantity	Width	Height	Depth	Weight	UPC Barcode
Packaging	1	18	9	3	2 lb	656777 00013 4
Master	10	18.5	19	16	20 lbs	10656777000131