

Parts of WCR682SS-2

Item	Parts No.	Description	Qty
1	DG11-4	DRY FILTER	1
2	DG2-11	POWER CORD	1
3	DG13-1	DRIP TRAY	1
4	DG13-24	DG13-24	1
5	DG12-22	ANTI-VIBRATING BLOCK	1
6	DG1-76	COMPRESSOR	1
7	DG17-25	COMPRESSOR GROUNDING LINE	1
8	DG17-93	COMPRESSOR GROUNDING LINE	1
9	DG12-112	SEAL PIPE	2
10	DG22-302	POWER BOARD	1
11	DG3-1051.2	PCB	1
12	DG6-1003.1	TRANSFORMER	1
13		CABINET	1
14	DG22-1062	LEFT TOP HINGE	1
15	DG22-1096	S/S TOP INSERT HOLE	3
16	DG3-1067W	LED BOARD	1
17	DG13-1079	MAIN BOARD COVER	1
18	DG22-1063	RIGHT TOP HINGE	1
19	DG22-1064	DOOR HINGE	1
20	DG12-59	EVAPORATOR	1
21	DG8-8-R	DEFROST SENSOR	1
22	DG7-3.1	UPPER FAN	1
23	DG22-1185	AIR-DUCT BOARD A	1
24	DG13-247	FAN WATER-BLOCK BOARD	1
25	DG19-6	FAN COVER	2
26	DG8-8-W	INSIDE SENSOR (UP)	1
27	DG13-198	SENSOR COVER	2
28	DG13-1063	CHARCOAL FILTER	1
29	DG22-1020.1	SHELF ROLLER	14
30	DG15-501.1	TOP SHELF	6
31	DG13-1013.6	S/S FRONT INSERT INCLUDING CONTROL PANEL FILM	1
32		GASKET	1
33	DG23-1071.7	DOOR	1
34	DG14-506	LOCK	1
35	DG14-1014	LOWER DOOR HINGE AXIS	1
36	DG14-1029.7	HANDLE	1
37	DG15-501	SHELF	8
38	DG15-1002	WOOD SHELF (BOTTOM)	1
39	DG15-502	SHELF	1
40	DG13-7	SHELF SUPPORT	2
41	DG22-1021	12-INCH ROLLER	1
42	DG8-8-Y	SENSOR(BOTTOM)	1
43	DG22-1009.1	BOTTOM GRILLE	1
44	DG7-3.9-Y	FAN(BOTTOM)	1
45	DG18-63	EVAPORATOR FOAM	2
46	DG14-508.1	RIGHT LOWER HINGE	1
47	DG13-6.1	LEG CABINET	4
48	DG22-240	SUPPORT BRACKET OF FRONT LEG	1
49	DG12-3	CONDENSOR	1
50	DG12-1005	SUCTION PIPE ASSEMBLY	1
51	DG22-254	COMPRESSOR BRACKET	1
52	DG7-23	OUTSIDE FAN	1
53	DG14-56	OUTSIDE FAN BRACKET	2
54	DG19-3	FAN COVER	1
55	FL-107	DRAIN PIPE	1

