

OBC32SS Outdoor Refrigerator - Spare Parts List

Item No.	Material Code	Description
1	1861701700	Handle
2	1871017600	Door
3	1853106000	Wiring harness for Temp.display
4	1864015400	Gasket
6	1856200400	Lamp
7	1849735400	Lampshade
8	1800500900	Shelves
9	1800500500	Curve Shelves
10	1800501001	Flattened Basket
11	1800500800	Large Basket
12	1856200300	Lampholder
13	1880026201	Evaporator
14	1864400201	Top hinge cover
15	1860413300	Top hinge
17	1864620000	Foot
18	1864802300	Water Drip Tray
19	1858422000	Compressor
19.1	1858460700	Starting Relay
19.2	1858450900	Overload
20	1860416300	Bottom hinge
21	1880007800	Drier
23	1858203100	Fan
25	1880013702	Condenser
27	1854602200	Mechanical Thermostat
30	1824706304	Ballast
32	1853114400	Power cord
36	1861751100	Back grid
38	1845744300	Bottom Grille

OBC32SS Outdoor Refrigerator - Explosion View

