



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSS EQ1208. You'll find the answers to all your questions on the BOSS EQ1208 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BOSS EQ1208
User guide BOSS EQ1208
Operating instructions BOSS EQ1208
Instructions for use BOSS EQ1208
Instruction manual BOSS EQ1208



EQ1208 *4-Band Graphic Equalizer with Subwoofer Output*

**Congratulations on your
purchase of a BOSS Equalizer.**

It has been designed, engineered
and manufactured to bring you
the highest level of performance
and quality, and will afford you
years of listening pleasure.

Thank you for making
BOSS your choice for car audio
entertainment!

USER'S MANUAL

| page | CONTENTS |
|----------|-----------------------------------|
| 2 | How an equalizer is used |
| 3 | Front panel controls and features |
| 4 | Top panel controls and features |
| 5 | Installation |
| 5 | Mounting the equalizer |
| 6 | Audio connections |
| 7 | Power connection |
| 8 | Specifications |

EQ1208 User's Manual - page 1



[Your user manual](#)
[BOSS EQ1208](#)

Manual abstract:

Install the unit securely, according to the diagram below. Vehicle dashboard Angle brackets Figure 1 Mounting the equalizer Turning on the power The EQ1208 has internal ON/OFF circuitry which responds to turning ON or OFF the head unit of your car audio system. This requires that your head unit have a remote turn-on lead available on the rear panel (which most head units have). With this convenient remote turn-on/off feature, you never have to worry about turning off the power to the equalizer when you shut off the audio system. EQ1208 User's Manual - page 5 English Español Português Français Deutsch Audio connections Review the diagrams on the next two pages and connect the unit as shown. SUBWOOFER OUTPUTS OUTPUTS FRONT REAR INPUTS CD/DVD RADIO R L R L R L R L R L To SUBWOOFER CHANNEL Audio Inputs of amplifier To FRONT Audio Inputs of AMPLIFIER To REAR Audio Inputs of AMPLIFIER Figure 2 Audio input and output wiring To OUTPUTS of RADIO (head unit) To OUTPUTS of CD or DVD PLAYER EQ1208 User's Manual - page 6 English Español Português Français Deutsch Power connections Please note that this equalizer contains an internal ON/OFF switch, which is activated when the head unit is turned on. For this reason, in order to use this equalizer, your head unit must have a remote-turn on lead. REMOTE +12V GROUND Chassis ground point FUSE Battery to REMOTE TURN-ON terminal of head unit Figure 3 Power connections EQ1208 User's Manual - page 7 Specifications EQ1208 4-Band Graphic Equalizer with Subwoofer Output EQ center frequencies 40Hz · 150Hz · 1kHz · 20kHz Equalization range +/- 18dB (boost/cut) Frequency response 20Hz-20kHz Subwoofer crossover freq. variable 30-250HzHz Signal-to-Noise Ratio 105dB EQ THD less than 0.05% Subwoofer channel THD less than 0.05% Channel separation 60dB Power supply 10-16V negative ground Output voltage 7V Dimensions (W x D x H) 6.8" x 4.25" x 1.1" All specifications subject to change without notice..



[Your user manual](#)
[BOSS EQ1208](#)