HABEY

Enabling Unlimited Embedded Computing

BIS-6564

Quick Setup Guide

Packing List

Description	QTY
BIS-6564	1
Power Cable	1
Power Adaptor	1
HDD Mounting Bracket	1
Rack Mount Ears	2
Rack Mount Screws	4
Drive Mounting Screws	4

Safety Warning:
The use and installation of this system should only be performed by professionals. Improper installation of any electronic device or electrical component can result in serious injury or death. Please make sure that all safety precautions are taken into account.

Install Guide

Step 1 - Inspect Contents

Unpack all package contents and inspect each component. Make sure all included parts and accessories are present.

Step 2 - Remove Top Cover

Using a phillips head screw driver, remove the four screws on the sides of the enclosure.

Step 3 - Install RAM

Align notch in memory circuit with corresponding guide on the memory slot. Insert the memory circut at a 45° angle and press the circuit flat and secure it to the memory slot with an audible click on each side of the memory slot.

Step 4 - Install 2.5" HDD

Mount the HDD onto the bracket and then fix it with 4 screws.

Then mount the HDD bracket back onto the backplane and fix it.

Place the cover as illustrated in the picture and connect SATA cable to HDD marked in lines.

Step 5 - Rack Mounting

Locate the included rack mount brackets (ears). Mount the ears on the bottom cover by securing the ears to the side of the enclosure with the included screws.

## Step 6 - Hardware Installation Complete

Your system is now ready. Connect the power cable to a power source and press the power button on the front of the system.

Input / Output

Rear Panel

COM — S/PDIF — LAN — 1x USB2.0
Power
2x ANT
HDMI — VGA — 2x USB2.0 — Audio

Dimensions

224mm/ 9.6"
156mm/ 6.1"
54mm/ 2.1"

Enabling Unlimited Embedded Computing

21015 Commerce Pointe Drive, Walnut, CA 91789
www. habeyusa.com