

NWZ-W273WHT

White 4 GB Walkman® Sports MP3 Player

Add music to any sport with the wire-free, all-in-one music player you can wear and experience freedom of movement. Plus enjoy 3-minute quick charging and drag-and-drop ease from iTunes® or Windows® Media Player. There's also 4GB of built-in memory and pristine audio quality with deep bass.



Bullets

- Cordless, one-piece wearable sports music player
- Waterproof³ design for worry-free workouts, even swimming
- 3-min quick charge = up to 60-min of battery life¹
- Drag & drop from iTunes® or Windows® Media Player
- Compact design with 4 GB internal memory²
- Easy navigation of songs & folders
- Enjoy playlist compatibility & shuffle mode
- Crystal clear sound and deep bass
- ZAPPIN® search plays about 4 or 15 second music clips
- USB dock, S/M/L/LL ear-buds and adjustment band included

Features

Wearable and Wire-free

This one-piece music player's unique design is lightweight, ideal for sports and active lifestyles. It allows you to be wire-free, hands-free, and without distraction whether you're working out at the gym, playing outdoors or even swimming³.

Waterproof³ to 2M

The NWZ-W273 series design is waterproof³ up to 2 meters depth. That means you can swim with it. To ensure a good fit before swimming see enclosed details. Do not use in salt water as it has corrosive effects.

Quick charge battery

Use the included USB dock to get up to 60 minutes of use on just 3 minutes of charge¹. With an impressive total battery life of up to 8 hours on a full charge¹, the NWZ-W273 is ready when you are.

Drag, drop and go

With a Walkman® player, you are never tied to just one music service. Just drag and drop files from iTunes® or Windows® Media Player and enjoy. Multi-format playback also lets you play MP3, WMA, AAC or L-PCM music files; now that's freedom.

Storage Capacity

The NWZ-W273 is compact in size but can store hours of music thanks to the internal 4 GB memory².

Navigate your song library

Searching through your music is simple with the multi-function playback buttons. A quick tap changes songs and a tap and hold changes folders while in all play mode. In playlist mode a quick tap changes songs and a tap and hold changes the playlist.

Playlist compatible

Create your favorite playlists in iTunes® or Windows® Media Player and drag them to the NWZ-W273 player. Use shuffle mode to mix it up.

High Quality Sound

The integrated 13.5 mm EX headphone drivers deliver great sound quality with deep bass.

Music to match your pace

Find the perfect music for the moment using the ZAPPIN® search feature, allowing you to easily navigate through your song collection by playing back main melodies.

Open, charge and listen

Everything you need is in the box including USB dock, small, medium, large and large-long ear buds.

Specifications

| Audio | |
|----------------------|--|
| Audio Power Output | 5 + 5mW |
| Format(s) Supported | MP3 / WMA / AAC-LC / L-PCM |
| Frequency Response | 20 to 20,000 Hz (when playing data file, single signal measurement) |
| Audio Features | |
| Play Mode | All Play / Shuffle / Playlist |
| Convenience Features | |
| Search Features | ZAPPIN®(Short or Long 3 min Quick charge Automatic Volume Limiter System Playback options |
| Hardware | |
| Headphone Type | EX headphones with closed, dynamic 13.5mm dome driver |
| Interface | Hi-Speed USB (USB 2.0 compliant) |

| System Requirements | <p>IBM PC/AT compatible computer preinstalled with the following Windows operating systems¹:</p> <p>Windows® XP Home Edition² (Service Pack 3 or later) Windows® XP Professional² (Service Pack 3 or later) Windows Vista® Home Basic (Service Pack 2 or later) Windows Vista® Home Premium (Service Pack 2 or later) Windows Vista® Business (Service Pack 2 or later) Windows Vista® Ultimate (Service Pack 2 or later) Windows® 7 Starter (Service Pack 1 or later) Windows® 7 Home Basic (Service Pack 1 or later) Windows® 7 Home Premium (Service Pack 1 or later) Windows® 7 Professional (Service Pack 1 or later) Windows® 7 Ultimate (Service Pack 1 or later) Windows® 8 Windows® 8 Pro Mac OS X v10.6 or later Not supported by OSs other than above.</p> <p>Compatibility mode for Windows XP (included with Windows Vista and Windows 7) is not supported.</p> <p>¹- Excluding OS Versions not supported by Microsoft. ² - Excluding 64-bit OS versions.</p> <p>CPU: 1 GHz processor (2.6 GHz recommended for video playback) RAM: 1 GB or more (2 GB RAM required for Windows 8 64-bit) Hard Disk Drive / Solid State Drive: 600 MB or more of available space Internet Explorer 7 or later Internet connection (for Gracenote® MusicID® service, podcast features, Store access, or online help).</p> <p>We do not guarantee operation for all computers even if they meet the above System Requirements.</p> <p>Not supported by the following environments Personally constructed computers or operating systems An environment that is an upgrade of the original manufacturer-installed operating system Multi-boot environment</p> | | | | | | | | | | | |
|--------------------------------|--|--------|--|-------------|------|--------------------------------|-------------------------------|-------|--|---------------------------|---|-------------------|
| | <table border="1"> <thead> <tr> <th colspan="2">Memory</th> </tr> </thead> <tbody> <tr> <td>Memory Size</td> <td>4 GB</td> </tr> <tr> <td>User Memory Capacity (Approx.)</td> <td>3.54 GB (3,803,414,528 bytes)</td> </tr> <tr> <th colspan="2">Power</th> </tr> <tr> <td>Battery Charging (Approx)</td> <td>USB-based: 1.5 Hrs (full charge) 3 Minutes (approx. 60 minutes playback)¹</td> </tr> <tr> <td>Battery Indicator</td> <td>LED Battery Life Indicator (Green/Orange/Red)</td> </tr> </tbody> </table> | Memory | | Memory Size | 4 GB | User Memory Capacity (Approx.) | 3.54 GB (3,803,414,528 bytes) | Power | | Battery Charging (Approx) | USB-based: 1.5 Hrs (full charge) 3 Minutes (approx. 60 minutes playback) ¹ | Battery Indicator |
| Memory | | | | | | | | | | | | |
| Memory Size | 4 GB | | | | | | | | | | | |
| User Memory Capacity (Approx.) | 3.54 GB (3,803,414,528 bytes) | | | | | | | | | | | |
| Power | | | | | | | | | | | | |
| Battery Charging (Approx) | USB-based: 1.5 Hrs (full charge) 3 Minutes (approx. 60 minutes playback) ¹ | | | | | | | | | | | |
| Battery Indicator | LED Battery Life Indicator (Green/Orange/Red) | | | | | | | | | | | |

| | |
|---------------------------------|--|
| Battery Life (Approx) | MP3 @ 128 kbps = 8 Hrs. Linear PCM @ 1411 kbps = 7 Hrs. |
| Power Type | Built-in Rechargeable Li-ion Battery |
| Weights and Measurements | |
| Weight (Approx.) | 29g (1.1 oz) |
| Accessories | |
| Supplied Accessories | Earbuds (Size S/M/L) Supplied in pairs. USB Cradle (1) Adjustment band (1) Quick Start Guide Notes on Water Resistant Specifications |



1. Actual battery life may vary based on product settings, usage patterns and environmental conditions. Battery capacity decreases over time and use.

2. 1 GB equals 1 billion bytes, a portion of which is used for data management functions.

3. Waterproof certified to the IPX8 standards, submersible up to 2 meters. Salt water is corrosive, do not use in salt water conditions.

© 2013 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. Sony, Walkman, ZAPPIN and their respective logos are trademarks of Sony. iTunes is a trademark of Apple Inc. Windows and Internet Explorer are trademarks of Microsoft Corporation. All other trademarks are trademarks of their respective owners.

Updated: April 18, 2013