

Philips Sonicare e-Series
Standard sonic toothbrush
heads

2-pack

HX7022/64



Removes up to 2X more plaque*

* vs a manual toothbrush

The brush heads for the Sonicare e-Series electric toothbrush are visibly angled for better reach within the mouth, providing a thorough every day clean, while massaging and stimulating gums.

Designed to optimize performance

- Reminder bristles ensure you are getting an effective clean

A brush head that fits multiple handles

- Screw-on brush head for our original Sonicare handles

Easy to maneuver to focus on hard-to-reach areas

- Unique angled neck helps you reach back teeth

PHILIPS
sonicare

sense and simplicity

Specifications

Technical specifications

- Operating time: For optimal results, a new brush head is recommended every three months.

Ease of use

- Suitable for these models: Elite, Essence, CleanCare, Xtreme, Advance

Highlights

Reminder bristles

Reminder bristles let's you know when to replace the brush head. After three months of normal use bristles exhibit fatigue, and brush heads are less effective. Replace your brush heads every 3 months.

Screw-on brush head

Screw-on brush head that will fit our original Sonicare handles

Unique angled neck



The slim angled neck enables you to easily maneuver the toothbrush head, particularly in hard-to-reach areas to remove plaque.

