

RM-LVR1

Live View Remote for Action Cam

Watch and control your Action Cam from your wrist via Wi-Fi with Sony's Live-View Remote. Waterproof¹ and shockproof for all the action in rugged and water activities. Equipped with a color LCD screen and large buttons, viewing and controlling your Action Cam is easy and convenient.



Key Features

View and Control your Action Cam from your wrist

The RM-LVR1 is wristwatch-style remote controller with color LCD screen which allows remote camera control and viewing of your Action Cam¹ all from your wrist.

Rugged and durable waterproof and shockproof build

Built to withstand the ruggedness of your adventures, the RM-LVR1 is waterproof down to 16feet (3meters) and is shockproof. Perfect for any sport including surfing and snowboarding.

Compatible with range of NFC/Wi-Fi enabled devices

Compatible with other Sony NFC/Wi-Fi devices including assorted NEX, Alpha and Music Cams.

Long Lasting Battery

Approx 240 minutes of continuous operating time

Specifications

| | |
|-----------------------|------------------|
| Waterproof | Yes (down to 3m) |
| Wi-Fi | Yes (5m) |
| Operating Temperature | +14°F to +104°F |

1. Wi-Fi does not work underwater though watch is waterproof; Wi-Fi range varies due to environment, but is generally spec'd at 5m

2. Waterproof down to 16feet (3m); not to be submerged longer than 30min at a time

© 2013 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. Sony and the Sony make.believe logo are trademarks of Sony. All other trademarks are trademarks of their respective owners. Features and specifications subject to change without notice. / UPC:027242873544 / Updated: December 9, 2013