

MP3 and Portable Media Players

Green Text with Light Green Background indicates the adapter tip is included with product.

Red Text with Clear Background indicates the adapter tip is sold separately.

N/A indicates that the adapter is not available.

NC (Not Compatible): The MP1550 is not compatible with devices that require more than 800mA. Therefore, it is important that the MP1550 is not used to power or charge these phones. The TekCharge MP1860A, however, is ideal for these phones.

Apple

Model	MP1550	MP1580	MP1800	MP1860A	MP2250	Additional Information
1G iPod, 2G iPod, 3G iPod	N/A	N/A	N/A	N/A	N/A	
iPod mini, 4G iPod, iPod photo, 5G iPod	iPod USB Cable	iPod USB Cable	iPod USB Cable	iPod USB Cable	MP3300-16	
iPod shuffle, iPod shuffle 2G	iPod USB Cable	iPod USB Cable	iPod USB Cable	iPod USB Cable	MP3300-16	
iPod classic 80G/120G/160G	iPod USB Cable	iPod USB Cable	iPod USB Cable	iPod USB Cable	MP3300-16	
nano, nano 2G, nano 3G, nano 4G, nano 5G, nano 6G	iPod USB Cable	iPod USB Cable	iPod USB Cable	iPod USB Cable	MP3300-16	
iPod touch, iPod touch 2G, iPod touch 3G	iPod USB Cable	iPod USB Cable	iPod USB Cable	iPod USB Cable	MP3300-16	
iPhone, iPhone 3G, iPhone 3G S, iPhone 4	iPod USB Cable	iPod USB Cable	iPod USB Cable	iPod USB Cable	MP3300-16	
iPad, iPad 2	*NC*	iPod USB Cable	iPod USB Cable	iPod USB Cable	MP3300-16	*Compatible for MP1800 batteries purchased after 12/1/2009*

Archos

Model	MP1550	MP1580	MP1800	MP1860A	MP2250	Additional Information
Archos: 104, 105, 204	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	
Archos: 404, 404 Camcorder, 405, 504	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	
Archos: 604, 604 WiFi, 605 WiFi	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	
Archos 5, 7	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	
Archos Vision: 10b, 14, 15, 15b, 18, 18b, 18c, 18d	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	
Archos Vision: 20b, 20c, 20d, 24, 24b, 24c, 24d	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	
Archos Vision: 3, 3cam, 30c, 35, 43, 50b	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	
Archos Vision: clipper	*NC*	Archos USB Cable	Archos USB Cable	Archos USB Cable	MP3300-16	

Creative

Model	MP1550	MP1580	MP1800	MP1860A	MP2250	Additional Information
ZEN Micro, ZEN MicroPhoto	UA-U03	UA-U03	UA-U03	UA-U03	UA-U03	

Microsoft

Model	MP1550	MP1580	MP1800	MP1860A	MP2250	Additional Information
Zune: 4GB, 8GB, 30GB, 80GB	Microsoft USB Cable	Microsoft USB Cable	Microsoft USB Cable	Microsoft USB Cable	MP3300-16	

SanDisk

Model	MP1550	MP1580	MP1800	MP1860A	MP2250	Additional Information
Sansa: c200, e200	UA-U03	UA-U03	UA-U03	UA-U03	UA-U03	
Sansa: Connect, Fuze, View	UA-U03	UA-U03	UA-U03	UA-U03	UA-U03	