

External Battery POWER BANK

Model: PWA | Capacity: 2600 mAh


Manual & Warranty Card

MOTA®

External Battery


POWER BANK

Manual & Warranty Card




How to Charge Your Device:

1. Choose the proper adapter for your device.
2. Connect the adapter to the USB connection cable.
3. To begin charging, press and release the power button.



How to Charge MOTA Battery:

1. Connect the Micro USB connection to your MOTA Battery.
2. Connect the USB connection to your computer.



MOTA®

External Battery

POWER BANK

Manual & Warranty Card



How to Operate Flash Light:

Press and hold the power button for three seconds to turn on the light. To turn the flash light off, press and hold the power button for three seconds.



Compatible with:

iPhone / iPod / iPad
Most Mobile Phones
PSP / Wii Game Consoles
MP3 Players
Digital Cameras
Other 5V Digital Devices



LED Status Guide:

Red: Battery stick is being charged.
Blue: Battery stick is charging your device.



Support:

Please visit <http://www.MotaElectronics.com/support/>

MOTA® is a trademark of UNorth® LLC. iPhone®, iPod®, iPad® are trademarks of Apple® Inc. Sony®, PSP® are trademarks of Sony® Corporation. Nokia® is trademark of Nokia® Corporation. MOTA Electronics and UNorth are not affiliated with Apple Inc., Sony Corporation, and Nokia Corporation. All other trademarks are the property of their respective owners.