
ACCESSORY POWER™



INSTRUCTION MANUAL

FREE PRODUCT REGISTRATION

Protect your investment and take advantage of this free product warranty.

YOU MUST REGISTER WITHIN 30 DAYS

of purchase to receive full warranty coverage and access to special offers.

www.AccessoryPower.com/warranty



Thank you for purchasing the Accessory Power **GOgroove SonaWAVE**. This light-weight, compact and powerful portable sound system delivers high fidelity music anywhere! It's sleek, modern design and easy to use interface make it the perfect pair for any laptop, iPhone[®], iPod[®], iPad[®], MP3, cell phone or other audio device. Enjoy listening to your music collection **no matter where life takes you!**

What's in the box?

- 1 - SonaWAVE Sound System
- 2 - AC power adapter
- 3 - USB power cable

- 4 - 3.5mm audio cable
- 5 - Instruction manual




fig. 1

Product Diagram

fig. 2-1






fig. 2-2



Operating Instructions:

Playing Music from an iPod® iPad® iPhone®, MP3 Player, Smartphone, or other 3.5mm Audio Device



Connect the GOgroove SonaWAVE to Power

When using AC power, connect the small end of the (3) *USB power cable* to the *USB port* (fig. 3) on the back of the **GOgroove SonaWAVE** and the other end into the (2) *AC power adapter*. Insert the (2) *AC power adapter* into a wall outlet. Press the *Power button* (fig. 2-1) to turn on the **GOgroove SonaWAVE**. *Volume* and *Power buttons* (fig. 2-1) will glow blue to indicate power flow. When using AAA battery power, simply insert four AAA batteries into the *AAA battery compartment* (fig.2-2).


Connect the Audio Device

Insert one end of the (4) *3.5mm audio cable* into the *AUX port* (fig. 3) on the back of the **GOgroove SonaWAVE**. Connect the opposite end of the (4) *3.5mm cable* to your audio device (fig. 3).

Choose your Music

You are now ready to play music! Just find your favorite music on your audio device and press "PLAY". You can adjust the volume with both your audio device and the *Volume buttons* (fig. 2-2) on the **GOgroove SonaWAVE**.

Playing Music from a Laptop Computer (Mac and PC)



Connect the GOgroove SonaWAVE to your Laptop Computer

First, connect the small end of the (3) *USB power cable* to the *USB port* (fig. 4) on the back of the **GOgroove SonaWAVE**. Connect the large end of the (2) *USB power cable* into your computer's USB port. The **GOgroove SonaWAVE** will receive an audio signal and power through the (2) *USB power cable* (fig 4.). There is no need to connect the (4) *3.5mm audio cable* for laptop configuration.

Power ON and Play Music

Press the *Power button* (fig. 2-1) to turn on the **GOgroove SonaWAVE**. You will see the *Volume* and *Power buttons* (fig. 2-1) glow blue to indicate power flow. You are now ready to play music! You can adjust the volume with your computer and with the *Volume buttons* (fig. 2-1) on the **GOgroove SonaWAVE**.

NOTE: If your laptop computer does not have a free USB port, you can connect the **GOgroove SonaWAVE** via the 3.5mm audio cable. You will have to provide power to the **GOgroove SonaWAVE** through either AC or AAA power.

Troubleshooting

Having trouble getting laptop music to play?

Please check to make sure that the volume level on your laptop is turned up. Also, check to make sure that **ONLY** the (3) *USB power cable (fig.4)* is being used for power and audio connection. When using **GOgroove SonaWAVE** with a laptop you do not need to connect the (4) *3.5mm audio cable*. Make sure that you see the lights of the **GOgroove SonaWAVE** glowing blue, and that the volume has been turned up so that the music can be heard.

Things to keep in mind when using AAA power...

Please use freshly charged or new AAA batteries with the **GOgroove SonaWAVE**. When using AAA's, the sound and power should work the same as when connected to AC or USB power. If you are experiencing mixed results with sound and power, please try a new set of AAA batteries.

If you are experiencing any other difficulties...

Restart and reconnect the **GOgroove SonaWAVE** as the details in this manual describe. Make sure that all cables are seated properly in the appropriate ports and that a good connection is being made. Most issues can be resolved by properly reconnecting.

Cautions

- Keep in a safe place free from dust, liquid and extreme temperatures
- Only use this device with the recommended power sources
- Keep out of reach of small children
- When not in use, please disconnect batteries or power sources

Product Specifications

Speakers: 3w X 2

Subwoofer: 6W

Driver unit: diameter 40 mm, 6 ohm

Dimension: 8.5 x 2.75 x 2 inches

Weight: 8.75 ounces

Power: AC adapter (included),

USB 5 volt, or 4 AAA batteries (not included)

Input: Standard 3.5mm audio plug or USB 2.0



Please Always Recycle



ACCESSORY POWER
WESTLAKE VILLAGE, CALIFORNIA

WWW.ACCESSORYPOWER.COM
MADE IN CHINA

©2010 ACCESSORY POWER

All trademarks and brand names are the property of their owners.

iPhone® and iPod® are trademarks of Apple, Inc.
registered in the U.S. and other countries.

Apple is not responsible for the operation of this device
or its compliance with safety and regulatory standards