
28600



Travel Power Pack

for Baby Touch®, Best View® Choice & Safe Sight™ compatible with 02000/28460/28530





I travel bag

ullet I plug adapter lacksquare(for use with Baby Touch handheld power adapter only)

WARNING:

THIS PRODUCT CANNOT REPLACE RESPONSIBLE ADULT SUPERVISION.

- STRANGULATION HAZARD Children have STRANGLED in cords. Keep this cord out of reach of children (more than 3 feet (0.9m) away from crib). Use enclosed Security Clips to help secure cord away from baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.
- When an AC Adapter is plugged into an electrical outlet, do not touch the exposed end.
- This product is not a toy. Do not allow children to play with it.
- This product contains small parts. Adult assembly required. Exercise care when unpacking and assembling the product.

SET UP & USE:

To Use in Video and Audio Mode:

Step 1: Place the Monitor in the room from which you want to monitor your baby (ie. bedroom or living room). Plug the AC Adapter into the monitor's AC Adapter Jack and the other end into a standard electrical

Step 2: Press and hold "POWERO" button for 4 seconds to turn on until video or Summer logo appears on screen.

Step 3: For audio and no video, press the VIDEO ON/OFF button on top of the unit.

Step 4: To turn the monitor off completely, press and hold the "POWER**ሪ**" button for 3 seconds.

Tips:

- Before using Monitor in portable mode (battery), be sure to charge battery 12-16 hours.
- To charge battery, plug the larger AC Adapter into the Monitor's AC Adapter Jack. Plug the other end into a standard electrical outlet.
- After initial 12-16 hour charge, to achieve optimal battery life, charge battery overnight and unplug all day during use.
- Note: Only charge battery when low indicator light comes on. Constant recharging of your battery before low battery indicator light comes on will decrease the life of your batteries.
- When battery is low, the Power On LED will illuminate amber, indicating that the battery needs to be recharged.
- To conserve battery power, use AC Adapter whenever possible. Remove battery during long periods of non-use.
- If battery is exhausted, remove immediately from the Monitor.
- Properly dispose of exhausted battery.



Summer Infant, Inc. 1275 Park East Drive Woonsocket, RI 02895 USA 1-800-268-6237

MONITOR

SET UP & USE:

To Use in Video and Audio Mode:

video or Summer logo appears on screen.

Summer Infant Europe, Ltd. First Floor North Wing, Focus 31 Cleveland Road, Hemel Hempstead Hertfordshire, HP2 7BW UK +44 (0) 144 250 5000

© 2012 Summer Infant, Inc. Colors and styles may vary.
Please retain information for future reference.


MADE IN CHINA. 6/12

Summer Infant Canadian Office 1055 Middlegate Road Mississauga, Ontario, Canada L4Y3Y4 905-848-2424

28600



for Baby Touch®, Best View® Choice & Safe Sight™ compatible with 02000/28460/28530



• I travel bag



ullet I plug adapter oxdot(for use with Baby Touch handheld power adapter only)

outlet.

of the unit.

1275 Park East Drive

Woonsocket, RI 02895 USA 1-800-268-6237

Before using Monitor in portable mode (battery), be sure to charge battery 12-16 hours.

Step 4: To turn the monitor off completely, press and hold the "POWER**O**" button for 3 seconds.

Step 1: Place the Monitor in the room from which you want to monitor your baby (ie. bedroom or living room). Plug the AC Adapter into the monitor's AC Adapter Jack and the other end into a standard electrical

Step 2: Press and hold "POWERO" button for 4 seconds to turn on until

Step 3: For audio and no video, press the VIDEO ON/OFF button on top

- To charge battery, plug the larger AC Adapter into the Monitor's AC Adapter Jack. Plug the other end into a standard electrical outlet.
- After initial 12-16 hour charge, to achieve optimal battery life, charge battery overnight and unplug all day during use.
- Note: Only charge battery when low indicator light comes on. Constant recharging of your battery before low battery indicator light comes on will decrease the life of your batteries.
- When battery is low, the Power On LED will illuminate amber, indicating that the battery needs to be recharged.
- To conserve battery power, use AC Adapter whenever possible. Remove battery during long periods of non-use.
- If battery is exhausted, remove immediately from the Monitor.
- Properly dispose of exhausted battery.



© 2012 Summer Infant, Inc. Colors and styles may vary. Please retain information for future reterence.

MADE IN CHINA. 6/12

er Infant Canadian Office 1055 Middlegate Road Mississauga, Ontario, Canada L4Y3Y4 905-848-2424

⚠ WARNING:

THIS PRODUCT CANNOT REPLACE RESPONSIBLE ADULT SUPERVISION.

STRANGULATION HAZARD - Children have STRANGLED in cords. Keep this cord out of reach of children (more than 3 feet (0.9m) away from crib). Use enclosed Security Clips to help secure cord away from baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

- When an AC Adapter is plugged into an electrical outlet, do not touch the exposed end.
- This product is not a toy. Do not allow children to play with it.
- This product contains small parts. Adult assembly required. Exercise care when unpacking and assembling the product.