




Guía de instalación rápida 

TU2-ET100
V3

Table of Contents

Español	1
1. Antes de iniciar	1
2. Cómo se instala	2
Troubleshooting	4



Contenidos del paquete

- TU2-ET100
- CD-ROM del controlador
- Guía de instalación rápida multilingüe

Requisitos del sistema

- Unidad de CD-ROM
- Puertos USB: 2.0 ó 1.1

Compatible con sistemas operativos	CPU	Memoria
Windows 7 (32/64-bit)	1GHz o superior	1GB RAM o superior
Windows Vista (32/64-bit)	800MHz o superior	512MB RAM o superior
Windows XP (32/64-bit)/ 2000 / ME / 98SE	300MHz o superior	256MB RAM o superior
Mac OS X (10.6)	CPU Intel	1GB RAM o superior
Mac OS X (10.5)	867MHz o superior	512MB RAM o superior
Mac OS X (10.4)	333MHz o superior	256MB RAM o superior
Mac OS X (10.1-10.3)	300MHz o superior	256MB RAM o superior

2. Cómo se instala

Nota:

1. Para la instalación del controlador con sistemas Windows 98SE, Me y OS X, consulte la guía del usuario en el CD-ROM del controlador.
2. No conecte el TU2-ET100 a su PC a menos que se le indique.



Windows 7 / Vista / XP / 2000

1. Inserte el CD-ROM del controlador en su unidad de CD-ROM.


2. Haga clic en Run Autorun.exe (sólo para Windows 7/Vista).

3. Haga clic en instalar el controlador (Install Driver).

4. Siga las instrucciones del InstallShield Wizard (asistente de Install Shield) y luego haga clic en Finish (Finalizar).



5. Haga clic en Exit (Salir)



6. Retire de la unidad de CD-ROM de su PC el disco que contiene el controlador.


7. Conecte el adaptador a un puerto USB disponible de su PC.



8. Los archivos controladores se instalarán automáticamente.



9. Conecte el cable RJ-45 del adaptador a un conmutador, enrutador o cable Módem o DSL.



La instalación ha sido completada

1. I inserted the Driver CD-ROM into my computer's CD-ROM Drive and the installation menu does not appear automatically. What should I do?

1. For Windows 7, if the installation menu does not appear automatically, click on the Windows Icon on the bottom left hand corner of the screen, click the "Search programs and files" box, and type D:\autorun.exe, where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard
2. For Windows Vista, if the installation menu does not appear automatically, click Start, click the Start Search box, and type D:\autorun.exe where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard.
3. For Windows 2000/XP, if the installation menu does not appear automatically, click Start, click Run, and type D:\autorun.exe where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard.

2. Can I connect or disconnect the TU2-ET100 while the computer is on?

Yes, you can connect or disconnect TU2-ET100 while the computer is on because the USB interface is Plug-and-Play compliant and hot-pluggable.

3. Windows is unable to recognize my hardware. What should I do?

1. Make sure your computer meets the minimum requirements as specified in Section 1 of this Quick Installation Guide.
2. Try plugging the adapter into a different USB port.

4. Windows recognizes my new hardware, but I'm unable to connect to my network. What should I do?

1. Verify that the RJ-45 Ethernet cable is securely connected from your switch or router to your adapter.
2. Verify that the LEDs on your adapter are lit.
3. Verify that the TCP/IP settings are set to Obtain an IP address automatically.

5. How do I install this device on Windows 98SE, ME and Mac OS X?

Refer to the User Guide included on the Driver CD-ROM for installation instructions.

If you still encounter problems or have any questions regarding the TU2-ET100, please contact TRENDnet's Technical Support Department.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



TRENDnet[®]

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>