




Imanuel de l'utilisateur: www.arctic.ac/fileadmin/p311/manual fr.pdf Manual del usuario: www.arctic.ac/fileadmin/p311/manual es.pdf Manual do Utilizador: www.arctic.ac/fileadmin/p311/manual pt.pdf SE Användarmanual: www.arctic.ac/fileadmin/p311/manual se.pdf

 Bedienungsanleitung: www.arctic.ac/fileadmin/p311/manual en.pdf
 Kato pro uživatele: www.arctic.ac/fileadmin/p311/manual cz.pdf Használati útmutató: www.arctic.ac/fileadmin/p311/manual hu.pdf D Instrukcja obsługi: www.arctic.ac/fileadmin/p311/manual_pl.pdf

Cebruikershandleiding: www.arctic.ac/fileadmin/p311/manual nl.pdf



Function diagram

- ① Multifunction button
- 2 LED indicator
- (3) Volume +
- (4) Volume
- S Mini USB charging port 6 Backward
- (7) Forward
- (8) Microphone



Getting started

1. Charge the battery

Please make sure the battery has been fully charged and fully discharged at the first three times of use to ensure the best performance of the battery. A normal charging process takes about 2 - 3 hours.







Hold for 7 seconds until the red and blue LED flash alternately

2. Pair and connect the headset

3. Turn on Bluetooth on your phone and pair with headset Example: iPad / iPhone / iPod Touch

Press Settings > General > Bluetooth > Bluetooth on > P311 > Pair



Example: Nokia N97 mini

Press Menu > Settings > Connectivity > Bluetooth > Bluetooth on > Paired devices > Options > New paired device > P311 > Passcode "0000"




Example: Motorola Milestone

Press Menu > Settings > Wireless & networks > Bluetooth settings > Bluetooth on > Scan for devices > P311 > Passkey "0000"



Use P311 with Skype (Windows 7)

 Connect the UD1 / UD2 USB Bluetooth^o Dongle (available at www.arctic.ac) to an available USB port of your computer after the installation of Bluetooth application.



3. To start the IVT BlueSoleil software, click the [®] icon located in the system tray, select "**Display Classic View**" from the pop-up menu.



5. Double click on the orange ball to start or stop searching for Bluetooth devices in range.



2. Click on the [®] icon located in the system tray and select "**Turn** on **Bluetooth**" from the pop-up menu.



4. To activate the pairing mode on your P311, hold the **multifunction button** for 7 seconds until the red and blue LED flash alternately.



Multifunction button

6. Right click on the P311 icon and select Pair.



7. Double click on the P311 icon to search Bluetooth services.



8. Double click on the **Bluetooth Headset and Microphone** for service icon to initiate the connection. The application will connect the headset to your PC (the for icon will become green).







10. Sign in to Skype and in the Tools menu, select Options...





11. Under Audio settings, select your Bluetooth device from Microphone, Speakers and Ringing dropdown lists.

General General	Audio settings: Set up sound on your computer	
General settings	Microphone Volume	Microphone (Bluetoeth SCO Audio)
Sounds		Automatically adjust microphone settings
Video settings	Speakers	Speakers (Buetooth SCO Audo) -
Skype Access	Volume	Automatically adjust speaker settings
Reivacy		Speakers (Bluetooth SCO Audio)
Notifications		
🕑 Cals		Show advanced options
O IM & 5M5	Other things you can	do
Advanced		setting up your audio equipment
	Buy a headset or	Skype phone from the Skype shop

12. Test your Skype audio settings are correctly configured by calling the Echo / Sound Test Service (Skype name:echo123)

Skype Contacts Conversation Call View Tools Help			
Q-	n	Echo / Sound Test Service	× Clos
Call cheaply to mobile phones and landlines		S Online	•
Contacts O F	tecent	22	
Q, Search			
🧟 😵 Echo / Sound Test	Service 🔶	Caller (Check settings _all)
0			
0			
5			
0			
e 9			
Add a contact	Create a group		
Call phones			
3,036,821 people online			
Our new Subsc The cheapest wa		© • 0 5×6	0
- 15% phones with Skyp			


Switch on

Hold for 3 seconds until the blue LED - switches on

Switch off

Hold for 3 seconds until the red LED switches on

Music controls



Note: iPhone 4, iPhone 3GS, iPhone 3G, iPad, iPod touch (2nd generation), and iPod touch (4th generation) support pause, play, stop, next track and previous track for AVRCP when running the latest version of the device software.

Make and receive calls		
Function	Action	
Make a call:	Dial from your mobile phone's keypad and press "Send" or "OK".	
Voice dialing:	 In handsfree state, enable voice recognition function of your mobile phone. Double press the multifunction button until you hear a beep prompt. Say the name of the person you wish to call loudly. 	
Answer a call:	Press 🖍 once.	
End a call:	Press 🖍 once.	
Refuse a call:	Press and hold 🖍 for 2 seconds.	
Redial the last dialed number:	Press and hold 🖍 for 2 seconds.	
Switch the call between mobile phone and headset:	In call state, press and hold 🖍 for 2 seconds.	
LED indicators		
Status	Indication	
Charging	Red LED on	
Battery full	Red LED off	

On	Blue LED flashes once every 7 seconds
Paring mode	Red and blue LED will flash alternately
Low battery	Red LED flashes every 30 seconds / acoustic signal

Precautions

1) Avoid extreme volume. Long term exposure to loud music may cause hearing damage.

The radio waves emitted by the headset and wireless transmitter can affect the operation of nearby electronics including medical devices.
 Keep the unit in a cool, dry place.

Warranty

This ARCTIC product includes a 2-year limited warranty. For further information, please consult warranty.arctic.ac

Copyright[©] 2011 ARCTIC (HK) Ltd. All Rights Reserved.

No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purpose, without the express written permission of ARCTIC (HK) Ltd. In no event shall ARCTIC its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.