


PC or Mac with  
music files




Wireless Router/Switch  
(or wired Ethernet)



## Connecting to powered speakers (M1000)


Power Cable



Speaker Base



PC or Mac with  
music files




Wireless Router/Switch  
(or wired Ethernet)



## Connecting to a stereo

Power Cable



Connect 1 of the following:

- (1) Optical "Toslink" SPDIF from SoundBridge to receiver
- (2) Black SPDIF Coax (RCA) to "Coax Digital In" on your receiver
- (3) Analog RCA cable (white/red) to AUX on your receiver

