U1 USB Recording Microphone

Before using the U1 in your favorite audio or communications application you must confirm that the computer's operating system recognizes the U1.

Windows XP recognition instructions


1. Plug the U1 into the USB port on the computer.

(When using a USB hub, check with the hub manufacturer to be sure the hub supports a device such as a microphone. Plug the U1 directly into the computer's powered USB port for optimal performance.)

- 2. Allow 30 to 60 seconds for the system software to recognize the U1. (A series of bubbles will appear by the Windows toolbar to notify you of a new device.)
- 3. In the Start Menu, select Control Panel.

| Internet Internet Explorer | My Documents |
|--------------------------------------|--|
| | My Pictures My Music Wy Computer |
| | My Network Places |
| | Connect To |
| | Help and Support Search |
| All Programs 📡 | 7 Run |


4. Select "Sounds, Speech, and Audio Devices".



6. Select the "Audio" tab. Confirm that under the "Sound recording" section the "C-Media USB Audio Device" is selected. (The "Sound playback" should remain your usual sound output device).


| /olume | Sounds Audio Voice Hardware |
|-------------|---------------------------------|
| Sound | playback |
| 0. | Default device: |
| 9) | (Default playback device) 🛛 🗸 |
| | Volume Advanced |
| Sound | recording |
| 2 | Default device: |
| 18 | C-Media USB Audio Device 🗸 |
| | Volume Advanced |
| MIDI m | usic playback |
| - | Default device: |
| <u>aine</u> | Microsoft GS Wavetable SW Synth |
| | Volume About |
| Use o | nly default devices |
| | OK Cancel Apply |

 Select the "Volume" tab under the Sound recording heading and select "Advanced Controls" in the Options menu of this window.



8. Click the "Advanced" button to open the "Advanced Controls for Wave In" window. Depending upon your system, you might have the option of selecting "1 AGC" or "Mic boost". Checking this option will significantly increase the sensitivity of the microphone. Use this for recording softer sounds. If you

5. Select "Sounds and Audio Devices".



experience distortion when recording louder sounds, try unchecking this option.

| dvanced | i Controls for Wave In | | | | | | | |
|-----------------|--|--|--|--|--|--|--|--|
| ľ | These settings can be used to make fine adjustments to your audio. | | | | | | | |
| Tone Co | ntrols | | | | | | | |
| These | settings control how the tone of your audio sounds. | | | | | | | |
| <u>B</u> ass: | Low High | | | | | | | |
| <u>T</u> reble: | Low High | | | | | | | |
| | settings make other changes to how your audio sounds. See rdware documentation for details. | | | | | | | |
| | Close | | | | | | | |

- 9. Launch your audio recording software.
- 10. Position the U1 approximately 4 to 6 inches from the sound source for best results.
- 11. Locate the preferences in your audio program and select the "C-Media USB Audio Device". Adjust the input level in this program so that the audio signal is not distorted.
- 12. Enjoy your CAD U1 USB Recording Microphone.

Mac OSX recognition instructions

1. Plug the U1 into the USB port on the computer.

(When using a USB hub, check with the hub manufacturer to be sure the hub supports a device such as a microphone. Plug the U1 directly into the computer's powered USB port for optimal performance.)

- 2. Allow 30 to 60 seconds for the system software to recognize the U1.
- 3. Go to the Apple Menu and locate "System Preferences".

| Ű | Finder | File | Edit | View | Go | Window | Help |
|----|-------------|---------|------|------------|----|--------|------|
| A | bout This | Mac | | | | | |
| Sc | oftware Up | odate | | | | | |
| М | ac OS X So | oftwar | e | | | | |
| Sy | /stem Pref | ference | es | | | | |
| D | ock | | | • | | | |
| Lo | ocation | | | ► | | | |
| Re | ecent Item | ns | | • | | | |
| Fo | orce Quit I | Finder | ٦ | C#03 | | | |
| SI | eep | | | | | | |
| Re | estart | | | | | | |
| Sł | nut Down. | | | | | | |
| Lo | og Out Ma | cintosh | User | 企業Q | | | |

4. Under "Hardware" click on the "Sound" icon.



- 6. Click on the "Output" button and choose the internal speakers or the output speakers of your choice. (The "Sound playback" should remain your usual sound output device).
- 7. Position the U1 4 to 6 inches away from your source (your mouth or music instrument).
- 8. Test the U1 by speaking or playing into the microphone.
- 9. You will see activity in the "Input Level" meter.

| Settings for the selecte | d dev | ice: | | | | | | |
|--------------------------|------------|------|---|--------|-----|-----|-----|----------|
| Input level: | 0 | | | 0 0 | 0 0 | 0 0 | 000 | ĺ |
| Input volume: | ! - | , | Q | j. | | 1 | , | U |

- 10. As you are speaking or playing adjust the "Input Volume" slider. Take care not to allow the signal to go beyond the meter, if the meter is fully illuminated the sound can become distorted. The meter should be illuminated 3/4ths of the way to obtain the best sound quality.
- 11. Close the System Preferences window to complete the settings.
- 12. Launch your audio recording software.
- 13. Position the U1 approximately 4 to 6 inches from the sound source for best results.
- 14. Locate the Preferences in your audio program and select the "C-Media USB Audio Device". Adjust the input level in this program so that the audio signal is strong but not distorted.
- 15. Enjoy your CAD U1 USB Recording Microphone.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference at his own expense.

5. Click on the "Input" button and choose the "C-Media USB Audio Device".

| 00 | | Sound | |
|-----------------------|----------------|--------------------|-----|
| ► Show All | | Q | |
| | Sound Effec | ts Output Input | _ |
| Choose a device fo | or sound input | | |
| Name | | Port | |
| Internal microphon | e | Built-in | |
| Line In | | Audio line-in port | |
| C-Media USB Audio | Device | USB | |
| Settings for the sele | | | |
| Input volum | e: 🖳 📻 | | |
| | | | ? |
| Output volume | 2 1 1 | lume in menu bar | ute |

Two-Year Limited Warranty

CAD Professional Microphones hereby warrants that this product will be free of defects in material and workmanship for a period of two years from the date of purchase. In the unlikely event that a defect occurs CAD will, at its option, either repair or replace with a new unit of equal or greater value. Retain proof of purchase to validate the purchase date and return it with any warranty claim.

Return warranty claims carefully packed, insured and prepaid to the Service Department at the address listed below.

This warranty excludes exterior finish or appearance, damage from abuse, misuse of the product, use contrary to CAD's instructions or unauthorized repair. All implied warranties, merchantability, or fitness for a particular purpose is hereby disclaimed and CAD hereby disclaims liability for incidental, special or consequential damages resulting from the use or unavailability of this product.

This warranty gives you specific legal rights and you may have other rights that vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. Note: No other warranty, written or oral is authorized by CAD Professional Microphones.

Shipping Instructions

Please call our customer service department at 440-349-4900 for a pre-approved return authorization number. Carefully repack the unit and return it to: CAD Professional Microphones, 6573 Cochran Road, Building I, Solon, Ohio 44139.

RETURNS WITHOUT A PRE-APPROVED RETURN AUTHORIZATION NUMBER WILL BE REFUSED. If outside the United States, contact your local dealer or distributor for warranty details.





CAD Professional Microphones 6573 Cochran Rd., Bldg. I Solon, OH 44139 800-762-9266 www.cadmics.com