Lava DSerial-PCI/LP Quick Installation Guide





Rev. B00

Windows NT 4.0 Installation

- 1. With the power turned off, insert the DSerial-PCI/LP card into any free PCI slot in your PC. Boot NT logging on as "Administrator".
- 2. Place the DSerial-PCI/LP installation diskette into your floppy drive and select Run from the Start Menu. When prompted type: A:\NT4.0\Setup.
- After the necessary files have been copied, select My Computer and start Control Panel. A new icon will appear called "LavaPort". This applet should now be used to configure ALL Com Ports in your PC – not just Lava serial ports.

LavaPort Control Panel Applet	×
Ports (COM) Ports (COM) Ports (Communication Port [COM7] Ports (Communication Port [COM8] Ports (Communication Port [COM3] Ports (Communication Port [COM2]	Close
	Property
	Delete

Please note that Com 1 may not appear in this applet if you have your mouse attached to Com 1.

DOS and Windows 3.x Installation

- 1. With the power turned off, insert the DSerial-PCI/LP card into any free PCI slot in your PC. Turn your PC on.
- 2. Place the DSerial-PCI/LP installation diskette into your floppy drive. In the Win3.11\16550 subdirectory of this diskette you will find a file called "Lavaconf.exe". Copy this file to your hard drive and run it.
- 3. When run, Lavaconf.exe will display two I/O addresses and one IRQ. These correspond to the addresses and IRQ chosen by your PC when configuring the DSerial-PCI/LP. Make a note of them.
- 4. If you are using Windows 3.x, start Windows and go to Control Panel | Ports. Choose Com 3 for Port 1 and Com 4 for Port 2 on the DSerial-PCI/LP. Click the Advanced button and enter the I/O address and IRQ for each port as reported by Lavaconf.exe. Reboot your PC for these changes to take effect.

Note: DOS and Windows 3.X support a maximum of four Com Ports in a PC.

Windows 95/98/Me/2000/XP Installation

- 1. With the power turned off, insert the DSerial-PCI/LP card into any free PCI slot in your PC. Make sure the card is well seated. Turn your PC on and start Windows.
- 2. Windows will automatically detect the DSerial-PCI/LP as a new PCI Serial Controller and ask you to insert the Installation Diskette. The installation files are located in the root directory of this disk.
- 3. After the necessary files have been copied, Windows will complete the full installation of the DSerial-PCI/LP. To view the installed configuration, click Control Panel | System. The DSerial-PCI/LP will appear in the ports listing as follows:

System Properties ? ×
General Device Manager Hardware Profiles Performance
View devices by type C View devices by connection
Display adapters
E - S Floppy disk controllers
E G Hard disk controllers
🗄 🕀 🛞 Keyboard
🖶 🖶 📕 Monitor
田·唐静 Network adapters
Communications Part (COM1)
Communications Port (COM2)
ECP Printer Port (LPT1)
Lava DSerial PCI Port A (COM5)
Lava DSerial PCI Port B (COM6)
Properties Refresh Remove Print
OK Cancel

NOTE: Modifying I/O Address and IRQ Resources is NOT recommended.

<u>Changing the Com numbering of your ports</u> <u>in Windows 95/98/Me</u>

Unless you already have more than 4 Com Ports installed in your PC, Windows will by default configure the DSerial-PCI/LP as Com5 and Com6. If you wish to change the Com number of either one of the ports on the DSerial-PCI/LP (e.g. Assign Port 1 to be Com 3), please use the Lava Com Port Redirect Utility included in the "Utils" subdirectory of your Installation Diskette. This may be necessary because some communications applications programs do not recognize port designations beyond Com 4. The Lava Com Port Redirect Utility will allow you to change the Com numbering of your ports without changing I/O address resources.

To install the Lava Com Port Redirect Utility on your hard drive, insert the Installation Diskette into your floppy drive, click Start, Run and type A:\Utils\Setup.



<u>Changing the Com numbering of your ports</u> <u>in Windows 2000/XP</u>

In Windows 2000 and Windows XP, Com port numbering can be changed by double-clicking the DSerial-PCI/LP entry displayed in Windows' Device Manager (as described earlier). Go to Settings | Advanced, and choose the Com port number you want.

Lava Technical Support

9:00 am to 5:30 pm Monday to Friday (Eastern Time)

Tel: +416 674-5942 Fax: + 416 674-8262

E-mail: tech@lavalink.com Internet: www.lavalink.com



Lava Computer MFG Inc.



This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE

Lava Computer MFG Inc. 908 Niagara Falls Blvd. #629. North Tonawanda NY 14120-2060