

Read Me First

for the ProCurve Switch zl Modules (J8706A, J8708A)

Software Release K.11.3x or Greater Is Required on Your Switch 5400zl

ProCurve switch software release K.11.17 is installed on the switch at the factory. This version of the switch software provides support for the two switch zl modules J8706A and J8708A.

For installation information refer to the *ProCurve Switch zl Modules Installation Guide* (5991-4714), that came with your zl modules.

Note

You can install, exchange, or remove modules after the switch has been powered on. Whenever a module is installed during this process, it is initialized and tested for correct operation. During this process, the switch Self Test LED is on. If you hot swap another module while the switch is initializing and testing the first module, it is possible to cause the first module or the entire switch to be reset.

Hot Swap Precautionary Procedures. To prevent the modules or switch from being reset when you must hot swap multiple modules, follow these simple precautions:

- Do not install/remove any modules from the switch while the switch Self Test LED is lit.
- Before removing or installing any modules, make sure that all network cables are disconnected from the module.

See the “Installing the Modules” section of the *ProCurve Switch zl Modules Installation Guide*, for more information.

Software Updates Are Free!



ProCurve Networking provides free software updates on the ProCurve Web site for your Series 5400zl Switch. To access the software updates, go to the ProCurve Web site at <http://www.procurve.com>, then click on **Software updates** to go to the “ProCurve Networking software updates” page. Under **Latest software** click on **Switches** to go to the page that has the free download for your switch.

Register for Automatic Notification of Updates. From the “ProCurve Networking software updates” page, you can also register yourself to automatically receive email notice of new updates for your managed ProCurve networking products.

To determine whether you have the latest software, you can compare the software version that is available on the web site with the version that is currently installed on your switch. Follow the instructions below to determine the current software version in your switch.

To Determine the Current Software Version in Your Switch. For the Series 5400zl Switch, use any of the following methods to view the current software version:

- Start a console session with the switch. In the console login screen (the first screen displayed), the **Firmware revision** line under the switch name shows the software version.
- If you already have a console session going, at the prompt enter the **show version** command. The resulting display lists the current software version.
- In the web browser interface, click on the **Identity** tab. The current software version is listed in the **Version** line.

To Download New Software. Your ProCurve Series 5400zl Switches support several different methods for downloading new operating system software. For instructions on how to download the new software, please see appendix A, “File Transfers” in the *Management and Configuration Guide* on the *Documentation CD-ROM* included with your switch.

Saving the Configuration After Installing or Exchanging a Module

The following cases automatically result in a change to the running-configuration on your switch:

- If you replace a module with another module of a different type and then reboot the switch
- If you install a module in a slot that has not previously been used (including when you install a module and apply power to the switch for the first time)

If you want to save such changes to permanent memory (startup-configuration), use the **write memory** command in the switch console. This causes the switch to use the new hardware configuration for subsequent reboots. (The switch always reboots from the startup-configuration.)

If you do not save the hardware changes to the startup-configuration, you will be prompted with the following message the next time you use the **reboot** or **reload** commands:

```
Do you want to save the current configuration [y/n]?
```

For more information on switch memory, including the startup-config and running-config memories, refer to the *Management and Configuration Guide* on the *Documentation CD-ROM* included with your switch. For the latest version of ProCurve switch documentation, visit <http://www.procurve.com>. (Click on **Technical support**, then **Product manuals**.)

For more information regarding the software configuration for your module refer to the *Management and Configuration Guide* on the *Documentation CD-ROM* included with your switch.

For the latest version of this documentation, visit <http://www.procurve.com>, (Click on **Technical support**, then **Product manuals**, then **Switch ProCurve 5400zl Series**).

