

# Table of Contents

---

WideCam F100 Features ..... 1

Set up the device ..... 2

I.P.M setting..... 3

Arcsoft Webcam Companion 4 ..... 4

How to use Webcam Companion4 ..... 5-12

Trouble shooting for WideCam F100 ..... 12-13

## Symbol for Separate Collection in European Countries

This symbol indicates that this product is to be collected separately.

The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.



## WideCam F100 Features

Experience true plug and play with WideCam F100! Hook it up to a USB port and start video chatting right away! No drivers are needed for this USB Video Class web camera.



### 1. Ultra wide angle lens

120 degree lens  
provides wider view

### 2. Microphone built in

Sensitive microphone

### 3. Base rotation

Base rotates 360  
degrees for any angle  
view

### 4. Clipping Base

Adjustable clipping  
base fits easily to  
desktop, NB or TV

## Set up the Device

WideCam F100 supports UVC (USB Video Class) which can plug and play in Windows 7/Vista/XP SP2 or Mac 10.4.9 and above without using a device driver.

1. Make sure your PC OS system is Windows 7/Vista/XP SP2 or Mac 10.4.9 and above.
2. Plug in the WideCam F100 to a USB port.
3. WideCam F100 is now ready for use with any application. It can work properly with any video chat software that supports a video feature. If you use Mac OS, you can use iChat for online chatting.

### Image Capture under Windows XP SP2 and Vista:

1. Double-click on the My Computer icon. Or click Start → My Computer
2. Now look for and double-click on “USB Video Device”, then you can start to capture still images.



### **NOTE**

- To check if Windows XP system is SP2 (Service Pack 2).
  - Click on the **My Computer** icon on your desktop or in the Windows Start menu.
  - When the menu appears, click **Properties**.
- If your Windows XP system isn't SP2 (Service Pack 2), go to the website <http://www.microsoft.com> to upgrade your version.

## **I.P.M(Image Protection Mechanism) setting**

**WideCam F100 embed I.P.M function. This feature prevents any person trying to hack into your system and use your web cam.**

1. When you turn on the web cam, the system will display a dialog box to ask you "Do you want to open the image from web cam?" Press "Yes" to open the image. Any hacker can not turn on your webcam because they can not press "Yes". This keeps your web cam safe.



2. Every time when you turn the web cam, the system will ask again if you want to prevent any hacker invasion.

## **Webcam Companion 4 (For HD recording)**

This simple application makes it easy for you to capture still images and videos directly from your webcam. You even have the option to shoot a picture of you in which your face is morphed by the one in the template you have selected. The program also provides templates and layouts for you to customize your photos and print them out or send them by email to share with your family and friends! WCC4 can record the HD video from webcam which up to 720p HD 30fps.




### **System Requirements**

Make sure that your PC meets the following minimum system requirements before running **Webcam Companion 4**

	Minimum	Recommended
Hardware		
CPU	Intel® Core™2 Duo 2.2 GHz	Intel® Core™2 Quad2.83 GHz
RAM	256 MB	1G DDR2
Disk Space	500 MB	1GB
DirectX	DirectX 9	DirectX 10
Software		
Operating System	Windows XP/Vista/7	
DirectX	DirectX 9 or above	

How to use Webcam Companion 4














	<b>Capture</b> The module allows you to capture a still image and video from your webcam.
	<b>Fun Frame</b> The function can personalize your photos with various templates and layouts.
	<b>Edit Module</b> Provides functions for you to enhance your captured photos and videos, and save the modified files to your local disk.

## Capture Module

On the Capture Preview screen, you can view live video from the webcam. The Capture tools display in this section let you capture media files.



	<b>Full Screen</b> Display the current video or live preview full screen. Press ESC button to exit full screen mode.
	<b>Setting</b> Adjust your capture settings such as image and video formats, quality, devices, number of photos in burst, etc.
	<b>Webcam setting</b> View and modify your webcam settings/properties. The options here will vary depending on your device. Consult the device documentation for details on the available

	options.
	<b>Connect/Disconnect</b> Connect or disconnect your camera.
	<b>Take Picture</b> Capture a still image from the webcam.
	<b>Burst</b> Capture multiple images in quick succession. Click the "Settings" icon to define the number of images to capture in each burst.
	<b>Snapshot</b> Click to start the auto-snapshot process with V-sign gesture. If the program detects the V-sign gesture after taking a picture with people's face, it will continue to detect whether there is blink in the picture or not. If a blink exists, a mention message will pop up and ask you to save or cancel the picture.
	<b>Record Video</b> Begin capturing video from your camera. The button will change to "Stop Recording" while capturing. Click it again to stop capturing. The recording time will show at the top of the capture preview section.
	<b>Record Audio</b> Click this button to capture audio from your camera. The button will change to "Stop Recording" while capturing. Click it again to stop capturing. The recording time will be shown at the top of the capture preview window.
	<b>Live Annotation</b> Add annotations to the live video. After annotations have been added, you can click "Take Picture" to save them as a still image; or you can also click "Record Video" before you start to record the entire annotation process as a video clip.
	<b>Preview Media Files</b> Launch the Photo Viewer or Media Player to view the selected photos or videos from the current album.



**Find Target**

Go to the location where you archive your captured files.






## Fun Frame Module

The Fun Frame function can personalize your photos with various templates and layouts.

Just choose your favorite template or layout to customize your photos and click to print it out or send it to your family and friends.

**Snap shot**






Click to start the auto-snapshot process with pose detection.










	<b>Take Picture</b> Capture a still image from the webcam.
	<b>Preview Media Files</b> Launch the Photo Viewer or Media Player to view the selected photos or videos from the current album.
	<b>E-mail</b> E-mail the captured images or videos as attachments from your e-mail program.
	<b>Print</b> Print your captures to share with your friends and family.
	
	<b>Pose Detection Sensitivity</b> Drag and drop the slider to adjust the sensitivity for Pose Detection function.







## Edit Module

The Edit Module provides functions for you to enhance your captured photos and videos, and save the modified files to your local disk.



	<b>Find Target</b> Go to the location where you archive your captured files.
	<b>E-mail</b> E-mail the captured images or videos as attachments from your e-mail program.
	<b>Print</b> Print your captures to share with your friends and family.
	<b>Delete</b> Remove the selected files from the current album. When you delete a thumbnail from the albums, the corresponding file will also be removed from your local disc.
	<b>Upload to Twitter</b> Upload the edited file to Twitter to post for others to view

	<b>Upload to Flickr</b> Upload the edited file to Flickr to post for others to view.
	<b>Upload to YouTube</b> Upload the edited video file to YouTube to share with your friends.
	<b>Auto Enhance</b> Click the Auto Enhance button to improve the overall quality of your pictures with a single click.
	
	<b>Adjust Brightness</b> Drag and drop the slider to lighten or darken your image.
	
	<b>Adjust Contrast</b> Drag and drop the slider to adjust the contrast of a photo manually.
	
	<b>Adjust Blur</b> Drag and drop the slider to smooth rough edges or sharpen fuzzy areas.
	<b>Zoom In</b> Enlarge the active photo within the preview area.
	<b>Zoom Out</b> Reduce the size of the active photo within the preview area.
	<b>Rotate Left 90</b> Rotate the active photo 90-degrees counter-clockwise.

	<b>Rotate Right 90</b> Rotate the active photo 90-degrees clockwise.
	<b>Flip</b> Create a mirror image of the photo.
	<b>Undo</b> Undo the last action. You can use this command to correct a mistake.
	<b>Redo</b> This command reverses the last Undo command.
	<b>Resize</b> Resize the active photo. A window will appear where you can type in the values for photo width and height, or choose to Keep Aspect Ratio.
	<b>Crop</b> Remove unwanted area from the image. Use the Crop Tool to define a rectangular or square area. Once the area is defined, the area outside the selection will turn dark. Click the Crop button located under the Preview area to apply the crop operation.

## Trouble shooting

### **Q1: My computer cannot detect the web camera when connected with an extended USB cable.**

Solution:

- Connect the web camera directly to a USB port on your computer. Make sure the web camera is connected to the USB port at the

back of your computer. Some USB ports at the front of computers may not supply sufficient power for your web camera.

**Q2: Insufficient system resources reserved for the USB port, causing the system to be unable to function.**

There are too many devices in the system, causing IRQ problems with the system's USB controller.

Do the following:

- Remove some USB devices from the system.
- Restart the system.
- The computer reallocates resources.

**Q3: The web camera does not light up or the computer restarts for no apparent reason.**

You may have a USB device drawing too much power from your computer. This can happen especially when connecting USB devices to a passive or self-powered USB hub. A **USB Hub Power Exceeded** dialog box appears.

Try the following:

- Connect the web camera directly to your computer's USB port.
- Use a USB hub with an external power supply.