



H i g h C u r r e n t G a m e r

**HCG-900**

**POWER SUPPLY**

**USER'S MANUAL**

## HCG-900

Making quad rail power and highly advanced power supply design available at a popular wattage, the HCG-900 features special High Current connectors and heavy-duty cabling, earning it NVIDIA® SLI®-Ready and AMD Crossfire certifications. At the same time the HCG-900 is also 80 PLUS® BRONZE certified for efficiency, and features active PFC with a swift, quiet 135 mm double ball bearing fan so you know you're getting not only High Current, but also high efficiency and excellent cooling. If loads of power, High Current engineering and exceptional efficiency are what you're after, the HCG-900 is the perfect PSU for you.

## STANDARDS AND FEATURES


The connectors and power specifications of the HCG-900 PSU are all compatible with ATX12V v2.32 and EPS12V v2.92 specifications. The HCG-900 features Universal Input, which automatically senses when you connect the power supply to any AC power source between 100 - 240V without setting a voltage switch. This power supply also features Active Power Factor Correction (PFC), which improves the power factor value of the power supply by altering the input current wave shape, helping to power transmission across the grid.

## SYSTEM PROTECTION

A variety of industrial-grade safety circuitry will help protect your computer: Over Current Protection (OCP), Over Voltage Protection (OVP), Under Voltage Protection (UVP), Short Circuit Protection (SCP), Over Power Protection (OPP), Surge & Inrush Protection (SIP) and Brown-Out Protection (BOP). Sometimes the PSU will “latch” into a protected state. You will need to power off the PSU and clear the fault before it will function again. There are no user-replaceable fuses in your HCG-900.

## 80 PLUS® CERTIFICATION

80 PLUS® certification is the most widely recognized independent standard in power supply efficiency. An 80 PLUS® certified power supply uses less energy and generates less heat to stay cooler, run quieter and last longer. The HCG-900 has been 80 PLUS® BRONZE certified to be at least 82% efficient at a wide range of operating loads; this will lower your operating costs and help protect the environment.










## POWER OUTPUT

To see the output capacity and regulation for each different voltage, see table 1.

**TABLE 1**


Output Voltage	Load Max.	Regulation	Ripple & Noise
+12V <sub>1</sub>	40A	± 5%	< 120 mV
+12V <sub>2</sub>	40A	± 5%	< 120 mV
+12V <sub>3</sub>	40A	± 5%	< 120 mV
+12V <sub>4</sub>	40A	± 5%	< 120 mV
+3.3V	25A	± 5%	< 50 mV
+5V	25A	± 5%	< 50 mV
-12V	0.5A	± 10%	< 120 mV
+5Vsb	3A	± 5%	< 50 mV

TABLE 2


Cable Quantity	Connectors	Description
1	 X 1	24(20+4)-pin Motherboard
1	 X 1	8(4+4)-pin ATX12V/EPS12V
2	 X 2	8(6+2)-pin PCI-E
1	 X 3	Molex
	 X 1	FDD
1	 X 3	Molex
3	 X 3	SATA

## INSTALLATION

Install the PSU into either the top or bottom of your case with the four screws provided. Refer to your case manual if you are unsure where the power supply should be installed.




Connect the 24-pin main power connector to your motherboard.




Connect the 8-pin or 4+4-pin connector for the CPU. If your motherboard has an 8-pin socket with a cover on some of the openings, we recommend that you remove the cover and use the 8-pin connector.

Note: Please also refer to your motherboards manual for any special instructions.



Connect the AC power cord to the power supply AC inlet. Be sure to use the heavy-duty cord supplied with your PSU.



PCI-E graphics cards use different amounts of power. For some, a single 6-pin connector is sufficient, making the hardwired connector the preferred choice. More powerful cards use multiple connectors, including the advanced 8-pin PCI-E connector. The 8-pin PCI-E connector on the PSU can be used as either a 6- or 8-pin connector.

Hard drives, optical drives (CD/DVD/BluRay™) and other accessories will use either the older 4-pin Molex connector or the newer 15-pin SATA connector. 4-pin Molex connectors have two black, one yellow and one red wire. The SATA connector has an additional orange power wire.

When you have all the connections secured, turn the switch on the PSU to the “|” position.



## Technical Support:

[www.antec.com/support](http://www.antec.com/support)

### USA & Canada

1-800-22ANTEC    [nasupport@antec.com](mailto:nasupport@antec.com)

### Europe

+49-(0)40-226-139-22    [eusupport@antec.com](mailto:eusupport@antec.com)

### Asia

+886 (0)800-060-696    [apsupport@antec.com](mailto:apsupport@antec.com)

Visit us on Facebook for contests, information & support

USA & Canada    [facebook.com/AntecInc](https://facebook.com/AntecInc)

Europe    [facebook.com/AntecEurope](https://facebook.com/AntecEurope)

UK    [facebook.com/AntecUK](https://facebook.com/AntecUK)

Australia & New Zealand    [facebook.com/AntecAU](https://facebook.com/AntecAU)

India    [facebook.com/AntecIndia](https://facebook.com/AntecIndia)

Israel    [facebook.com/AntecIsrael](https://facebook.com/AntecIsrael)

Philippines    [facebook.com/AntecPH](https://facebook.com/AntecPH)

Singapore    [facebook.com/AntecSG](https://facebook.com/AntecSG)

Sweden    [facebook.com/AntecSweden](https://facebook.com/AntecSweden)

Antec, Inc.

47900 Fremont Blvd., Fremont, CA 94538 / USA

Tel: 510-770-1200 - Fax: 510-770-1288

[www.antec.com](http://www.antec.com)

© 2011-2012 Antec, Inc. All rights reserved.

Specifications are subject to change without prior notice. Actual product(s) and accessories may differ from illustrations. Omissions and printing errors excepted. Content of delivery might differ in different countries or areas. Some trademarks may be claimed as the property of others.

Reproduction in whole or in part without written permission is prohibited.