

WarioWare D.I.Y. help



SEZMARQUE1 1 posts since

Apr 1, 2010

I need help. When I am playing the games in the game blender sometimes the screen is green and I cant do anything and I lose at the game. What should I do?



COMPUTERS 90 posts since

Apr 1, 2010 1. Re: WarioWare D.I.Y. help Apr 3, 2010 12:22 AM

I'm unsure on why your screen is going a solid color in this phase of the game, but I recommend contacting Nintendo Consumer Service as a repair to either the game or system itself may be required.

NINTENDO CONSUMER SERVICE:

1-800-255-3700

6am - 7pm, Pacific Time, 7 days a week.

Hope this helps you out!



AUTOSAVER1 635 posts since

Apr 2, 2010 2. Re: WarioWare D.I.Y. help Apr 3, 2010 9:33 AM

My brother has the same error.

If its just this game, then its a faulty game. If its issue for all games, you'll need a repair.

My brother gets a green/red screen whenever he plays his games. Sorry.. there isn't a fix.



BRANDOS12 219 posts since

Apr 1, 2010 3. Re: WarioWare D.I.Y. help Apr 3, 2010 10:37 AM

The following is from Nintendo's Support site.

Occasional lockups with video games can happen from time-to-time and do not necessarily indicate a need for repair or replacement. If you are experiencing frequent lockups, or a particular game always locks up in the same area, please see the information below.

- Make sure you are using only [licensed](#) accessories. Unlicensed products and accessories do not undergo Nintendo's testing and evaluation process. They may not work at all with our game systems, and they may have compatibility problems with certain games or accessories.
- Check for visible contamination or foreign material on the connector pins of your Game Cards or Game Paks. If you see contamination or foreign material on a Game Card, please [click here](#) for replacement information.
- Does the problem occur frequently with multiple games? If so, it may be difficult to determine if the problem is with the system itself, the games, or a combination of both. Please call (800) 255-3700 so that Nintendo may assist you further
- If possible, try the Game Card in any other Nintendo DS system (including Nintendo DS and Nintendo DS Lite systems).

- If the game still does not work in another system, it is likely a problem with the Game Card. Please review Nintendo's Nintendo DSi [Game Card replacement options](#) to determine how to get your game replaced.
- If the game works properly in another system, the problem is with your Nintendo DSi or Nintendo DSi XL and it will need to be repaired. Please [click here](#) for repair options.

If you are not able to try the game in another system, or the above troubleshooting steps haven't narrowed the problem down, it is impossible to determine for certain whether the problem is the system or the Game Card. Please contact Nintendo's Consumer Department at (800) 255-3700 for assistance.



[BRANDOS12](#) 219 posts since

Apr 1, 2010 [4. Re: WarioWare D.I.Y. help](#) Apr 3, 2010 11:01 AM

I pre-ordered WarioWare D.I.Y. last week and it is still coming in the mail. Once I finally get it, I will see if I experience this issue also.



[METASTICK](#) 6 posts since

Apr 17, 2010 [5. Re: WarioWare D.I.Y. help](#) May 5, 2010 4:49 PM

Do you mean that the frame of the microgame is there, but the game itself is a solid color? If so, it sounds like you have a faulty cartridge.



[AUTOSAVER1](#) 635 posts since

Apr 2, 2010 [6. Re: WarioWare D.I.Y. help](#) May 5, 2010 5:58 PM

Ugh X_x I put a wrong answer....

Does this happen to other games? If it doesn't, it might be a cartridge fault. You might want to get a replacement.